



HIGH VOLTAGE

POWER SUPPLIES, X-RAY GENERATORS & MONOBLOCK® X-RAY SOURCES







Powering the Future of Advanced Technologies

spellmanhv.com

01.08.2024





Plastics Sorting

Mineral Analysis

Crystal Inspection

X-Ray Fluorescence

Plating Measurement

X-Ray Diffraction

Thickness Gauging

Cargo Screening

Food Inspection

NDT Analysis

Undersea Telecom

Security Applications

Radiography

Fluoroscopy

Extraoral Dental X-Ray

Bone Densitometry

Mammography

Mass Spectrometry

Capillary Electrophoresis

Electrostatic Printing

Ion Beam Implantation

Semiconductor Processing

Electron Beam Welding

Capacitor Charging

High Power RF Transmitters

Spellman High Voltage.

Powering the Future of Advanced Technologies



For over 75 years, Spellman has been helping technology companies grow by providing standard and custom high voltage power converters, X-Ray generators and Monoblock® X-Ray sources of exceptional value and

performance and by aligning our procedures, processes and infrastructure to support our cutomers' goals – a process we call homologation. At Spellman, homologation is in everything we do. From initial product concept through final delivery, we dedicate a team of experts to work with each customer.

Your Vision is Our Mission

Spellman advances medical care, industrial processes, quality control, scientific research, security and telecommunications by providing innovative high voltage power conversion solutions that enable equipment manufacturers to improve their systems' performance, reliability, cost and bottom line.

Innovation & Quality

With over 75 years of high voltage innovation, world-class ISO certified production facilities and global support network, Spellman can meet the needs of discriminating global OEM's system manufacturers

Compliance and Safety

Safety and Regulatory Agency approvals such as: UL, CSA, and IEC can be provided. In addition, Spellman is authorized to conduct UL sanctioned testing

Risk Management

Consistent processes across multiple facilities ensures a secure supply chain. Products can be manufactured at multiple Spellman sites. With standardized manufacturing, training and equipment, you can be assured of quality products and service for years to come

Support and Service

Our globally situated technical support centers are strategically located to provide rapid local response to customer needs Support Centers are linked through a common ERP system and real-time data reporting so information is always available about your product and delivery status

PRODUCT INDEX

MODULAR SUPPLIES

MODEL	MAX. VOLTAGE	MAX. POWER	PAGE
MSA	1–3kV	0.9W	4-5
MS	300V-3kV	3W	6-7
PMT	500V-7.5kV	1.9-4W	8-9
UM	62.5V-6kV	4W-30W	10-15
UM8-40	8kV-40kV	4W-30W	16-21
MPS	1kV-30kV	10W	22-24
MPD	1kV-30kV	10W	25-27
MPS20W	1kV-20kV	20W	28-29
SMS	1kV-60kV	60W	30-31
UMW	8kV-20kV	60W, 125W	32-35
SLM	1kV-160kV	300W-1.2kW	36-39

RACK MOUNT SUPPLIES

MODEL	MAX. VOLTAGE	MAX. POWER	PAGE
SL	1kV-130kV	10W-1.2kW	40-44
SL150KV	150kV	1.2kW	45-46
SL2KW	500V-50kV	2kW	47-50
SLS	160kV-360kV	2kW	51-54
STA	1kV-70kV	4kW	55-57
STR	1kV-150kV	6kW	58-60
ST	1kV-225kV	12kW-180kW	61-65

X-RAY GENERATORS

MODEL	MAX. VOLTAGE	MAX. POWER	PAGE
XLG	30kV-130kV	3W-260W	66-67
XMPF	10kV	5W	68-69
XMPG	10kV	10W	70-71
MNX	50kV, 65kV	50W, 65W, 75W	72-74
uX	50kV, 65kV	50W, 65W, 75W	75-79
MFX	50kV, 65kV	50W, 65W, 75W	80-82
XRF	160kV	80W, 320W, 640W	83-84
uXHP	50kV-80kV	100W	85-88
DXM	20kV-160kV	300W-1.2kW	89-93
DXB	40kV-320kV	300W-1.2kW	94-96
DXM100	100kV	300W-1.2kW	97-99
XLF	60kV	600W-1.2kW	100-101
XRV	160kV-450kV	1.8kW-6kW	102-105
XRV Controller	•		286
XRV I/O Box			287-290
DF/FF	60kV	3kW-4kW	106-107
VMX	40kV	5kW	108-110
PMX	49kV	5kW	111-113
PMX70	70kV	12kW	114-116
CCT	60kV-140kV	32kW, 42kW, 50kW	117-118
CT	60kV-140kV	32kW-110kW	119

PORTABLE X-RAY IMAGING

MODEL	MAX. VOLTAGE	MAX. POWER	PAGE
SPX	160kV-300kV	800W-900W	120-126
Tube Stand			127-128
SPX Laser P	ointer		129

MONOBLOCK® X-RAY SOURCE

MODEL	MAX. VOLTAGE	MAX. POWER	PAGE
XRB011	80kV	20W, 50W	130-133
uXRB130P65	130kV	65W	134-138
XRB80N100	80kV	100W	139-142
XRB80PN100HR	80kV	100W	143-148
XRB100N100	100kV	100W	149-151
XRBHR	80kV-100kV	100W-500W	152-159
XRBD	160kV	100W-500W	160-167
XRB180PN200	180kV	200W	168-170
XRBe80PN300	80kV	300W	171-175
XRB80PN320	80kV	320W	176-178
XRB200PN400/CT	200kV	400W	179-181
XRB160PN480/1	160kV	480W	182-184
XRB160PN480/2	160kV	480W	185-187
XRB160PN480/CT	160kV	480W	188-190
XRB200PN500	200kV	500W	191-193
XRB150PN600	150kV	600W	194-196
XRB160PN688/CT	160kV	688W	197-199
PDM90PN900	90kV	900W	200-202
MMB125PN3.5	125kV	3.5kW	203-205

APPLICATION SPECIFIC

APPLICATION SPECIFIC				
MODEL	MAX. VOLTAGE	MAX. CURRENT	PAGE	
Mass Spectrometry				
MI1.5PN24 ML430 ML1350 MX2.5 MX8 PLUS MX10 MX20 MXE MX10 PLUS MXR MCP TOF3000 MCP4	1.5kV 430V 245V-1350V 2.5kV 8kV 10kV 20kV 2.5kV-10kV 2.3kV-10kV 20kV, 30kV 3kV 30kV	6.5mA 12mA-25mA 15mA 60µA 100µA 100µA 200µA 200µA 300µA 330µA 400µA	206-207 208-209 210-211 212-213 214-215 216-217 218-219 220-221 222-223 224-225 226-227 228-229 230-231	
E Beam/IBeam FIB EBM20N5/24 EBM-TEG EBM-TEGR EBM-FEG EBM60-FEG VS100	35kV 20kV 30kV 30kV 30kV 60kV	30µA 250µA 170µA 400µA 200µA 300µA 100µA	232-234 235-237 238-239 240-241 242-244 245-247 248-249	
Power Feed Equipmen	nt			
PFE-P PFE-LV PFE-HV PFE-SB	6kV 6kV 6kV-15kV 6kV-20kV	1.0A 1.2A 1.5A 2A-2.5A	250-252 253-254 255-256 257-260	
Image Intensifiers				
DGM935 DGM945 Electrophoresis/	30kV 30kV Ospinning 30kV	30μΑ 50μΑ 300μΑ	261-262 263-264 265-266	
CZE2000	5kV-30kV	0.3mA-2mA	267-268	
Capacitor Charging CCM1KW CCM e-Beam Evaporation EVA	1kV-4kV 4kV 5kV-10kV	500J/s- 1000J/s 3100J/s 3kW, 6kW, 12kW	269-271 272-273	
Electrostatic Chuck	OVA-IOVA	ORIV, ORIV, IZRVV	214-200	
MSC2.5PN7.5 ECHUCK Injector Control	2.5kV 2kV–5kV	3mA 5mA	281-282 283	
ICA	15kV	5.5mA	284-285	

ACCESSORIES

MODEL	PAGE
XRV Controller	286
XRV I/O Box	287-290
HVD	291

 Compact High Performance Module Variable Voltage Programming

Arc and Short Circuit Protected

0.9W REGULATED PCB Mount hv Power Supply



able (PCB) high voltage power supply module available

from 1kV to 3kV with either a positive or negative output

polarity. The MSA Series feature 0-10Vdc variable voltage

programming that equals 0-100% of rated output voltage. A voltage monitor is provided where 0-10Vdc equals

0-100% of rated output voltage. Additionally a status signal and enable signal provides simple control of the

fault conditions.

unit reducing radiated noise.

Photomultiplier Tubes

TYPICAL APPLICATIONS

Electron Multiplier

Mass Spectrometry

Electrostatic Lenses

Nuclear Instruments

SPECIFICATIONS

+24 Vdc, ±2Vdc

150mA maximum input current

30mA pk-pk maximum input current ripple

Input Voltage:

Input Current:

power supply. All units have in-built protection against

is required, like driving an electron multiplier in a mass

spectrometer. The aluminium enclosure helps shield the

The MSA Series are intended for general use where a

compact high performance PCB mountable power supply



Output Polarity:

Positive or negative, specify at time of order

Output Power:

0.9 watts, maximum

 0.9 Watts Output Power **Voltage Monitor**

Output Voltage Accuracy:

±1%

Voltage Regulation:

Line: 21.6Vdc to 26.4Vdc, ±0.02% Load: 0-100% rated load, ±0.02%

Stability:

50ppm/8hrs after one hour warm up period

Temperature Coefficient:

25ppm per degree C

Settling Time:

After Power On or Enable:

100 milliseconds, typical

When power is removed the unit will decay to <±60 volts within 2 seconds

Protection:

Arc and short circuit protected.

Not designed to withstand continuous arcing

Environmental:

Temperature Range:

Operating: 0°C to 60°C

Storage: -20°C to 70°C

Humidity:

95% RH, non-condensing

Cooling:

Convection cooled

Dimensions:

2.73" L x 2.21" W x 1.21" D (69.4mm x 56.2mm x 30.7mm)

Weight:

7.0 oz. (200g)

Regulatory Approvals:

Designed to meet EN 61010-1, UL 61010A-1 and

CAN/CSA-22.2 No. 61010.1

As the unit is intended for incorporation into end users equipment it will not be tested as a standalone unit to meet the EMC directive. The user will need to follow sensible EMC precautions in using the unit. The unit is compliant with the EU RoHS directive.



e-mail: sales@spellmanhv.com

PAGE 2 OF 2

MSA SELECTION TABLE

	Model	Output Voltage	Output Current	Ripple (Vpp)
ı	MSA1*24	0-1kV	0-900μΑ	30mV
ı	MSA2*24	0-2kV	0-450μΑ	40mV
ı	MSA3*24	0-3kV	0-300μΑ	50mV

- Replace the * with "P" for positive output polarity and "N" for negative output polarity.
- 2) The ripple figure includes random non switch related noise, noise related to the oscillator, switching and feedback control circuitry and noise associated with the rectified primary switching frequency.

LOW VOLTAGE SIGNAL PINS FOR POWER AND CONTROL

PIN	SIGNAL	LEVEL	SIGNAL PARAMETERS
1	Enable	TTL	Enable = Low (\leq 1.2V). Disable = High (\geq 2.4V), when Enable pin is NC, $10k\Omega$ pull up to $+5V \pm 10\%$
2	2 Status 0V/5		OK = 11kΩ pull up to +5.1V ±10%. Fault = \leq 0.1V, Zout = 1kΩ
3	Voltage Program	0-10V	0 to \pm 10Vdc = 0 to 100% rated output voltage, Accuracy = \pm 1%. Zin = 10k Ω
4	Voltage Monitor 0-10V		0 to +10Vdc = 0 to 100% rated output voltage, Accuracy = $\pm 2\%$. Zout = 20 k Ω
5	Input Voltage	24Vdc	Power Input
6*	Signal Ground	OV	Ground reference for control and monitoring signals
7*	Power Ground	0V	Power Return


To reset the unit after a fault condition, Pin1 (Enable) must be set high for at least 10 seconds

HIGH VOLTAGE CONNECTION DETAIL


	SIGNAL	SIGNAL PARAMETERS
8	High Voltage Output	0-100% Rated Output. !!Danger: High Voltage!!

DIMENSIONS: in.[mm]


TOP VIEW




FRONT VIEW



BOTTOM VIEW



SIDE VIEW







^{*} pins 6 & 7 are linked internally





Spellman's MS Modules have been designed for printed circuit board mounting with high reliability, small size and light weight. The MS 3W modules provide well regulated, low ripple, high stability output voltages ranging from 300V to 3kV in a versatile, compact and cost-effective design. The modules incorporate remote control and arc & short-circuit protection. Radiated pickup is eliminated by sealing each module in an aluminum enclosure.

TYPICAL APPLICATIONS

Photomultiplier Tubes Precision Lenses Image Intensifiers Nuclear Instruments Spectroscopy

OPTIONS

I Isolated Input to Output
Maximum Isolation Voltage:
40V for units ≤1kV
100V for units >1kV

Note: this option is only available for certain models, please consult Spellman for availability.

SPECIFICATIONS

Input Voltage:

+12Vdc ±1V. Other input voltages also available.

Input Current:

< 0.65A at full output.

Output Voltage:

Continuously adjustable over each entire range Models available in either positive or negative polarity. See table for voltage ranges.

- Low Cost
- Output Voltages up to 3kV
- 3 Watts Power Rating
- Positive or Negative Polarity
- Arc and Continuous Short Circuit Protected
- Low Stored Energy
- High Reliability
- Internal 5V Reference
- OEM Customization Available

Output Voltage Control:

Remote voltage programming such that 0-5Vdc gives 0 to full rated output

Output Power: 3W continuous.

Voltage Regulation:

Line: 0.005% for input change of 1V. (<0.01% for MS0.3 units)

Load: 0.05% for 100µA to full load change at maximum

voltage. (<0.1% for MS0.3 units)

Ripple: See MS selection table **5Vdc Reference:** +5.0V (±0.2V)

A maximum of 1mA can be drawn from this output.

Temperature:

Operating: 0°C to +50°C. Storage: -35°C to +85°C.

Temperature Coefficient: 50ppm/°C typical.

Stability:

< 0.05%/8 hrs at constant operating conditions after one hour warm-up.

Humidity: 0 to 90% non-condensing.

Dimensions:

Units ≤1kV:

.87"H x 2.1"W x 3.1"D (23mm x 53mm x 78mm).

Units >1kV:

1.1"H x 2.36"W x 4.2"D (28mm x 60mm x 106mm).

Weight:

Corporate Headquarters

Units $\leq 1 \text{kV}$: 0.2lb (80g). Units > 1 kV: 0.4lb (160g).

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. UK Conformity Assessed. RoHS Compliant.





MS SELECTION TABLE

OUTPUT VOLTAGE (V)	OUTPUT CURRENT (mA)	RIPPLE V (p-p)	MODEL
300	10	0.05	MS0.3*
500	6	0.05	MS0.5*
750	4	0.075	MS0.75*
1000	3	0.10	MS1*
1500	2	0.15	MS1.5*
2000	1.5	0.20	MS2*
2500	1.2	0.25	MS2.5*
3000	1	0.30	MS3*

How To Order:

MSXX*12/C/I

where:


XX is the Output voltage (see selection table) * is the polarity: P for positive / N for negative

12 is the input voltage. This is 12V /I is the floating output option, if required


Examples: MS2P12/C MS0.3P12/C/I

DIMENSIONS: in.[mm]

SIDE VIEW



BOTTOM VIEW




UNIT > 1000V UP TO 3000V

SIDE VIEW



BOTTOM VIEW



View on pins.
Recommended hole size for terminals 1mm.







PAGE 1 OF 2



Spellman's Bertan brand of PMT modular high voltage power supplies offer well regulated, fixed polarity outputs up to 7.5kV, which operate off a low voltage DC input voltage. These fully enclosed modules are specifically designed with proprietary linear power conversion techniques to provide exceptionally low ripple and noise. The PMT is ideal for precision applications including: photomultiplier tubes, solid state detectors and ultrasonic transducers.

The output voltage can be controlled by either a local internal potentiometer or by a customer provided ground referenced signal for remote operation. Additionally a ground referenced output voltage monitor signal is provided. The PMT can be powered from either a single positive voltage source or a split ± voltage source, providing application flexibility.

TYPICAL APPLICATIONS

Photomultiplier tubes Ultrasonic transducers Solid state detectors

SPECIFICATIONS

Input Voltage:

Option 1: ± 24 Vdc to ± 30 Vdc @ 400mA Option 3: ± 12 Vdc to ± 18 Vdc @ 400mA

specify "-1" (option 1) or "-3" (option 3) when ordering

Efficiency:

≈50%, typical

Output Polarity:

Positive or negative, specify at time of order

Output Voltage:

See "model selection" table

Output Current:

See "model selection" table

Output Power:

1.875W, 2W, 2.5W, 3W, 4W

Voltage Regulation:

Line: ±0.001% of rated output voltage for a +1% input line change

Load:±0.001% of rated output voltage for a full load change

500V to 7.5kV @ 1.9 to 4 Watts

- Low Cost Modular Design
- Excellent Stability & Regulation
- Low Noise & Ripple
- Arc & Short Circuit Protected
- UL Recognized and RoHS Compliant

Ripple:

See "model selection" table

Stability:

≤0.005% per hour, 0.02% per 8 hours, after a 1/2 hour warm up

Accuracy:

Remote Programming $\pm(2\%$ of setting, $\pm0.5\%$ of maximum) Voltage Monitor $\pm2\%$

Temperature Coefficient:

≤50ppm/°C

Arc/Short Circuit:

All units are fully arc and short circuit protected and will limit continuous short circuit output current to less than 150% of maximum rated output current.

Operating Temperature

0°C to +50°C

Storage Temperature:

-40°C to +85°C

Humidity:

20% to 85% RH, non-condensing

Interface Connector:

12 position card edge connector, mate provided with unit

Output Connector:

A captive 24" (610mm) of RG-59B/U shielded cable, unterminated is provided

Cooling:

Convection cooled.

Dimensions:

3.875 W X 1.25 H X 6.3125 D (98mm x32mm x 160mm)

Weight

Corporate Headquarters

≤2.0 pounds (0.9kg)

Regulatory Approvals:

Designed to meet EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized File E148969. RoHS compliant.





MODEL SELECTION TABLE

Model	Output Voltage	Output Current	Ripple (Vpp)
PMT-05C-P,N	0 to 500V	0 to 8mA	5mV
PMT-10C-P,N	0 to 1kV	0 to 4mA	4mV
PMT-20C-P,N	0 to 2kV	0 to 2mA	2mV
PMT-30C-P,N	0 to 3kV	0 to 1mA	6mV
PMT-50C-P,N	0 to 5kV	0 to 0.5mA	10mV
PMT-75C-P,N	0 to 7.5kV	0 to 0.25mA	100mV

Specify "P" for positive polarity or "N" for negative polarity

INTERFACE CONNECTOR

Signal	Parameters	Option 1 Pin Number	Option 3 Pin Number
+ Power Input	+24Vdc to +30Vdc or +12Vdc to +18Vdc	3&4	3 & 4 & 5
- Power Input	-12Vdc to -18Vdc	n/a	2 & 6
Ground	Ground	1 & 12	1 & 12
Voltage Monitor	See Voltage Monitor Table	11	11
+9Vdc Reference	+9.0Vdc, 10mA maximum	10	10
Voltage Program Input			8
Local Voltage Program	Internal program potentiometer wiper, 0 to 9Vdc	9	9


VOLTAGE MONITOR TABLE

Model	Signal Voltage	Signal Impedance
PMT-05C-P,N	0 to 5 volts	50k ohms
PMT-10C-P,N	0 to 1 volts	10k ohms
PMT-20C-P,N	0 to 2 volts	25k ohms
PMT-30C-P,N	0 to 3 volts	30k ohms
PMT-50C-P,N	0 to 5 volts	100k ohms
PMT-75C-P,N	0 to 7.5 volts	200k ohms


Note: The Voltage Monitor polarity matches the high voltage output polarity

DIMENSIONS: in.[mm]


TOP VIEW



BOTTOM VIEW



FRONT VIEW





Hauppauge, New York USA

Corporate Headquarters

PAGE 1 OF 6



- 8 Voltage Ranges from 62.5V to 6kV, Fixed Negative or Positive Polarity
- Available Output Power Increments of 4, 20 and 30 Watts
- Voltage/Current Regulation with Automatic Crossover Control
- Voltage and Current Monitor Signals
- Fully Arc and Short Circuit Protected
- Precision +5V Reference Output
- Comprehensive Standard Interface
- CE Listed, UL Recognized and RoHS Compliant

Form, Fit and Function Design:

Spellman's UM Series of printed circuit board mountable, high voltage modules offer a form, fit and function replacement for presently available commercially made units, while providing additional features and benefits at competitive pricing. Utilizing proprietary power conversion technology and Spellman's six decades of high voltage experience, these SMT based high voltage modules provide improved performance/reliability and easier system integration at a lower cost when compared to the competition.

Advanced Power Conversion Topology:

UM converters use a proprietary zero voltage switching power conversion topology providing exceptional efficiency and inherent low noise and ripple. Radiated emissions are reduced compared to conventional switching topologies, minimizing or even eliminating the need to shield the unit from adjacent circuitry.

The high voltage output is generated using a ferrite core high voltage step up transformer which feeds the output circuitry. Units at 1kV or higher utilize an arrangement of half wave Cockcroft-Walton voltage multiplier stages to obtain the specified high voltage output, while lower voltage units use a robust rectification and filter circuit.

Due to the fixed, high frequency conversion rate the output capacitance is small resulting in minimal stored energy. Through the use of generously rated surge limiting resistors and a fast acting current loop, all units are fully arc and short circuit protected.

Control and Regulation:

The actual output voltage generated is sampled via a high impedance divider to create a voltage feedback signal. A current feedback signal is created via a current sense resistor in the low end return of the high voltage output circuitry. These two accurate ground referenced feedback signals are used to precisely regulate and control the units in addition to external monitoring purposes.

Due to the UM's unique converter topology it can provide full current into low impedance loads or even a short circuit. Standard units limit at 103% of maximum rated output current.

Standard Interface:

The Spellman UM Series interface provides current programming capability and positive polarity, buffered, low output impedance voltage and current monitor signals (zero to +4.64Vdc equals zero to full scale rated). A voltage programming input is provided where 0 to +4.64Vdc equals 0 to 100% of rated voltage.

Current programmability allows the user to set where the unit will current limit, anywhere from 0 to 100% of maximum rated current. This feature is beneficial where less than full output current is desired, like in the case of protecting a sensitive load.

The buffered low impedance voltage and current monitor signals can drive external circuitry directly, while minimizing loading and pickup effects. These features save the user the expense and implementation of external interface buffering circuitry while improving overall signal integrity.

This standard interface is made available via a row of 13 pins with 0.1" pin spacing. A legacy interface (7 pins on a 0.2" spacing) that is compatible with presently available commercially made units can be provided by ordering the "L" option.

Mechanical and Environmental Considerations:

The UM Series are solid encapsulated, printed circuit board mountable, plastic cased converters measuring only 2.97" X 1.5" X 0.83" (75.4mm X 38.1mm X 21.1mm). All units are encapsulated using a silicon based potting material which is considerably lighter in weight than epoxy. Two isolated, non grounded 2-56 machine screws thread into the module to securely mount it to the printed circuit board, relieving any stress on the interface pins. Mounting plates, brackets and flanged mounting options are also available

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588. RoHS Compliant.





SPECIFICATIONS

Input Voltage:

12Vdc for 4W, 24Vdc for 20W and 30W

Nominal Voltage Range:

11Vdc to 30Vdc for 4W, 23Vdc to 30Vdc for 20W and 30W

Input Current: (typical)

Disabled: 30mA No load: 90mA

Full load:

4 watt units: 0.5A 20 watt units: 1.0A 30 watt units: 1.5A

Efficiency:

80-85%, typical

Voltage Regulation:

Line: <0.01% Load: <0.01%

Current Regulation: Line: <0.01%

Load: <0.01%

Stability:

0.01% per 8 hours, 0.02% per day after 30 min. warmup

Accuracy:

2% on all programming and monitoring, except I Sense 10%

Temperature Coefficient: (typical)

Standard: 100ppm/°C

Optional: 25ppm/°C (T Option)

Environmental:

Temperature Range:

Operating: 0°C to 65°C case temperature Storage: -55°C to 85°C, non operational

Humidity:

10% to 90%, non-condensing.

Cooling:

Convection cooled, typical. 30 watt units operating at full power might require additional cooling to maintain case temperature below 65°C. Methods may include: forced air cooling, use of heat sink or metal case, etc. It is the user's responsibility to maintain the case temperature below 65°C. Damage to the power supply due to inadequate cooling is considered misuse and repairs will not be covered under warranty.

Dimensions:

2.96" L X 1.49" W X 0.81" H (75.2mm X 37.9mm X 20.6mm)

Weight:

4 oz. (113g), typical

UM 4W SELECTION TABLE

Model Number	Output V	Output Current	Low Freq. Ripple %Vp-p @ 1Hz-1kHz	High Freq. Ripple %Vp-p @ 1kHz-1MHz	Output Capacitance	Arc Limiting Resistance	I Sense Scaling Full Scale Signal	High Voltage Divider Resistance
UM0.062*4	0 to 62.5V	64mA	0.030	0.028	8.8µF	1Ω	1.5V	0.5ΜΩ
UM0.125*4	0 to 125V	32mA	0.045	0.014	8.8µF	4.4Ω	2.75V	0.88ΜΩ
UM0.25*4	0 to 250V	16mA	0.034	0.017	2.2µF	20Ω	4.9V	1.50ΜΩ
UM0.5*4	0 to 500V	8mA	0.036	0.040	0.8µF	94Ω	10.1V	2.65ΜΩ
UM1*4	0 to 1KV	4mA	0.025	0.015	0.2µF	470Ω	10.75V	20ΜΩ
UM2*4	0 to 2kV	2mA	0.022	0.015	0.097µF	1.0ΚΩ	10.4V	30ΜΩ
UM4*4	0 to 4kV	1mA	0.019	0.017	0.012µF	9.4ΚΩ	11.1V	100ΜΩ
UM6*4	0 to 6kV	0.67mA	0.016	0.015	0.007µF	20ΚΩ	9.9V	150ΜΩ

UM 20W SELECTION TABLE

Model Number	Output V	Output Current	Low Freq. Ripple %Vp-p @ 1Hz-1kHz	High Freq. Ripple %Vp-p @ 1kHz-1MHz	Output Capacitance	Arc Limiting Resistance	I Sense Scaling Full Scale Signal	High Voltage Divider Resistance
UM0.062*20	0 to 62.5V	320mA	0.060	0.088	8.8µF	1Ω	330mV	0.5ΜΩ
UM0.125*20	0 to 125V	160mA	0.067	0.044	8.8µF	4.4Ω	675mV	0.88ΜΩ
UM0.25*20	0 to 250V	80mA	0.035	0.019	2.2µF	20Ω	1.135V	1.50ΜΩ
UM0.5*20	0 to 500V	40mA	0.041	0.040	0.8µF	94Ω	2.25V	2.65ΜΩ
UM1*20	0 to 1KV	20mA	0.039	0.095	0.2µF	470Ω	4.35V	20ΜΩ
UM2*20	0 to 2kV	10mA	0.026	0.016	0.097µF	1.0ΚΩ	6.6V	30ΜΩ
UM4*20	0 to 4kV	5mA	0.023	0.028	0.012µF	9.4ΚΩ	6.65V	100ΜΩ
UM6*20	0 to 6kV	3.3mA	0.017	0.018	0.007µF	20ΚΩ	6.74V	150ΜΩ

UM 30W SELECTION TABLE

Model Number	Output V	Output Current	Low Freq. Ripple %Vp-p @ 1Hz-1kHz	High Freq. Ripple %Vp-p @ 1kHz-1MHz	Output Capacitance	Arc Limiting Resistance	I Sense Scaling Full Scale Signal	High Voltage Divider Resistance
UM0.062*30	0 to 62.5V	480mA	0.075	0.112	8.8µF	1Ω	500mV	0.5ΜΩ
UM0.125*30	0 to 125V	240mA	0.075	0.056	8.8µF	4.4Ω	930mV	0.88ΜΩ
UM0.25*30	0 to 250V	120mA	0.055	0.031	2.2µF	20Ω	1.65V	1.50ΜΩ
UM0.5*30	0 to 500V	60mA	0.085	0.041	0.8µF	94Ω	3.4V	2.65ΜΩ
UM1*30	0 to 1KV	30mA	0.032	0.171	0.2µF	220Ω	6.5V	20ΜΩ
UM2*30	0 to 2kV	15mA	0.031	0.112	0.097µF	470Ω	9.85V	30ΜΩ
UM4*30	0 to 4kV	7.5mA	0.028	0.071	0.012µF	4.4ΚΩ	9.85V	100ΜΩ
UM6*30	0 to 6kV	5mA	0.020	0.051	0.007µF	9.4ΚΩ	10.0V	150ΜΩ

Note: Total ripple is the sum of the low frequency and high frequency ripple. Grayed text indicates Legacy interface signals.

FAX: +1-631-435-1620

e-mail: sales@spellmanhv.com



+1-631-630-3000



STANDARD INTERFACE

PIN	SIGNAL	PARAMETERS
1	Power Ground Return	+12Vdc or +24Vdc power return/HV return
1A	Signature Resistor	Unique Identifying resistor connected to ground
2	+ Power Input	+12Vdc or +24Vdc power input
2A	N/C	
3	I Sense	See I Sense text and tables
ЗА	I Mon	0 to 4.64Vdc = 0 to 100% rated output. Zout < $10k\Omega$
4	Enable Input	Low (<0.7V, Isink@1mA)=HV OFF,
		High (open or >2V)=HV ON
4A	V Mon	0 to 4.64Vdc = 0 to 100% rated output. Zout $<$ 10k Ω
5	Signal Ground	Signal Ground
5A	I Pgm	0 to 4.64Vdc = 0 to 100% rated output. Zin > 47kΩ Leave open for preset current limit @103% of rated output current
6	Remote Adjust	Positive Polarity Unit: 0 to +4.64VDC = 0 to 100% rated voltage, Zin >1MΩ Negative Polarity Unit: +5VDC to 0.36V = 0 to 100% rated voltage, Zin >100kΩ Leave open if pin 6A (VPgm) is used for programming
6A	V Pgm	0 to 4.64Vdc = 0 to 100% rated voltage. Zin > 100kΩ Leave open if pin 6 (remote adjust) is used for programming
7	+5V Reference Output	+5Vdc ±0.5%, 50ppm/°C. Zout =475Ω
8	HV Ground Return	HV Ground Return
9	E Out Monitor	10:1 ratio for models below 1kV, 100:1 ratio for models 1kV and above. Polarity of Voltage Monitor signal equals polarity of unit. Accuracy is ±2%, 100ppm/°C. Calibrated with DVM with 10MΩ input impedance
10	HV Output	HV Output
11	HV Output	HV Output

Grayed out signals are provided for backward legacy compatability and their use

Power Ground Return, Signal Ground and HV Ground Return are connected internally. For best performance they should not be connected externally.

LEGACY INTERFACE (L OPTION)

PIN	SIGNAL	PARAMETERS
1	Power Ground Return	+12Vdc or +24Vdc power return/HV return
2	+ Power Input	+12Vdc or +24Vdc power input
3	l Sense	See I Sense text and tables for details
4	Enable Input	Low (<0.7V, Isink@1mA)=HV OFF, High (open or >2V)=HV ON
5	Signal Ground	Signal Ground
6	Remote Adjust	Positive Polarity Unit: 0 to +4.64VDC = 0 to 100% rated voltage, Zin >1M Ω Negative Polarity Unit: +5VDC to 0.36V = 0 to 100% rated voltage, Zin >100k Ω
7	+5V Reference Output	+5Vdc ±0.5%, 50ppm/°C. Zout =475Ω
8	HV Ground Return	HV Ground Return
9	E Out Monitor	10:1 ratio for models below 1kV, 100:1 ratio for models 1kV and above. Polarity of Voltage Monitor signal equals polarity of unit. Accuracy is ±2%, 100ppm/°C. Calibrated with DVM with 10MΩ input impedance
10	HV Output	HV Output
11	HV Output	HV Output

Power Ground Return, Signal Ground and HV Ground Return are connected internally. For best performance they should not be connected externally.

Standard Interface Connections

Seventeen (17) gold plated 0.025" (0.64mm) square pins suitable for direct PCB mounting. See mechanical drawing for location and spacing details.

Programming and Monitor Signals

Voltage and current programming is done via positive polarity, high input impedance, 0 to 4.64Vdc signals. Voltage and current monitors are positive polarity, buffered low output impedance 0 to 4.64Vdc signals.

The I Mon signal is a true output current monitoring signal. All internal offsets due to feedback divider currents have been compensated for.

Signature Resistor

A unique identifying signature resistor for each type of unit is connected from Pin 1A to ground. Details if desired are available upon request.

Legacy Interface Connections

Eleven (11) gold plated 0.025" (0.64mm) square pins suitable for direct PCB mounting. See mechanical drawing for location and spacing details.

I Sense Signal

The I Sense signal polarity is opposite of the output polarity of the module. This signal is protected via a transorb and provided via a series connected 47k isolation resistor. Internal HV dividers create a small, linear offset voltage on the I sense signal that can be compensated for.


Adhesive Backed Heat Sink

UM modules are provided with an uninstalled top mounted adhesive backed heat sink. Label removal is not required if the customer elects to install and use the provided heat sink.

The UM's internal power dissipation causes a case temperature rise. If the case exceeds 65°C, the unit needs external cooling (fan or heat sink). Even if the case is below 65°C, it is prudent to keep it much lower. Like a semiconductor device; the hotter it is, the shorter the life. For every 10°C reduction of temperature the lifetime will be increased by a factor of ≈2.35. The thermal resistance from internal circuitry to ambient is 8°C/watt without a heat sink (still air). This reduces to 6°C/watt with the heat sink.

Example:

Assuming ≈80% efficiency for a 20 watt UM module, the 5 watts of internal power dissipation would create a 40°C rise. Using the heat sink there would be only a 30°C rise. Ultimately it is up to the user to determine what cooling method is applicable for their application, but the general recommendation is to keep the module as cool as possible.





UM OPTIONS

C Option

Fast Rise Time Applications-

If applications demand a power supply that is optimized for fast rise time/low overshoot requirements, then the C Option should be considered. A Hysteretic control circuit is employed providing improved performance in these unique applications with higher ripple observed (1% Vpp typical). If used for capacitor charging, a Spellman Capacitor Charging Questionnaire should be filled out to assure all aspects of the intended usage is understood assuring the appropriate unit is provided. Speak to a Spellman sales person for more details.

T Option

Low Temperature Coefficient-

The T Option offers the UM with an improved temperature coefficient. The standard voltage feedback divider is replaced with one having a superior temperature coefficient, resulting in a unit with 25ppm/C° (typical) temperature coefficient.

Maximum short circuit discharge rate:

> CV² (f) <1 watt

С = Output capacitance of unit

C ext = External capacitance ٧ = Maximum rated voltage

f = Frequency of discharge

Ι = Nominal output current

= Rise time t_R

Typical Rise Time:

$$t_R = \frac{C + C \text{ ext}}{I} (V)$$

Minimum rise time is 3mS


PHYSICAL INTERFACING

A Option

Adapter Board-

Spellman's UM module can be fitted with an adapter board that will allow a drop in replacement for other commercially available modules of a physically larger size, while providing identical functionality with superior performance.






B Option

Terminal Block-

The B Option provides terminal block connections for both the customer interface and high voltage output/return. This feature can be helpful in situations where frequent wiring changes are anticipated, as in a testing





SHIELDING

or prototype

environment.

M Option

Mu Metal Shield-

UM modules can be fitted with an adhesive backed Mu Metal foil shield to help protect sensitive adjacent circuitry.




Same as standard unit. See page 6 of 6 for dimensional drawings







SHIELDING continued



CHASSIS MOUNTING









DIMENSIONS: in.[mm]

17 PIN - Standard Interface




ORDERING INFORMATION Voltage 0 to 62.5Vdc 0.062 0 to 125Vdc 0.125 0 to 250Vdc 0.25 0 to 500Vdc 0.5 0 to 1000Vdc 1 0 to 2000Vdc 2 0 to 4000Vdc 4 0 to 6000Vdc 6 **Polarity** Positive Ρ Negative Ν Power Watts Output 4 Watts Output 20 Watts Output 30

STANDARD UNIT ORDERING EXAMPLE



11 PIN - Legacy Interface



Note: There may be some restrictions on multiple option combinations. Please contact our sales department for more details.








OPTION ORDERING INFORMATION

OPTION	OPTION CODE
Legacy Interface	L
Fast Rise Time	С
Low Temperature Coefficient	Т
Adapter Board	А
Terminal Block	В
Mu Metal Shield	М
RF Tight Shielded Can	S
Eared Mounting Plate	Е
Eared Mounting Plate/Adapter Board	E2

OPTION ORDERING EXAMPLE





PAGE 1 OF 6



- 9 Voltage Ranges from 8kV to 40kV, Fixed Negative or Positive Polarity
- Available Output Power Increments of 4, 15 and 30 Watts
- Voltage/Current Regulation with Automatic Crossover Control
- Voltage and Current Monitor Signals
- Fully Arc and Short Circuit Protected
- Precision +5V Reference Output
- Comprehensive Standard Interface
- CE listed and RoHS compliant

Form, Fit and Function Design:

Spellman's UM Series of printed circuit board mountable, high voltage modules offer a form, fit and function replacement for presently available commercially made units, while providing additional features and benefits at competitive pricing. Utilizing proprietary power conversion technology and Spellman's six decades of high voltage experience, these SMT based high voltage modules provide improved performance/reliability and easier system integration at a lower cost when compared to the competition.

Advanced Power Conversion Topology:

UM converters use a proprietary zero voltage switching power conversion topology providing exceptional efficiency and inherent low noise and ripple. Radiated emissions are reduced compared to conventional switching topologies, minimizing or even eliminating the need to shield the unit from adjacent circuitry.

The high voltage output is generated using a ferrite core high voltage step up transformer which feeds a half wave Cockcroft-Walton voltage multiplier to obtain the specified high voltage output.

Due to the fixed, high frequency conversion rate the output capacitance is small resulting in minimal stored energy. Through the use of generously rated surge limiting resistors and a fast acting current loop, all units are fully arc and short circuit protected.

Control and Regulation:

The actual output voltage generated is sampled via a high impedance divider to create a voltage feedback signal. A current feedback signal is created via a current sense resistor in the low end return of the high voltage output circuitry. These two accurate ground referenced feedback signals are used to precisely regulate and control the units in addition to external monitoring purposes.

Due to the UM's unique converter topology it can provide full current into low impedance loads or even a short circuit. Standard units limit at 103% of maximum rated output current.

Standard Interface:

The Spellman UM Series interface provides current programming capability and positive polarity, buffered, low output impedance voltage and current monitor signals (zero to +4.64Vdc equals zero to full scale rated). A voltage programming input is provided where 0 to +4.64Vdc equals 0 to 100% of rated voltage.

Current programmability allows the user to set where the unit will current limit, anywhere from 0 to 100% of maximum rated current. This feature is beneficial where less than full output current is desired, like in the case of protecting a sensitive load.

The buffered low impedance voltage and current monitor signals can drive external circuitry directly, while minimizing loading and pickup effects. These features save the user the expense and implementation of external interface buffering circuitry while improving overall signal integrity.

This standard interface is made available via a row of 13 pins with 0.1" pin spacing. A legacy interface (7 pins on a 0.2" spacing) that is compatible with presently available commercially made units can be provided by ordering the "L" option.

Mechanical and Environmental Considerations:

The UM Series are solid encapsulated, printed circuit board mountable, plastic cased converters. All units are encapsulated using a silicon based potting material which is considerably lighter in weight than epoxy. Isolated, non grounded 2-56 machine screws thread into the module to securely mount it to the printed circuit board, relieving any stress on the interface pins. Mounting plates, brackets and flanged mounting options are also available. High voltage output is provided via a 36" (914.4mm) minimum length of appropriately rated high voltage wire.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588. RoHS Compliant.



PAGE 2 OF 6

SPECIFICATIONS

Input Voltage:

12Vdc for 4W, 24Vdc for 15W and 30W

Nominal Voltage Range:

11Vdc to 30Vdc for 4W, 23Vdc to 30Vdc for 15W and 30W 4W units can operate at 24Vdc input with no

deratings or damage to unit

Input Current: (typical)

10mA @ 24Vdc Disabled:

Full output, no load: 160mA @ 24Vdc, 300mA @ 12Vdc

Full output, full load:

330mA @ 24Vdc, 640mA @ 12Vdc 4 watt units:

15 watt units: 850mA @ 24Vdc 30 watt units: 1590mA @ 24Vdc

Voltage Regulation:

Line: <0.01% Load: <0.01%

Current Regulation:

Load: <0.01% Line: <0.01%

Stability:

0.01% per 8 hours, 0.02% per day after 30 min. warmup

Accuracy:

2% on all programming and monitoring, except I Sense 10%

Temperature Coefficient: (typical)

Standard: 100ppm/°C

Optional: 25ppm/°C (T Option)

Environmental:

Temperature Range:

Operating: -40°C to 65°C case temperature Storage: -55°C to 105°C, non operational

Humidity

10% to 90%, non-condensing.

Cooling:

Convection cooled, typical. 30 watt units operating at full power might require additional cooling to maintain case temperature below 65°C Methods may include: forced air cooling, use of heat sink or metal case, etc. It is the user's responsibility to maintain the case temperature below 65°C. Damage to the power supply due to inadequate cooling is considered misuse and repairs will not be covered under warranty.

Dimensions:

8kV-12kV

3.700"L X 1.500"W X 0.990"H (93.98mm X 38.10mm X 25.03mm)

15kV-20kV:

4.700"L X 1.500"W X 0.990"H (119.38mm X 38.10mm X 25.03mm)

25kV-40kV:

6.960"L X 1.600"W X 1.14"H (176.78mm X 40.84mm X 28.87mm)

Weight:

8kV-12kV: 5.7 ounces (162 grams), typical 15kV-20kV: 7.2 ounces (204 grams), typical 25kV-40kV: 13.1 ounces (371 grams), typical

Output Cable:

UM8, UM10, UM12, UM15: TV20 (min. length, 36" (914.4mm) UM20, UM25: TV30 (min. length, 36" (914.4mm) UM30, UM35, UM40: TV40 (min. length, 36" (914.4mm)

UM 4W, 8kV TO 40kV SELECTION TABLE

Model	Output V	Output Current	Ripple(max)	Output	Arc Limiting	I Sense Scaling	High Voltage
Number			%Vp-p	Capacitance	Resistance	Full Scale Signal	Divider Resistance
UM8*4	0 to 8kV	0.5mA	0.05	6830pF	50kΩ	5V	200ΜΩ
UM10*4	0 to 10kV	0.4mA	0.05	4380pF	50k Ω	2.4V	300ΜΩ
UM12*4	0 to 12kV	0.333mA	0.05	4380pF	50k Ω	3.33V	300ΜΩ
UM15*4	0 to 15kV	0.266mA	0.05	3220pF	100kΩ	1.69V	400ΜΩ
UM20*4	0 to 20kV	0.2mA	0.05	2310pF	100kΩ	1.316V	550M Ω
UM25*4	0 to 25kV	0.16mA	0.05	1540pF	100kΩ	1.1V	800ΜΩ
UM30*4	0 to 30kV	0.133mA	0.05	1370pF	120kΩ	0.95V	900ΜΩ
UM35*4	0 to 35kV	0.115mA	0.05	1370pF	140kΩ	0.72V	900ΜΩ
UM40*4	0 to 40kV	0.1mA	0.05	1370pF	140kΩ	1.3V	900ΜΩ

UM 15W, 8kV TO 40kV SELECTION TABLE

Output V	Output Current	Ripple(max)	Output	Arc Limiting	I Sense Scaling	High Voltage
		%Vp-p	Capacitance	Resistance	Full Scale Signal	Divider Resistance
0 to 8kV	1.875mA	0.05	6830pF	50kΩ	3.75V	200ΜΩ
0 to 10kV	1.5mA	0.05	4380pF	50k Ω	8.152V	300ΜΩ
0 to 12kV	1.25mA	0.05	4380pF	50kΩ	5V	300ΜΩ
0 to 15kV	1mA	0.05	3220pF	100kΩ	5.53V	400ΜΩ
0 to 20kV	0.75mA	0.05	2310pF	100kΩ	4.21V	550MΩ
0 to 25kV	0.6mA	0.05	1540pF	100kΩ	3.42V	0Μ008
0 to 30kV	0.5mA	0.05	1370pF	120kΩ	2.89V	900ΜΩ
0 to 35kV	0.429mA	0.05	1370pF	140kΩ	2.39V	900ΜΩ
0 to 40kV	0.375mA	0.05	1370pF	140kΩ	4.21V	900ΜΩ
	0 to 8kV 0 to 10kV 0 to 12kV 0 to 15kV 0 to 20kV 0 to 25kV 0 to 30kV 0 to 35kV	0 to 8kV 1.875mA 0 to 10kV 1.5mA 0 to 12kV 1.25mA 0 to 15kV 1mA 0 to 20kV 0.75mA 0 to 25kV 0.6mA 0 to 35kV 0.5mA 0 to 35kV 0.429mA	WVp-p 0 to 8kV 1.875mA 0.05 0 to 10kV 1.5mA 0.05 0 to 12kV 1.25mA 0.05 0 to 15kV 1mA 0.05 0 to 20kV 0.75mA 0.05 0 to 25kV 0.6mA 0.05 0 to 30kV 0.5mA 0.05 0 to 35kV 0.429mA 0.05	Wop-p Capacitance 0 to 8kV 1.875mA 0.05 6830pF 0 to 10kV 1.5mA 0.05 4380pF 0 to 12kV 1.25mA 0.05 4380pF 0 to 15kV 1mA 0.05 3220pF 0 to 20kV 0.75mA 0.05 2310pF 0 to 25kV 0.6mA 0.05 1540pF 0 to 30kV 0.5mA 0.05 1370pF 0 to 35kV 0.429mA 0.05 1370pF	%Vp-p Capacitance Resistance 0 to 8kV 1.875mA 0.05 6830pF $50k\Omega$ 0 to 10kV 1.5mA 0.05 4380pF $50k\Omega$ 0 to 12kV 1.25mA 0.05 4380pF $50k\Omega$ 0 to 15kV 1mA 0.05 3220pF $100k\Omega$ 0 to 20kV 0.75mA 0.05 2310pF $100k\Omega$ 0 to 25kV 0.6mA 0.05 1540pF $100k\Omega$ 0 to 30kV 0.5mA 0.05 1370pF $120k\Omega$ 0 to 35kV 0.429mA 0.05 1370pF $140k\Omega$	%VP-p Capacitance Resistance Full Scale Signal 0 to 8kV 1.875mA 0.05 6830pF 50kΩ 3.75V 0 to 10kV 1.5mA 0.05 4380pF 50kΩ 8.152V 0 to 12kV 1.25mA 0.05 4380pF 50kΩ 5V 0 to 15kV 1mA 0.05 3220pF 100kΩ 5.53V 0 to 20kV 0.75mA 0.05 2310pF 100kΩ 4.21V 0 to 25kV 0.6mA 0.05 1540pF 100kΩ 3.42V 0 to 30kV 0.5mA 0.05 1370pF 120kΩ 2.89V 0 to 35kV 0.429mA 0.05 1370pF 140kΩ 2.39V

UM 30W, 8kV TO 40kV SELECTION TABLE

Model Number	Output V	Output Current	Ripple(max) %Vp-p	Output Capacitance	Arc Limiting Resistance	I Sense Scaling Full Scale Signal	High Voltage Divider Resistance
UM8*30	0 to 8kV	3.75mA	0.05	6830pF	50k Ω	5.36V	200ΜΩ
UM10*30	0 to 10kV	3mA	0.05	4380pF	50k Ω	7.87V	300ΜΩ
UM12*30	0 to 12kV	2.5mA	0.05	4380pF	50k Ω	5V	300ΜΩ
UM15*30	0 to 15kV	2mA	0.06	3220pF	100kΩ	5.29V	400ΜΩ
UM20*30	0 to 20kV	1.5mA	0.06	2310pF	100kΩ	8.15V	550MΩ
UM25*30	0 to 25kV	1.2mA	0.06	1540pF	100kΩ	6.56V	0Μ008
UM30*30	0 to 30kV	1mA	0.06	1370pF	120kΩ	5.52V	900ΜΩ
UM35*30	0 to 35kV	0.857mA	0.05	1370pF	140kΩ	4.66V	900ΜΩ
UM40*30	0 to 40kV	0.75mA	0.05	1370pF	140kΩ	8.15V	900ΜΩ

Corporate Headquarters

Grayed text indicates Legacy interface signals.



PAGE 3 OF 6

STANDARD INTERFACE

PIN	SIGNAL	PARAMETERS
1	Power Ground Return	+12Vdc or +24Vdc power return/HV return
1A	Signature Resistor	Unique Identifying resistor connected to ground
2	+ Power Input	+12Vdc or +24Vdc power input
2A	OT Output	+5Vdc @ 1mA = Over Temp fault
3	I Sense	See I Sense text and tables for details
ЗА	I Mon	0 to 4.64Vdc = 0 to 100% rated output. Zout < $10k\Omega$
4	Enable Input	Low (<0.7V, lsink@1mA)=HV OFF,
		High (open or >2V)=HV ON
4A	V Mon	0 to 4.64Vdc = 0 to 100% rated output. Zout $<$ 10k Ω
5	Signal Ground	Signal Ground
5A	I Pgm	0 to 4.64Vdc = 0 to 100% rated output. Zin > $47k\Omega$
\perp		Leave open for preset current limit @103% of rated output current
6	Remote Adjust	Positive Polarity Unit:
1		0 to +4.64VDC = 0 to 100% rated voltage, 7in >1MO
1		Negative Polarity Unit:
		+5VDC to 0.36V = 0 to 100% rated voltage,
		Zin >100kΩ
		Leave open if pin 6A (VPgm) is used for programming
6A	V Pgm	0 to 4.64Vdc = 0 to 100% rated voltage. Zin > $100k\Omega$
		Leave open if pin 6 (remote adjust) is used for programming
7	+5V Reference Output	+5Vdc ±1%, 25ppm/°C. Zout =475Ω
8	HV Ground Return	HV Ground Return
9	E Out Monitor	1000:1 ratio. Polarity of Voltage Monitor signal equals
		polarity of unit. Accuracy is $\pm 2\%$, 100ppm/°C. Calibrated with DVM with 10M Ω input impedance

Grayed out signals are provided for backward legacy compatability and their use is not required.

Power Ground Return, Signal Ground and HV Ground Return are connected internally. For best performance they should not be connected externally.

LEGACY INTERFACE (L OPTION)

PIN	SIGNAL	PARAMETERS
1	Power Ground Return	+12Vdc or +24Vdc power return
2	+ Power Input	+12Vdc or +24Vdc power input
3	I Sense	See I Sense text and tables for details
4	Enable Input	Low (<0.7V, Isink@1mA)=HV OFF, High (open or >2V)=HV ON
5	Signal Ground	Signal Ground
6	Remote Adjust	Positive Polarity Unit: 0 to +4.64VDC = 0 to 100% rated voltage, Zin >1M Ω Negative Polarity Unit: +5VDC to 0.36V = 0 to 100% rated voltage, Zin >100k Ω
7	+5V Reference Output	+5Vdc ±1%, 25ppm/°C. Zout =475Ω
8	HV Ground Return	HV Ground Return
9	E Out Monitor	1000:1 ratio. Polarity of Voltage Monitor signal equals polarity of unit. Accuracy is $\pm 2\%$, 100ppm/°C. Calibrated with DVM with 10M Ω input impedance


Power Ground Return, Signal Ground and HV Ground Return are connected internally. For best performance they should not be connected externally.

Standard Interface Connections

Fifteen (15) gold plated 0.025" (0.64mm) square pins suitable for direct PCB mounting.

Legacy Interface Connections

Nine (9) gold plated 0.025" (0.64mm) square pins suitable for direct PCB mounting.



See mechanical drawing for location and spacing details

Programming and Monitor Signals

Voltage and current programming is done via positive polarity, high input impedance, 0 to 4.64Vdc signals. Voltage and current monitors are positive polarity, buffered low output impedance 0 to 4.64Vdc signals.

I Mon

The I Mon signal is a true output current monitoring signal. All internal offsets due to feedback divider currents have been compensated for.

Signature Resistor

A unique identifying signature resistor for each type of unit is connected from Pin 1A to ground. Details if desired are available upon request.

I Sense Signal

The polarity of the I Sense signal is opposite of the polarity of the output voltage of the unit that generated it. So a positive output polarity unit creates a negative polarity current monitor signal; while a negative output polarity unit creates a positive polarity current monitoring signal. This signal is clamped to ground internally via a bidirectional transient protection device and the signal is made available via a series connected $47 k\Omega$ isolation resistor. Internal HV dividers create a small, linear offset voltage on this current monitor signal that can be compensated for.

OT Output

The unit is protected by an internal thermostat that will shut the unit off if the case temperature exceeds 65°C. The OT Output signal will change states indicating an over temperature fault has occurred. In order to clear the OT signal and re-enable the unit, the temperature has to drop below 55 degrees C and input power needs to be recycled. For details on unit cooling requirements and the OT Output signal please see the operator's manual.

e-mail: sales@spellmanhv.com

PAGE 4 OF 6

UM8-40 OPTIONS

C Option

Fast Rise Time Applications-

If applications demand a power supply that is optimized for fast rise time requirements, then the C Option should be considered. If used for capacitor charging, a Spellman Capacitor Charging Questionnaire should be filled out to assure all aspects of the intended usage is understood assuring the appropriate unit is provided. Speak to a Spellman sales person for more details.

T Option

Low Temperature Coefficient-

The T Option offers the UM with an improved temperature coefficient. The standard voltage feedback divider is replaced with one having a superior temperature coefficient, resulting in a unit with 25ppm/C° (typical) temperature coefficient.

Maximum short circuit discharge rate:

> CV^2 $\frac{1}{2}$ (f) <1 watt

С = Output capacitance of unit

C ext = External capacitance ٧ = Maximum rated voltage

= Frequency of discharge

Τ = Nominal output current

= Rise time t_R

Typical Rise Time:

$$t_R = \frac{C + C \text{ ext}}{I} (V)$$

Minimum rise time is 10ms


PHYSICAL INTERFACING

B Option

Terminal Block-

The B Option provides terminal block connections for both the customer interface and high voltage output/return. This feature can be helpful in situations where frequent wiring changes are anticipated,






SHIELDING OPTIONS

S Option

RF Tight Shielded Can-

The S Option mounts the UM module inside of a flanged RF tight aluminum can.





Corporate Headquarters

PAGE 5 OF 6

SHIELDING OPTIONS (CONT)

M Option

Mu Metal Shield-

UM modules can be fitted with an adhesive backed Mu Metal foil shield to help protect sensitive adjacent circuitry.



- 1.20 (30.45)-

Same as standard unit. See page 6 of 6 for dimensional drawings


CHASSIS MOUNTING OPTION

E Option

Eared Mounting Plate-

An eared mounting plate is affixed to the top surface of the UM module allowing simple chassis mounting of unit.






ORDERING INFORMATION

Voltage	oltage 0 to 8kV 8	
l	0 to 10kV	10
	0 to 12kV	12
	0 to 15kV	15
	0 to 20kV	20
	0 to 25kV	25
	0 to 30kV	30
	0 to 35kV	35
	0 to 40kV	40
Polarity	Positive	Р
	Negative	N
Power	Watts Output	4
	Watts Output	15
	Watts Output	30


STANDARD UNIT ORDERING EXAMPLE



OPTION ORDERING INFORMATION

OPTION	OPTION CODE
Legacy Interface	L
Fast Rise Time	С
Low Temperature Coefficient	T
Mu Metal Shield	M
RF Tight Shielded Can	S
Eared Mounting Plate	E
Terminal Block	В


OPTION ORDERING EXAMPLE




PAGE 6 OF 6

DIMENSIONS: in.[mm]

15 PIN - Standard Interface



9 PIN - Legacy Interface





Corporate Headquarters







Copyright © 2010 Spellman High Voltage Electronics Corp.





- Differential Input for Voltage Program
- Optional RS-232/RS-485 Control
- 10 Watts Output Power
- **Voltage and Current Monitors and Controls**
- High Stability
- **Ultra Low Ripple and Noise**
- CE Marked and UL61010-1 Certified

Spellman's new MPS series are a family of high voltage 10 Watt modules that provide output voltages ranging from 1kV to 30kV.

The MPS series are high performance products designed with Spellman's hybrid topology of linear and switch mode power conversion techniques delivering lower noise with higher efficiency. The MPS series produces excellent ripple and stability performance specifications from a compact footprint. Additionally the MPS series features, as standard, a differential amplifier input for the voltage programming signal to improve immunity from external system noise and addressing any offset issues. Alternatively the output voltage may be pre-set by an internal potentiometer.

RS-232 or RS-485 digital interfaces are also available as optional; both the standard analog and the optional digital controls are provided via a 15-pin D-type connector.

Spellman's proprietary HV technology coupled with SMT circuitry results in an ultra compact and lightweight module that is available as either a positive or negative supply that is ideal for OEM applications.

TYPICAL APPLICATIONS

Photomultiplier Tubes Electrostatic Printing Electron and Ion Beams Scintillators

Electronmultiplier Detectors Mass Spectrometry Microchannel Plate Detectors Electrostatic Lenses

Nuclear Instruments

OPTIONS

VCC Variable Current Control

HS High Stability DCC 2 RS-232 DCC 4 RS-485

Note: It is not possible to supply the unit with

both HS and DCC options

SPECIFICATIONS

Input Voltage:

+24 Vdc, ±2Vdc

Input Current:

≤1 amp maximum

Output Voltage:

9 models available from 1kV to 30kV

Output Polarity:

Positive or negative, specify at time of order

Power:

10 watts, maximum

Voltage Regulation:

Line: ≤0.001% of rated output voltage over specified

input voltage

Load: ≤0.001% of rated output voltage for full load change

Current Regulation (VCC Option):

Line: ≤0.01% for 1V input voltage change under

any load conditions

Load: ≤0.01% for full load to short circuit

Ripple:

See "model selection" table

Stability:

≤0.007% per hour, 0.02% per 8 hours after 1.0 hour warm up period. ≤0.05% per 1000 hours after 1.0 hour warm up period (HS option)

Temperature Coefficient:

≤25ppm per degree C

≤10ppm per degree C (HS option)

Environmental:

Temperature Range:

Operating: 0°C to 50°C Storage: -35°C to 85°C

Humidity:

20% to 85% RH, non-condensing

Cooling:

Convection cooled

Interface Connector:

15 pin male D connector

Output Connector:

A captive 39.4" (1 meter) long shielded HV cable is provided



PAGE 2 OF 3

Dimensions:

1-10kV: 1.18"H X 2.75"W X 5.12"D

(30mm x 70mm x 130mm)

15-20kV: 1.18" H X 2.75" W X 6.49" D (30mm x 70mm x 165mm)

30kV: 1.37" H X 2.95" W X 8.47" D (65mm x 75mm x 215mm)

Weight:

1-3kV: 9.88 oz. (280g) 5-10kV: 14.82 oz. (420g) 15-20kV: 22.92 oz. (650g) 30kV: 35.51 oz. (950g)

Regulatory Approvals:

UL recognized component (RC), File E354595. Compliant to IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. UKAS marked to BS EN 61010-1. RoHS compliant.

As the unit is designed for incorporation within the users system it is not tested against any specific EMC standards. The user will need to take sensible EMC precautions when designing the unit in and verify the overall system EMC performance against any relevant standards.

MPS ANALOG INTERFACE— 15 PIN D CONNECTOR (NON-DCC UNITS)

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power/Signal Ground	Ground (also used as analog signal ground on 1kV to 10kV units)
2	+24Vdc Input	+24Vdc @ 1 amp maximum
3	Voltage Monitor Output	0 to 10Vdc=0 to 100% Rated Output ±2%, Zout =10kΩ
4	Local Programming Potentiometer Wiper Output	Potentiometer connected to +10Vdc (accuracy: 0.2%) and Ground, 0 to 10Vdc adjustable wiper output provided
5	Voltage Program Input	0 to 10Vdc=0 to 100% Rated Output $\pm 2\%$, Zin=10M Ω
6	Voltage Program Differential Amplifier Output	0 to 10Vdc=0 to 100% Rated Output, Zout =10kΩ
7	Voltage Program Differential Amplifier Input—Positive	0 to 10Vdc differential between pin 7 and pin 9 = 0 to 100% of rated output, diode clamped to ground, Zin =38kΩ
8	Current Monitor Output	0 to 10Vdc = 0 to 100% Rated Output $\pm 2\%$, Zout =10k Ω
9	Voltage Program Differential Amplifier Input—Negative	0 to 10Vdc differential between pin 7 and pin 9 = 0 to 100% of Rated Output, diode clamped to ground, Zin =38kΩ
10	No Connection	No Connection
11	Current Program Input	Standard: Internally connected to provide 110% fixed current limit VCC Option: 0 to 10Vdc=0 to 100% Rated Output ±2%, Zin=1MΩ
12	Enable Input	Low = Enable, TTL, CMOS, Open Collector Compliant
13	Internal Connection	No Connection
14	Vref (/HS unit only)	+10V ultra high stability reference output. Accuracy: 0.05%, temperature coeff. <5ppm/°C On standard units the reference voltage is available on pin 4
15	Analog Signal Ground (15kV to 20kV units)	Analog Signal Ground (No connection for (1kV to 10kV units)

MPS DIGITAL INTERFACE— 15 PIN D CONNECTOR (DCC UNITS)

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power/Signal Ground	Ground
2	+24Vdc Input	+24Vdc @ 1 amp maximum
3	No Connection	No Connection
4	Local Programming Potentiometer Wiper Output	Potentiometer connected to +10Vdc and Ground, 0 to 10Vdc adjustable wiper output provided
5	No Connection	No Connection
6	No Connection	No Connection
7	No Connection	No Connection
8	No Connection	No Connection
9	No Connection	No Connection
10	No Connection	No Connection
11	No Connection	No Connection
12	Enable Input	Low = Enable, TTL, CMOS, open collector compliant
13	No Connection	No Connection
14	TxD	Transmit data (output) with respect to ground (pin 1)
15	RxD	Receive data (input) with respect to ground (pin 1)

Notes: 1.) The DCC option operated via a simple ASCII protocol. Contact us for more information.

2.) The HS and DCC option cannot be offered together

MPS SELECTION TABLE

	Model	Output Voltage	Output Current	Ripple (Vpp)
	MPS1*10/24	1kV	10mA	<10mV
	MPS2*10/24	2kV	5.00 mA	<20mV
	MPS2.5*10/24	2.5kV	4.00 mA	<25mV
	MPS3*10/24	3kV	3.3mA	<25mV
	MPS5*10/24	5kV	2mA	<30mV
I	MPS10*10/24	10kV	1mA	<50mV
ĺ	MPS15*10/24	15kV	0.66mA	<100mV
Ì	MPS20*10/24	20kV	0.5mA	<150mV
	MPS30*10/24	30kV	0.33mA	<250mV

*Specify "P" for positive polarity or "N" for negative polarity. Custom units available.

How To Order:

MPSXX*10/24/YYY

where

XX is the Output voltage (see selection table)

* is the polarity: P for positive / N for negative YYY is the option: VCC / HS / DCC2 / DCC4

e-mail: sales@spellmanhv.com


1.37 [35]



T-20kV FRONT VIEW To a serious property of the seriou

BOTTOM VIEW

2.75 [70]




SIDE VIEW



BOTTOM VIEW

2.95 [75]



SIDE VIEW





Hauppauge, New York USA

e-mail: sales@spellmanhv.com

+1-631-630-3000 FAX: +1-631-435-1620

Corporate Headquarters









Spellman's MPD series is a family of high voltage, high performance 10 Watt modules with output voltages ranging from 1kV to 30kV.

Spellman's hybrid topology of linear and switch mode power conversion techniques delivers ultra-low noise, excellent ripple and stability performance all within its compact footprint.

The MPD series can be controlled via analog or digital interfaces, both provided via a standard 15-pin D-type connector.

In analog mode, the unit features a differential amplifier input for the voltage programming signal to improve immunity from external system noise and address any offset issues. In digital mode, RS-232 and RS-485 interfaces provide additional features: current control, status flags, multiple units operation (RS-485 only), and wobbler function.

Spellman's proprietary HV technology coupled with SMT circuitry results in an ultra-compact and lightweight module, available as either a positive or negative supply, that is ideal for OEM applications.

TYPICAL APPLICATIONS

Mass Spectrometry Electrostatic Printing Scintillators Electrostatic Lenses Automatic test equipment **Electron Multipliers** Capillary Electrophoresis Electrospinning Electron and Ion Beams Electrostatic Chucks Microchannel Plate Detectors Photomultiplier Tubes

SPECIFICATIONS

Input Voltage:

+24 Vdc, ±2Vdc

Input Current:

≤1 amp maximum

Output Voltage:

7 models available from 1kV to 30kV

Output Polarity:

Positive or negative, specify at time of order

Power:

10 watts, maximum

Extremely Compact 10W High Performance Module

- Multiple Control Interfaces: Differential Analog, RS-232 and RS-485
- **Voltage and Current Monitors**
- High Stability, Low TC
- Ultra Low Ripple and Noise, Down to 1/f Band
- Free GUI for Testing and Development Work
- Digital Control Features: Multiple Units Operation. **Current Control, Status Flags and Wobbler Function**

Voltage Regulation:

Line: For a 1V line change 10ppm Load: 0-100% load 10ppm

Current Limit:

110% of rated output current. In digital control mode, the current limit is settable from 0 to 110% of the rated output current.

Ripple:

See "drift, ripple and noise" table

Stability:

After one hour warm up period. 10ppm/hour 25ppm/8 hours 100ppm/1000 hours

Temperature Coefficient:

10ppm per degree C

Protection:

Arc and short circuit protected.

Not designed to withstand continuous arcing. The unit monitors and reports faults through status flags (digital com). When a trip occurs, the output is disabled and the unit can be reset through enable, fault reset or power cycle.

Control Software:

A free GUI can be provided for customer testing and development work.

Main Features:

- -Voltage control and enable inputs
- -Voltage and current monitor outputs
- -10V voltage reference output

Digital Features:

The following features are available when operating in digital control mode.

-Multiple units operation (RS-485 only)

-Current control

-Wobbler function: sine wave superimposed to voltage output (programmable amplitude 0-300V, period 0.1 to 2s)

Environmental:

Temperature Range: Operating: 0°C to 50°C Storage: -35°C to 85°C Humidity:

20% to 85% RH, non-condensing

Cooling:

Convection cooled



25

PAGE 2 OF 3

Dimensions:

1kV-10kV:

1.18" H X 2.75" W X 5.12" D (30mm x 70mm x 130mm) 15kV-20kV:

1.18``H X 2.75``W X 6.50``D (30mm x 70mm x 165mm) 30kV-20kV:

1.38" H X 2.95" W X 8.46" D (35mm x 75mm x 215mm)

Weight:

1kV-10kV: 14.82 oz. (420g) 15kV-20kV: 22.93 oz. (650g) 30kV: 33.51 oz. (950g)

Interface Connector:

15 pin male D connector

Output Connector:

Captive 39.4" (1 meter) long un-terminated and

shielded HV cable:

1kV to 20kV units: HRG58 30kV units: LEMO 130666

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. UK Conformity Assessed. UL/CUL recognized, File E354595. RoHS

Compliant.

Note: for 1kV and 30kV units approvals, please inquire.

MPD SELECTION TABLE

Model	Output Voltage	Output Current
MPD1*10/24	1kV	10mA
MPD2.5*10/24	2.5kV	4.00mA
MPD5*10/24	5kV	2mA
MPD10*10/24	10kV	1mA
MPD15*10/24	15kV	0.66mA
MPD20*10/24	20kV	0.5mA
MPD30*10/24	30kV	0.33mA

^{*}Specify "P" for positive polarity or "N" for negative polarity. Custom units available.

MPD DRIFT, RIPPLE and NOISE

Model	3mHz-30mHz	30mHz-3Hz	3Hz-30Hz	30Hz-300Hz	300Hz-30kHz	30kHz-3MHz
MPD1	7mV	7mV	7mV	4mV	4mV	4mV
MPD2.5	10mV	10mV	10mV	5mV	5mV	5mV
MPD5	10mV	10mV	10mV	10mV	10mV	10mV
MPD10	20mV	20mV	20mV	20mV	20mV	20mV
MPD15	30mV	30mV	30mV	30mV	30mV	30mV
MPD20	40mV	40mV	40mV	40mV	40mV	40mV
MPD30	60mV	60mV	60mV	60mV	60mV	60mV


MPD EXTERNAL INTERFACE— 15 PIN MALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power Ground	Ground
2	+24Vdc Input	+24Vdc @ 1 amp maximum
3	Voltage Monitor Output	Voltage monitor 0 to 10Vdc for 0 to full scale output $\pm 1\%$ (wrt signal ground) Zout=10k $\!\Omega$
4	Voltage Reference Output	10Vdc @ 10mA maximum
5	Voltage Program Input	0 to 10Vdc=0 to 100% rated output ±1%, Zin=10MΩ
6	Voltage Program Differential Amplifier Output	0 to 10Vdc=0 to 100% rated output, Zout =10kΩ
7	Voltage Program Differential Amplifier Input—Positive	0 to 10Vdc differential between pin 7 and pin 9 = 0 to 100% of rated output, diode clamped to ground, Zin =38k Ω
8	Current Monitor Output	Voltage monitor 0 to 10Vdc for 0 to full scale output $\pm 1\%$ (wrt signal ground) Zout=10k Ω
9	Voltage Program Differential Amplifier Input—Negative	0 to 10Vdc differential between pin 7 and pin 9 = 0 to 100% of rated output, diode clamped to ground, Zin =38k Ω
10	Voltage Program Digital Output	0 to 10Vdc = 0 to 100% rated output, Zout = $10k\Omega$
11	Signal Ground	Signal ground for control and monitoring
12	Enable Input	Low = Enable, TTL, CMOS, open collector compliant
13	Digital Mode	RS-232 or RS-485 configuration Low = RS-485, Open circuit = RS-232
14	RS-232 TxD/RS-485 (-)	Transmit data (output) wrt pin 1 or RS-485 inverting
15	RS-232 RxD/RS-485 (+)	Receive data (input) wrt pin 1 or RS-485 non inverting

Digital Control – Connect pin 5 to pin 10 Analog Control – Connect pin 5 to pin 6



DIMENSIONS: in.[mm]













PAGE 1 OF 2



Spellman's new MPS20W series are a family of high voltage 20 Watt modules that provide output voltages ranging from 1kV to 20kV.

The MPS20W series are high performance products designed with Spellman's hybrid topology of linear and switch mode power conversion techniques delivering lower noise with higher efficiency. The MPS20W series produces excellent ripple and stability performance specifications from a compact footprint. Additionally the MPS20W series features, as standard, a differential amplifier input for the voltage programming signal to improve immunity from external system noise and addressing any offset issues. Alternatively the output voltage may be pre-set by an internal potentiometer. A fully featured remote user interface is provided via 15-pin D-type connector as standard. The output voltage is arc and short circuit protected and the power input has a current limiter fitted.

Spellman's proprietary HV technology coupled with SMT circuitry results in an ultra compact and lightweight module that is available as either a positive or negative supply that is ideal for OEM applications.

TYPICAL APPLICATIONS

Photomultiplier Tubes Microchannel Plate Detectors Scintillators Mass Spectrometry Electron and Ion Beams Electrostatic Lenses Nuclear Instruments **Electrostatic Printing**

OPTIONS

VCC Variable Current Control

SPECIFICATIONS

Input Voltage:

+24 Vdc, ±2Vdc

Input Current:

≤1.5 amps

Output Voltage:

7 models available from 1kV to 20kV

Output Polarity:

Positive or negative, specify at time of order

Differential Input for Voltage Program

- 20 Watts Output Power
- **Voltage and Current Controls**
- **Voltage and Current Monitors**
- High Stability
- **Ultra Low Ripple and Noise**
- High Voltage Enable Control

Power:

≤20 watts

Voltage Regulation:

Line: ≤0.001% of rated output voltage over specified

input voltage

Load: ≤0.001% of rated output voltage for full load change

Current Regulation (Vcc Option):

Line: ≤0.01% for 1V input voltage change under

any load conditions

Load: ≤0.001% for 0 to full load

Ripple:

See "model selection" table

Stability:

≤0.01% per hour, 0.02% per 8 hours after 1.0 hour warm up period.

Temperature Coefficient:

≤25ppm per degree C

Environmental:

Temperature Range:

Operating: 0°C to 50°C Storage: -35°C to 85°C

Humidity:

20% to 85% RH, non-condensing

Cooling:

Convection cooled

Dimensions:

1-10kV 1.31" H x 3.74" W x 5.91" D (33.5mm x 95mm x 150mm) 15-20kV 1.31" H x 3.74" W x 7.28" D (33.5mm x 95mm x 185mm)

Weight:

1-2kV: 15.17 oz. (430g) 3-10kV: 25.76 oz. (730g) 15-20kV:35.30 oz. (1000g)

Interface Connector:

15 pin male D connector

Output Connector:

A captive 39.4" (1 meter) long shielded HV cable is provided

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588. RoHS compliant.



e-mail: sales@spellmanhv.com

PAGE 2 OF 2

MPS20W SELECTION TABLE

Model	Output Voltage	Output Current	Ripple (Vpp)
MPS1*20/24	0-1kV	20mA	<25mV
MPS2*20/24	0-2kV	10 mA	<50mV
MPS3*20/24	0-3kV	6.67mA	<75mV
MPS5*20/24	0-5kV	4mA	<125mV
MPS10*20/24	0-10kV	2mA	<250mV
MPS15*20/24	0-15kV	1.33mA	<375mV
MPS20*20/24	0-20kV	1mA	<500mV

*Specify "P" for positive polarity or "N" for negative polarity. Custom units available.

MPS20W ANALOG INTERFACE— 15 PIN D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power/Signal Ground	Ground
2	+24Vdc Input	+24Vdc @ 1.5 amp maximum
3	Voltage Monitor Output	0 to 10Vdc=0 to 100% Rated Output, Zout =2.2k Ω
4	Local Programming Potentiometer Wiper Output	Potentiometer connected to +10Vdc and Ground, 0 to 10Vdc adjustable wiper output provided
5	Voltage Program Input	0 to 10Vdc=0 to 100% Rated Output, Zin=10MΩ
6	Voltage Program Differential Amplifier Output	0 to 10Vdc=0 to 100% Rated Output, Zout =2.2k Ω
7	Voltage Program Differential Amplifier Input—Positive	0 to 10Vdc differential between pin 7 and pin 9 = 0 to 100% of rated output, diode clamped to ground, Zin =38k Ω
8	Current Monitor Output	0 to 10Vdc = 0 to 100% Rated Output, Zout =2.2k Ω
9	Voltage Program Differential Amplifier Input—Negative	0 to 10Vdc differential between pin 7 and pin 9 = 0 to 100% of Rated Output, diode clamped to ground, Zin =38k Ω
10	No Connection	No Connection
11	Current Program Input	Standard: Internally connected to provide 110% fixed current limit VCC Option: 0 to 10Vdc=0 to 100% Rated Output, Zin=1MΩ
12	Enable Input	Low = Enable, TTL, CMOS, Open Collector Compliant
13	Internal Connection	No Connection
14	No Connection	No Connection
15	Analog Signal Ground	Analog Signal Ground

DIMENSIONS: in.[mm]

FRONT VIEW


1-10kV Unit



SIDE VIEW



BOTTOM VIEW



FRONT VIEW


15-20kV Unit



SIDE VIEW



BOTTOM VIEW





Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

+1-631-630-3000 FAX: +1-631-435-1620





Spellman's SMS Series of 60 watt high voltage power supplies are based on a proprietary resonant fly back power conversion topology that provides over 80% efficiency. These fixed polarity modules (specify positive or negative at time of order) feature both voltage and current regulation with automatic crossover, making them ideal for sensitive load applications. The robust design of SMS Series along with comprehensive arc and short circuit protection allow operation in the most demanding environments.

TYPICAL APPLICATIONS

Electrospinning Hipot Testing Detector Arrays Electrophoresis Cable Testing

- Output Voltages from 1kV to 60kV
- Arc and Short Circuit Protected
- Low Stored Energy
- Test Points for Output Current and Voltage
- Enable/Inhibit Control of Output
- OEM Customization Available

SPECIFICATIONS

Input:

+24Vdc ±10% @ 4.0A

Output:

10 models from 1kV to 60kV. Positive or negative polarity outputs.

Efficiency:

80 to 85%, typical

Voltage Regulation:

Load: 0.01% of output voltage no load to full load. Line: ±0.01% for ±10% change in input voltage.

Current Regulation:

Load: 0.1% of output current from 0 to rated voltage. Line: 0.05% of rated current over specified input range.

Stability:

0.02% per 8 hours.

Temperature Coefficient:

0.01% per °C, voltage or current regulated.

Ripple

0.1% p-p of maximum output voltage.

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -40°C to 85°C
Humidity:

0 to 90%, non-condensing

Dimensions:

3"H x 5"W x 9"D (7.6cm x 12.7cm x 23.0cm).

Weight:

Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

+1-631-630-3000 FAX: +1-631-435-1620

5.25 pounds (2.38kg)

Input Connector:

12 pin AMP Metri-Mate (mating connecter and pins provided)

Output Cable:

18"±1" (45.7cm) of UL® approved high voltage wire

Front Panel Ground Connection:

Threaded 8-32 ground stud, nut provided

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.





DIMENSIONS: in.[mm]

SIDE VIEW

SMS SELECTION TABLE

Maximum Rating		Model Number
kV	mA	
1	60	SMS 1*60
3	20	SMS 3*60
5	12	SMS 5*60
10	6	SMS 10*60
15	4	SMS 15*60
20	3	SMS 20*60
30	2	SMS 30*60
40	1.5	SMS 40*60
50	1.2	SMS 50*60
60	1.0	SMS 60*60

^{*}Specify "P" for positive polarity or "N" for negative polarity.

CONNECTOR 12 PIN

PIN	SIGNAL	PARAMETERS
1	Power Ground	+24Vdc Return
2	+24Vdc Input	+24Vdc @ 3.5 amps, maximum
3	High Voltage Enable/Inhibit	Open = HV OFF, Ground = HV ON
4	Voltage Test Point	0 to 10Vdc = 0 to 100% of rated output
5	Current Test Point	0 to 10Vdc = 0 to 100% of rated output
6	Voltage Programming	0 to 10Vdc = 0 to 100% of rated output
7	Current Programming	0 to 10Vdc = 0 to 100% of rated output
8	+10Vdc Reference	+10Vdc @ 1mA maximum
9	Signal Ground	Signal Ground
10	Spare	No Connection
11	Spare	No Connection
12	Spare	No Connection


3.00 [76.20] 0.95 ± .06 [24.13]

TOP VIEW

9.00 ± .04 [228.60]



BACK VIEW







PAGE 1 OF 4



- 5 Voltage Ranges from 8kV to 20kV. Fixed Negative or Positive Polarity
- Available Output Power Increments of **60 and 125 Watts**
- Voltage/Current Regulation with Automatic Crossover Control
- Voltage and Current Monitor Signals
- Fully Arc and Short Circuit Protected
- UL Recognized
- CE Listed and RoHS Compliant

Form, Fit and Function Usability:

Spellman's UMW Series of high voltage modules provides users with a form, fit and function replacement for presently available commercially made units, while providing superior features and benefits at competitive pricing. Utilizing proprietary power conversion technology, unique high voltage packaging, and Spellman's unmatched encapsulation techniques, these SMT based high voltage modules provide improved performance and easier system integration at a lower cost when compared to the competition.

Advanced Power Conversion Topology:

UMW converters use a proprietary resonant power conversion topology providing exceptional efficiency and inherent low noise and ripple outputs. Radiated emissions are dramatically reduced compared to conventional switching topologies, effectively minimizing or even eliminating the need to shield the unit from adjacent circuitry.

The high voltage output is generated through the use of a ferrite core high voltage step up transformer which feeds the high voltage output circuitry. Units utilize an appropriate arrangement of low capacitance Cockcroft-Walton voltage multiplier stages to obtain the specified high voltage output.

Due to the fixed, high frequency conversion rate of the converter, the output capacitance is small resulting in minimal stored energy and fast rise times. Through the use of generously rated surge limiting resistors and a fast acting current loop, all units are fully arc and short circuit protected.

Control and Regulation:

The actual output voltage generated is sampled via a high impedance divider to create a voltage feedback signal. A current feedback signal is created via a current sense resistor being placed in the low end return of the high voltage output circuitry. These two accurate ground referenced feedback signals are used to precisely regulate and control the units output. These accurate and calibrated signals are also used for external monitoring purposes.

Due to the UMW's unique converter topology it can provide full current into low impedance loads or even a short circuit. Standard units limit at 103% of maximum rated output current.

Standard User Interface:

The Spellman UMW Series offers a standard customer interface that provides current programming capability and positive polarity, buffered, low output impedance voltage and current monitor signals (0 to +4.64Vdc equals 0 to full scale rated). A voltage programming input is provided where 0 to +4.64Vdc equals 0 to 100% of rated voltage.

Current programmability allows the user to set where the unit will current limit, anywhere from 0 to 100% of maximum rated current. This feature is beneficial where less than full output current is desired, like in the case of protecting a sensitive load.

The buffered low impedance voltage and current monitor signals can drive external circuitry directly, while minimizing loading and pickup effects. These feature save the user the expense and implementation of external interface buffering circuitry while improving overall signal integrity.

Mechanical and Environmental Considerations:

The UMW Series are modular sheet metal enclosed converters measuring 8.00" X 4.50" X 1.075" (203mm X 114mm X 27mm). All units are encapsulated using a propriety silicon based potting material which is considerably lighter in weight than epoxy encapsulation techniques. Physical mounting of the unit is accomplished via the use of bottom mounted studs or threaded blind inserts, dependent upon model ordered.



Corporate Headquarters

FAX: +1-631-435-1620



SPECIFICATIONS

Input Voltage:

24Vdc

Normal Voltage Range:

23Vdc to 30Vdc

Derated Voltage Range:

11Vdc to 30Vdc

Input Current: (typical)

Disabled: <40mA No load: <600mA

Full load:

60 watt units: 3 amps 125 watt units: 6.2 amps

Voltage Regulation:

Line: <0.01% Load: <0.01%

Current Regulation: Line: <0.01%

Load: <0.01%

Stability:

0.01% per 8 hours, 0.02% per day

after 30 min. warmup

Accuracy:

2% on all programming and monitoring, except I Sense 10%

Temperature Coefficient: (typical)

100ppm/°C

Overshoot:

<0.1% Vp

Environmental:

Temperature Range:

Operating: 0°C to 65°C case temperature storage: -55°C to 85°C, non operational

Humidity:

10% to 90%, non-condensing

Dimensions:

8.00" L X 4.50" W X 1.075" H (203mm X 114mm X 27mm)

Weight:

1.75 lbs. (0.79kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File

E227588. RoHS Compliant.

UMW 60W SELECTION TABLE

Model Number	Output V	Output Current	Ripple(max) %Vp-p	Output Capacitance	Arc Limiting Resistance	I Sense Scaling Full Scale Signal
UMW8*60	0 to 8kV	7.5mA	<1.0 (C load ≥0.05µF)	3553pF	14.1kΩ	1.6V
UMW10*60	0 to 10kV	6mA	<1.0 (C load ≥0.05µF)	3553pF	14.1kΩ	1.47V
UMW12*60	0 to 12kV	5mA	<1.0 (C load ≥0.05µF)	2870pF	30kΩ	1.24V
UMW15*60	0 to 15kV	4mA	<1.0 (C load ≥0.05µF)	2460pF	30kΩ	1.0V
UMW20*60	0 to 20kV	3mA	<1.0 (C load ≥0.01µF)	2460pF	45kΩ	4.61V

UMW 125W SELECTION TABLE

Model Number	Output V	Output Current	Ripple(max) %Vp-p	Output Capacitance	Arc Limiting Resistance	I Sense Scaling Full Scale Signal
UMW8*125	0 to 8kV	15.5mA	<1.0 (C load ≥0.05µF)	7106pF	3kΩ	1.1V
UMW10*125	0 to 10kV	12.5mA	<1.0 (C load ≥0.05µF)	7106pF	3kΩ	1.15V
UMW12*125	0 to 12kV	10.5mA	<1.0 (C load ≥0.05µF)	5740pF	6.6kΩ	1.40V
UMW15*125	0 to 15kV	8.3mA	<1.0 (C load ≥0.05µF)	4920pF	6.6kΩ	1.1V
UMW20*125	0 to 20kV	6.25mA	<1.0 (C load ≥0.01µF)	4920pF	14.1kΩ	9.57V

Corporate Headquarters

Hauppauge, New York USA


Grayed text indicates Legacy interface signals.

ORDERING INFORMATION

Voltage	0 to 8kV	8
	0 to 10kV	10
	0 to 12kV	12
	0 to 15kV	15
	0 to 20kV	20
Polarity	Positive	Р
	Negative	Ν
Power	60Watts	60
	125Watts	125
Legacy Interface	Legacy Interface	L

If a high voltage mating connector is required it should be included at time of order. See page 3 for details

ORDERING EXAMPLE







STANDARD INTERFACE

PIN	SIGNAL	PARAMETERS
1	Power Ground Return	+24Vdc power ground return
2	+ Power Input	+24Vdc power input
3	I Sense	See I Sense text and tables for details
4	Enable Input	Low (<0.7V, Isink@1mA)=HV OFF, High (open or >2V)=HV ON
5	Signal Ground	Signal Ground
6	Remote V Adjust	0 to +4.64Vdc = 0 to 100%, Zin >1M Ω
7	+5V Reference Output	$+5$ Vdc ± 2 %. Zout = 475Ω
8	Power Ground Return	+24Vdc Power Ground Return
9	+ Power Input	+24Vdc Power Input
10	Signature Resistor	Unique identifying resistor connected to ground
11	Remote I Adjust	0 to +4.64Vdc = 0 to 100%, Zin >1MΩ Leave open for preset current limit @103% of rated output current
12	I Monitor	0 to +5Vdc = 0 to 107.5%, Zout <10kΩ
13	V Monitor	0 to +5Vdc = 0 to 107.5%, Zout <10kΩ
14	E Out Monitor	1.00 Volt, $1G\Omega/1.1M\Omega$ divider with $10M\Omega$ meter

Interface Connections

Fourteen (14) gold plated 0.025" (0.63mm) square pins that will mate with AMP Mod-U connectors. See mechanical drawing for location and spacing details.

Programming and Monitor Signals

Voltage and current programming is done via positive polarity, high input impedance, 0 to 4.64Vdc signals. Voltage and current monitors are positive polarity, buffered low output impedance 0 to 4.64Vdc signals.

Signature Resistor

A unique identifying signature resistor for each type of unit is connected from Pin 10 to Ground. Details if desired are available upon request.

LEGACY INTERFACE (L OPTION)

PIN	SIGNAL	PARAMETERS
1	Power Ground Return	+24Vdc power ground return
2	+ Power Input	+24Vdc power input
3	I Sense	See I Sense text and tables for details
4	Enable Input	Low (<0.7V, Isink@1mA)=HV OFF, High (open or >2V)=HV ON
5	Signal Ground	Signal Ground
6	Remote Adjust	Positive Polarity Unit: 0 to $+4.64$ Vdc = 0 to 100% rated voltage Zin>1M Ω Negative Polarity Unit: $+5$ Vdc to 0.36 Vdc = 0 to 100% rated voltage Zin>1M Ω
7	+5V Reference Output	$+5$ Vdc ± 2 %. Zout = 475Ω
8	Power Ground Return	+24Vdc Power Ground Return
9	+ Power Input	+24Vdc Power Input
10	Signature Resistor	Unique identifying resistor connected to ground
11	N/C	
12	N/C	
13	N/C	
14	E Out Monitor	1.00 volt/kV, $1G\Omega/1.1M\Omega$ divider with $10M\Omega$ meter

I Sense Signal

The polarity of the current monitor signal is opposite of the polarity of the output voltage of the unit that generated it. So a positive output polarity unit creates a negative polarity current monitor signal; while a negative output polarity unit creates a positive polarity current monitoring signal. This signal is clamped to ground internally via a bidirectional 18 volt transient protection device and the signal is made available via a series connected $47 k\Omega$ isolation resistor. Internal HV dividers create a small, linear offset voltage on this current monitor signal that can be compenstated for.

HIGH VOLTAGE MATING CONNECTOR

K۷	CONNECTOR	
8	LGH1 SHV P.N. 304781-001	
10		
12		
15		
20	LGH1L SHV P.N. 304781-101	

Low Voltage Interface Connector

A mating AMP Mod-U interface connector will be provided.

High Voltage Output Mating Connector

An appropriate mating LGH high voltage connector (36" long) will be required. Please see table to left for specific part number.

High Voltage Return


Two gold plated 0.025" (0.63mm) square pins (15 and 16) are provided. These are connected to Power Ground Return.




e-mail: sales@spellmanhv.com





DIMENSIONS: in.[mm]








BOTTOM VIEW .75 (19.05) 3.00 (76.20) .750 (19.05) 6.50 (165.1)

















PAGE 1 OF 4



Spellman's SLM Series of high voltage modules are designed for OEM applications up to 160kV at 1200 watts. Its universal input, small package size and choice of three standard digital interfaces simplifies integrating the SLM into your system design. Models are available in either positive or negative polarity. The SLM is fully arc and short protected. Excellent regulation specifications are provided along with outstanding stability performance.

TYPICAL APPLICATIONS

Capacitor Charging Electrostatics
HiPot Testing E Beam Systems
CRT Testing CW Lasers

FIRMWARE CONFIGURATIONS

STANDARD BASED FEATURES

AOL Adjustable Overload Trip

AT Arc Trip
NAD No Arc Detect
NSS No Slow Start

PSS Programmable Slow Start
 RFR Remote Fault Reset
 RMI Remote Mode Indicators
 ROV Remote Overvoltage Adjust

SPECIFICATIONS

Input Voltage:

Power factor corrected input, ≥0.98 100-240Vac, ±10% (90-264Vac):

47-63Hz @ 4.0A for 300 watt units

200-240Vac, ±10% (180-264Vac):

47-63Hz @ 4.0A for 600 watt units 47-63Hz @ 8.0A for 1200 watt units

Output Voltage:

12 models-1kV to 160kV

Output Polarity:

Negative or positive, specify at time of order

Local Indicators:

Arc, HV On, Temp Error, OVP, I Mode Power On, OC, Reg Error

Power

3 power ranges available—300, 600 and 1200 watts. Other power levels available on special order.

- Compact & Lightweight
- Models from 1kV-160kV, 300W, 600W AND 1200W
- Universal Input, Power Factor Corrected
- Low Cost Modular Design
- Standard Digital Interfaces: USB, Ethernet and RS-232
- CE Compliant, UL Recognized

Voltage Regulation:

<0.01% of rated output voltage over specified input voltage range <0.01% of rated output voltage for a full load change

Current Regulation:

≤0.01% of rated output current over specified input voltage range ≤0.01% of rated output current for a ±100µA for a full voltage change

Ripple

≤0.2% rms of maximum rated voltage, measured with a 10 foot long HV cable

Stability:

≤50ppm/hr after a 2 hour warm up

Temperature Coefficient:

≤100ppm per degree C

Environmental:

Temperature Range:

Operating: 0°C to 40°C Storage: -40°C to 85°C

Humidity:

20% to 85% RH, non-condensing.

Control Interface

Local Interface:

Potentiometers are provided to adjust voltage and current.

Remote Interface: USB, Ethernet and RS-232 are standard,

implemented with 12 bits of resolution.

All digital monitors have an accuracy specification of 2%.

Control Software: A Windows graphical user interface example is provided.

HV Control Enable/Interlock:

A dry contact, hardware based interlock is provided for remote mode. In local mode this I/O is the enable.

Monitor Signals:

Voltage and current monitor signals are scaled 0-10Vdc equals 0-100% of full scale, accuracy is 1%.

Dimensions:

300/600 watts: 4.75" H X 6" W X 12" D

(120.65mm x 152.4mm x 304.8mm)

1200 watts: 4.75" H X 12" W X 12" D

(120.65mm x 304.8mm x 304.8mm)

160kV: 10.5"H X 19"W X 21.5"D

(266.7mm x 482.6mm x 546.1mm)

Weight:

300/600 watts: 14 pounds (6.35kg) 1200 watts: 26 pounds (11.8kg) 160kV: 142 pounds (64.4kg)



e-mail: sales@spellmanhv.com

PAGE 2 OF 4

Cooling:

Forced air

Input Line Connector:

IEC320 cord set with integrated EMI filter

Output Cable:

1-70kV units:

A detachable 10' (3.3m) long shielded HV cable is provided.

160kV units:

R24 connector. Mating HV cable not provided

Regulatory Approvals:

Compliant to 204/108/EC, the EMC Directive and 2006/95/EC, the Low Voltage Directive. UL/CUL recognized, File 227588. RoHS compliant. SLM160*1200 is not UL recognized.

SLM SELECTION TABLE- 300W

	300 Watt					
kV	mA	Model				
1	300	SLM1*300				
3	100	SLM3*300				
5	60	SLM5*300				
10	30	SLM10*300				
15	20	SLM15*300				
20	15	SLM20*300				
30	10	SLM30*300				
40	7.5	SLM40*300				
50	6	SLM50*300				
60	5	SLM60*300				
70	4.28	SLM70*300				

^{*}Specify "P" for positive polarity or "N" for negative polarity

SLM SELECTION TABLE- 600W

600 Watt					
kV	mA	Model			
1	600	SLM1*600			
3	200	SLM3*600			
5	120	SLM5*600			
10	60	SLM10*600			
15	40	SLM15*600			
20	30	SLM20*600			
30	20	SLM30*600			
40	15	SLM40*600			
50	12	SLM50*600			
60	10	SLM60*600			
70	8.56	SLM70*600			

^{*}Specify "P" for positive polarity or "N" for negative polarity

SLM SELECTION TABLE- 1200W

	1200 Watt					
kV	mA	Model				
1	1200	SLM1*1200				
3	400	SLM3*1200				
5	240	SLM5*1200				
10	120	SLM10*1200				
15	80	SLM15*1200				
20	60	SLM20*1200				
30	40	SLM30*1200				
40	30	SLM40*1200				
50	24	SLM50*1200				
60	20	SLM60*1200				
70	17.14	SLM70*1200				
160	7.5	SLM160*1200				

^{*}Specify "P" for positive polarity or "N" for negative polarity

SLM ANALOG INTERFACE— J2 15 PIN MALE D CONNECTOR

	PIN	SIGNAL	SIGNAL PARAMETERS
ſ	1	Power Supply Fault	Open Collector, 35V @ 10mA Maximum
Ī	2	Current Program In	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
I	3	Voltage Program In	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
Î	4	NC	No Connection
Ī	5	Local Voltage Prog.	Multi-turn front panel potentiometer
I	6	NC	No Connection
١	7	Local Current Prog.	Multi-turn front panel potentiometer
Ī	8	Voltage Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%
Î	9	Signal Ground	Ground
I	10	Current Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%
Ī	11	HV Enable Input	Connect to Pin 12 to HV Enable Supply
I	12	HV Enable Output	+15V @ Open, ≤15mA @ Closed
	13	NC	No Connection
ı	14	HV On Output Signal	Open Collector, 35V @10mA Maximum
Ì	15	Spare	No Connection

RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	NC	No Connection
2	TX out	Transmit Data
3	RX in	Receive Data
4	NC	No Connection
5	SGND	Ground
6	NC No Connection	
7	NC	No Connection
8	NC	No Connection
9	NC	No Connection

USB DIGITAL INTERFACE— J4 4 PIN USB "B" CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	VBUS	+5 Vdc
2	D-	Data -
3	D+	Data +
4	GND	Ground

ETHERNET DIGITAL INTERFACE— J5 8 PIN RJ45 CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receive Data +
4	NC	No Connection
5	NC	No Connection
6	RX-	Receive Data -
7	NC	No Connection
8	NC	No Connection

R24 HV CONNECTOR PINOUT J6 HIGH VOLTAGE OUTPUT (160kV)

PIN	OUTPUT CONNECTION
C (common)	High Voltage Output
S (small)	High Voltage Output
L (large)	High Voltage Output



1200 Watt

PAGE 3 OF 4

DIMENSIONS: in.[mm]


300/600 Watt BOTTOM VIEW HVOUTPUT 1-50kV HVOUTPUT 10-32 BLIND PEMS 4 PLCS 10.50 [266]

BOTTOM VIEW HV OUTPUT 1-50kV HV OUTPUT 10.50 [266] 10.50 [266]

FRONT VIEW

3.88 [99]


1.06 [27]




FRONT VIEW



SIDE VIEW



SIDE VIEW





PAGE 4 OF 4

DIMENSIONS: in.[mm]

160kV

TOP VIEW



FRONT VIEW



SIDE VIEW





Corporate Headquarters



PAGE 1 OF 5



Spellman's SL Series of high voltage power supplies are designed to meet uncompromising performance standards in a minimum of space. Their circuitry includes a resonant high frequency inverter with proprietary control which provides fault-free operation in extreme transient and arcing environments with greater than 85% efficiency. These full featured supplies are available in a wide range of outputs with many options.

TYPICAL APPLICATIONS

Analytical X-ray Capacitor Charging
Electrostatics Hipot Testing
E-Beam Systems General Laboratory

OPTIONS

See page 5 for options and descriptions

SPECIFICATIONS

Status Indicators:

Voltage and Current Control Mode, Interlock Open/Closed, High Voltage Inhibit, Overcurrent and Overvoltage, Arc, Regulation Error, Overtemperature, Over Power (optional).

Input

115Vac or 220Vac±10%, 50/60Hz. Specify with order. 1200W model available in 200/220Vac only. For input current see table on page 2.

Output:

Models available from 1kV to 130kV. Each model is available in positive, negative or reversible polarity output.

Front Panel Controls:

Voltage and current are continuously adjustable by ten-turn potentiometers with lockable counting dials, ON/OFF circuit breaker/lamp, high voltage ON switch/indicator and high voltage OFF switch/indicator.

Voltage Regulation:

Load: 0.005% of maximum voltage +500mV for full load change.

Line: ±0.005% of full voltage +500mV over specified input range

Current Regulation:

Load: 0.01% of maximum current ±100µA

for full voltage change.

Line: ±0.005% of maximum current for a ±10%

input line change.

Very Compact and Lightweight

- Voltage Range from 1kV to 130kV
- Reversible Polarity Standard up to 8kV
- Extensive Analog and Digital Interface
- Optional VFD Front Panel/Ethernet Interface
- Arc Quench/Arc Count/Arc Trip
- OEM Customization Available

Ripple:

0.1% p-p +1Vrms.

Temperature Coefficient:

100ppm/°C voltage or current regulated. Higher stability is available on special order.

Environmental:

Temperature Range: Operating: 0°C to 50°C. Storage: -40°C to 85°C.

Humidity:

10 to 90% relative humidity, non-condensing

Stability:

100ppm/hour after 1/2 hour warm-up for both voltage and current regulation.

Meterina:

Digital voltage and current meters, 3¹/₂ digit ±1 least significant digit.

Output Cable:

10' (3.05m) of shielded high voltage cable removable at the rear panel.

AC Line Input Cable:

10 to 300W: IEC320 Cord Set, 6' (1.83m) 600 to 1200W: 3-conductor, 12AWG, 6' (1.83m) cable permanently attached to unit.

Dimensions:

10W - 300W: 1³/₄"H(1U) x 19"W x 19"D** (4.45cm x 48.3cm x 48.3cm). 600W - 1200W: 3¹/₂"H(2U) x 19"W x 19"D** (8.9cm x 48.3cm x 48.3cm). **Depth becomes 24" (60.7cm) for 80 to 130kV ranges.

Weight:

17 to 30lbs (7.7 to 14kg) depending on model.

Regulatory Approvals:

Compliant to EEC EMC Directive and EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

SL series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The SL series is not intended to be operated by end users as a stand-alone device. The SL series power supply can only be fully assessed when installed within a system, and as a component part within that system.

PAGE 2 OF 5

SL SELECTION TABLE- 10W, 30W, 60W 1.75" (1U)

		10 Watt		30 V	30 Watt		60 Watt	
	kV	mA	Model	mA	Model	mA	Model	
١	1	10	SL1PN10	30	SL1PN30	60	SL1PN60	
	2	5	SL2PN10	15	SL2PN30	30	SL2PN60	
ı	3	3.3	SL3PN10	10	SL3PN30	20	SL3PN60	
1	6	1.7	SL6PN10	5	SL6PN30	10	SL6PN60	
١	8	1.25	SL8PN10	3.75	SL8PN30	7.5	SL8PN60	
١	10	1.0	SL10*10	3	SL10*30	6	SL10*60	
١	15	0.67	SL15*10	2	SL15*30	4	SL15*60	
١	20	0.50	SL20*10	1.5	SL20*30	3	SL20*60	
1	30	0.33	SL30*10	1.0	SL30*30	2	SL30*60	
ı	40	0.25	SL40*10	0.75	SL40*30	1.5	SL40*60	
ı	50	0.20	SL50*10	0.60	SL50*30	1.2	SL50*60	
١	60	0.17	SL60*10	0.50	SL60*30	1.0	SL60*60	
١	70	0.14	SL70*10	0.43	SL70*30	0.85	SL70*60	
١	80	0.13	SL80*10	0.38	SL80*30	0.75	SL80*60	
١	100	0.10	SL100*10	0.30	SL100*30	0.60	SL100*60	
١	120	0.10	SL120*10	0.25	SL120*30	0.50	SL120*60	
١	130	0.10	SL130*10	0.25	SL130*30	0.46	SL130*60	

SL SELECTION TABLE- 150W, 300W 1.75" (1U)

			` ,	
	150	Watt	300	Watt
kV	mA	Model	mA	Model
1	150	SL1PN150	300	SL1PN300
2	75	SL2PN150	150	SL2PN300
3	50	SL3PN150	100	SL3PN300
6	25	SL6PN150	50	SL6PN300
8	18.75	SL8PN150	37.5	SL8PN300
10	15	SL10*150	30	SL10*300
15	10	SL15*150	20	SL15*300
20	7.5	SL20*150	15	SL20*300
30	5.0	SL30*150	10	SL30*300
40	3.75	SL40*150	7.5	SL40*300
50	3.00	SL50*150	6.0	SL50*300
60	2.50	SL60*150	5.0	SL60*300
70	2.1	SL70*150	4.28	SL70*300
80	1.90	SL80*150	3.75	SL80*300
100	1.50	SL100*150	3.00	SL100*300
120	1.25	SL120*150	2.50	SL120*300
130	1.15	SL130*150	2.30	SL130*300

SL SELECTION TABLE- 600W, 1200W 3.50" (2U)

	` '			
	600 W	att	1200	Watt
kV	mA	Model	mA	Model
1	600	SL1PN600	1200	SL1PN1200
2	300	SL2PN600	600	SL2PN1200
3	200	SL3PN600	400	SL3PN1200
6	100	SL6PN600	200	SL6PN1200
8	75	SL8PN600	150	SL8PN1200
10	60	SL10*600	120	SL10*1200
15	40	SL15*600	80	SL15*1200
20	30	SL20*600	60	SL20*1200
30	20	SL30*600	40	SL30*1200
40	15	SL40*600	30	SL40*1200
50	12	SL50*600	24	SL50*1200
60	10	SL60*600	20	SL60*1200
70	8.6	SL70*600	17	SL70*1200
80	7.5	SL80*600	15	SL80*1200
100	6.0	SL100*600	12	SL100*1200
120	5.0	SL120*600	10	SL120*1200
130	4.6	SL130*600	9.2	SL130*1200

SL INPUT CURRENT

MODEL	115Vac	220Vac
10 watt	<1A	<1A
30 watt	<1A	<1A
60 watt	1.1A	<1A
150 watt	2.8A	1.5A
300 watt	5.6A	3A
600 watt	11.1A	6A
1200 watt	n/a	12A

The input current numbers above are worse case assuming the power supply is being operated at maximum power and low line conditions, taking efficiency and power factor into account.

SL TERMINAL BLOCK 26 PIN

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power Supply Common	Signal Ground
2	External Inhibit	Ground=Inhibit, Open=HV On
3	External Interlock	+15V at Open, <15mA at Closed
4	External Interlock Return	Return for Interlock
5	Current Monitor	0 to 10V=0 to 100% Rated Output
6	kV Test Point	0 to 10V=0 to 100% Rated Output
7	+10Vdc Reference	+10Vdc, 1mA Max
8	Remote Current Program In	0 to 10V=0 to 100% Rated Output
9	Local Current Program Out	Front Panel Program Voltage
10	Remote Voltage Program In	0 to 10V=0 to 100% Rated Output
11	Local Voltage Program Out	Front Panel Program Voltage
12	Power Monitor	0 to 10V=0 to 100% Rated Output
13	Remote Power Program In	(Optional)
14	Local HV Off Out	+15V at Open, <25mA at Closed
15	HV Off	Connect to HV OFF for FP Operation
16	Remote HV On	+15V, 10mA Max=HV Off
17	Remote HV Off Indicator	0=HV On, +15V, 10mA Max=HV Off
18	Remote HV On Indicator	0=HV Off, +15V, 10mA Max=HV On
19	Remote Voltage Mode	Open Collector 25V May 10mA May
20	Remote Current Mode	Open Collector 35V Max, 10mA Max On=Active
21	Remote Power Mode	OH=Active
22	Remote PS Fault	0=Fault, +15V, 0.1mA Max=No Fault
23	+15V Output	+15V, 100mA Max
24	Power Supply Common	Signal Ground
25	Spare	Spare
26	Shield Return	Chassis Ground

How To Order:

Sample model number: SL80PN1200/NSS/DPM4

SL series unit, 80kV maximum output voltage, reversible polarity output, 1200 watts, no slow start, 4.5 digit panel meters

There may be some restrictions on multiple option combinations. Please contact our sales department for more details.

*Specify "P" for positive, "N" for negative, or "PN" for reversible polarity. Higher voltage models available on special order.



DIMENSIONS: in.[mm]

10W-300W 600W-1200W 0.38 [9.53] **FRONT VIEW FRONT VIEW** 0.38 [9.52] 4 PL 0.25 [6.35] 19.00 [482.60] 0.25 [6.35] 19.00 [482.60] 1.25 [31.75] 4 PL 4 PL TYP 3.00 [76.20] 1.72 [43.66] i o 3.45 TYP [87.60] 18.31 [465.14] 0.23 [5.97] 0.34 [8.73] 18.31 [465.14] 0.23 [5.72] 0.34 [8.73] **TOP VIEW** TYP **TOP VIEW** 17.00 [431.80] 17.03 [432.49] 19.00 [482.60] 19.00 [482.60] *24.00 [609.60] *24.00 [609.60] DANGER HIGH VOLTAGE DANGER HIGH VOLTAGE **BACK VIEW BACK VIEW** IEC 320 16.87 [428.62] INPUT CONNECTOR 26 PIN TERMINAL 16.88 [428.62] BLOCK FOR REMOTE CONTROL MONITORING 2 PIN TERMINAL 26 PIN TERMINAL **BLOCK LOAD** MATING CONNECTOR 6 ft OF LINE CABLE **BLOCK FOR** 2 PIN TERMINAL BLOCK LOAD RETURN AND 10ft. OF SUPPLIED WITH UNIT REMOTE CONTROL RETURN (CHASSIS GROUND) (CHASSIS GROUND) HIGH VOLTAGE MONITORING CABLE SUPPLIED MATING CONNECTOR WITH UNIT AND 10ft. OF HIGH VOLTAGE CABLE SUPPLIED

* Depth becomes 24" [609.60] for 80kV to 130kV range.





WITH UNIT

PAGE 4 OF 5

eSL OPTION



The eSL Option provides a vacuum fluorescent front panel display and Ethernet connectivity. Both the 1U (1.75") and 2U (3.5") SL product offerings are available with the eSL Option. Using the front panel local controls the main menu has the following features:

Local/Remote Control

Allows operation from either the local front panel or remotely via the Ethernet Category 5 connector.

Features Menu

Allows control over Adjustable Overload Trip and Slow Start features.


Tutorial Menu


Provides information on how to use the local front panel interface.

Diagnostics Menu

Provides information on the revisions of the hard ware, firmware and IP address. Additionally the Diagnostics Menu provides information on the status of the internal low voltage housekeeping power supply voltages.

eSL Option power supplies can still be fully controlled via the SL's comprehensive remote analog interface, so these units are fully backwards compatible with standard SL power supplies.









SL SERIES OPTIONS

AOL Adjustable Overload Trip

A control board jumper is moved to make the power supply shut down if it ever operates in current mode. This allows the user to set the current programming level as a trip point that will turn the power supply off with an Over Current fault if it ever tries to operate in Current Mode.

Adjustable Power Trip

A third control loop is installed in the power supply, a power loop. This power loop uses an analog multiplier chip to multiply the voltage and current feedback signals to create a power feedback signal. Programming and feedback scaling is 0-10Vdc = 0-100% of rated power. The circuit is configured to trip the power supply off with an Over Power fault if the power loop ever tries to regulate.

ΑT

A control board jumper is moved such that the first arc sensed will shut the power supply off with an ARC fault.

CMS Current Mode Select

A front panel switch is provided to allow the power supply to either regulate in current mode or create an over current fault when operated in current mode, which will shut down the supply. This is basically a switch selectable AOL option.

CPC Constant Power Control

Identical to the APT Option with the exception the power supply will run and regulate when the power loop becomes active.

DPM4 Digital Panel Meter, 4.5 digits

The standard 3.5 digit front panel meters are replaced with 4.5 digit panel meters.

EFR External Fault Relay

A set of relay contacts are provided via the rear panel interface that will change state if the power supply shuts down due to a fault condition.

eSL Ethernet Connectivity/VFD Front Panel

The eSL Option provides a vacuum fluorescent front panel display, Ethernet connectivity and comprehensive front panel controls.

FCV Fine Control Voltage

This option adds a second potentiometer to the front panel of the unit. This allows for a finer local adjustment of the output voltage setting.

FG Floating Ground

All the analog returns inside the power supply are isolated from chassis and brought to one point on the rear panel. Any current that flows out of the power supply via the HV cable/connecter on the high side must return back to the multiplier via the load return on the low side. With only one path to flow through on the low side, a current meter can be inserted in series and a safe ground referenced measurement can be made of the actual high voltage output current.

FGLL Floating Ground Low Leakage

Identical functionality as the FG Option but a shield is placed around the high voltage multiplier to capture any leakage current inside the power supply and return it to the top of the current sense resistor. This negates any internal leakage currents from effecting measurements being made.

10 Instant On

A jumper is placed between TB1-15 and TB1-16 on the rear panel, causing the power supply to automatically toggle into HV ON when ever the line voltage is applied.

LL(X) Lead Length

Extra long high voltage output cable. 20, 40, 60 and 100 feet are standard lengths.

LR Low Ripple

Done on a case by case basis, the standard unit is evaluated and modifications are done to improve the output ripple to 0.05% peak to peak. The operating frequency might be increased, or additional filtering may be added to the HV multiplier.

NAD No Arc Detect

This option removes the arc intervention circuitry from the power supply. Care must be exercised when using this option as damage to the HV multiplier could occur.

NSS No Slow Start

The standard 6 second long linear ramp of output voltage is removed allowing the high voltage to "step" to its set point when enabled.

PN Positive/Negative

Reversible polarity option. Units that are not inherently reversible by design (10kV to 130kV) can have their output polarity reversed by the process of exchanging the high voltage multiplier section.

RFR Remote Fault Reset

This option provides the ability to reset any power supply faults that might occur via toggling a signal on the rear panel interface.

ROV Remote Over Voltage

The programming signal for the over voltage comparator circuit is made available to the customer remotely, allowing the power supply to be set to trip the OVP circuit anywhere from 0 -110% of rated output voltage.

SL

Industry standard rack mounted slides are installed on the power supply.

SS(X) Slow Start(X)

The standard slow start is modified to provide a time of (X) seconds. Time frames of 0.1 seconds to 120 seconds can be accommodated.

There may be some restrictions on multiple option combinations. Please contact our Sales department for more details.



www.spellmanhv.com





Spellman's SL150kV rack mount high voltage power supply is designed for scientific and industrial OEM applications requiring 150kV at 1200 watts in a compact cable connected standard sized rack. Models are available in positive, negative or reversible polarity. The SL150kV is fully arc and short circuit protected. Excellent regulation specifications are provided along with outstanding stability performance. The vacuum encapsulated high voltage output section assures reliable corona free operation by eliminating any concerns due to environmental factors.

TYPICAL APPLICATIONS

Electrostatics HiPot Testing Semiconductor Processing Capacitor Charging

OPTIONS

200	200Vac Input Voltage	
AOL	Adjustable Overload Trip	
APT	Adjustable Power Trip	
AT	Arc Trip	
BFP	Blank Front Panel	
CPC	Constant Power Control	
DPM4	4.5 Digit Panel Meters	
EFR	External Fault Relay	
LL(X)	Non-Standard HV Cable Length	
	(10 standard)	
NAD	No Arc Detect	
NSS	No Slow Start	
RFR	Remote Fault Reset	
SS(X)	Non-Standard Slow Start	
	(6 seconds standard)	

- Cable Connected 150kV @ 1200W Power Supply
- Requires Only 8.75" (5U) Panel Height
- Extensive Analog Interface
- Arc Quench/Arc Count/Arc Trip
- Comprehensive Digital Fault Diagnostics

SPECIFICATIONS

Front Panel Controls:

Power ON/OFF switch, HV ON Switch, HV OFF Switch with preset feature, 3.5 digit backlight digital meters for display of output voltage and output current, 10 turn locking potentiometers with counting dials for adjustment of both output voltage and output current.

Front Panel Indicators:

HV ON High Voltage Inhibit HV OFF Over Current Voltage Control Mode Over Voltage Current Control Mode Arc

Interlock Open Regulation Error Interlock Closed Overtemperature

Input:

220Vac ±10%, 50/60Hz @ 12A 200Vac ±10%, 50/60Hz @ 13.2A

Output Voltage:

0 to 150kV

Output Polarity:

Positive, negative or reversible specify at time of order

Output Current:

8mA

Output Power:

1200W

Voltage Regulation:

Load: 0.01% of rated voltage for a full load change Line: ±0.01% of rated voltage over specified input voltage range

Current Regulation:

Load: 0.01% of rated current ±100µA for full voltage change.

Line: ±0.01% of rated current over specified input

voltage range

Ripple:

0.1% peak to peak of maximum output

Temperature Coefficient:

100ppm/°C.

100ppm/hr after a 2 hour warm up, for both voltage and current regulation

Operating Temperature:

0 to 40°C operating

Storage Temperature:

-40 to +85°C storage



PAGE 2 OF 2

Humidity:

20% to 85%, non-condensing

Input Line Connector:

3 conductor 12 AWG 6 ft (1.83m) cable, permanently attached

Output Connector:

A detachable 10 ft (3.05m) shielded HV cable is provided

Cooling:

Forced Air

Dimensions:

8.75"H x 19"W x 22"D rack mount. (22.23cm x 48.26cm x 55.88cm)

Weight:

89 pounds (40.4kg)

Regulatory Approvals:

Designed to meet EEC EMC Directive. Designed to meet to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

SL150kV series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The SL150kV series is not intended to be operated by end users as a stand-alone device. The SL150kV series power supply can only be fully assessed when installed within a system, and as a component part within that system.

SL150KV ANALOG INTERFACE— JB4 25 PIN MALE D CONNECTOR


PIN	SIGNAL	PARAMETERS
1	Power Supply Common	Signal Ground
2	External Inhibit	Ground = Inhibit, Open = HV ON
3	External Interlock	+15Vdc @ open, ≤ 5mA @ closed
4	External Interlock Return	Connect to pin 3 to enable supply
5	Current Monitor	0 to 10Vdc = 0 to 100% rated voltage, Zout = $10k\Omega$
6	Voltage Monitor	0 to 10Vdc = 0 to 100% rated voltage, Zout = $10k\Omega$
7	+10Vdc Reference	+10Vdc @ 1mA, maximum
8	Remote Current Program Input	0 to 10Vdc = 0 to 100% rated voltage, Zout = $10k\Omega$
9	Local Current Program Output	
10	Remote Voltage Program Input	
11		Multi-turn front panel pot for local control capability
12	EFR (Common)	External Fault Relay (Optional)
13	EFR (Normally Open)	External Fault Relay (Optional)
14	Local HV OFF OUT	+15Vdc @ open, <25mA @ closed, connect to
Ш		HV OFF for front panel operation
15	HV OFF	Connect to HV OFF OUT for front panel operation
16	Remote HV ON	+15Vdc @ 10mA maximum = HV OFF
17	Remote HV OFF Indicator	0 = HV ON, +15Vdc @ 10mA maximum = HV OFF
18	Remote HV ON Indicator	0 = HV OFF, +15Vdc @ 10mA maximum = HV ON
19	Remote Voltage Mode	Open collector 50Vdc @ 10mA maximum, ON = Active
20	Remote Current Mode	Open collector 50Vdc @ 10mA maximum, ON = Active
21	Remote Power Mode	Open collector 50Vdc @ 10mA maximum, ON = Active
22	Power Supply Fault	Open collector, 50Vdc @ 10mA maximum
23	+15Vdc Output	+15Vdc @ 100mA, maximum
24	Power Supply Ground	Signal Ground
25	Shield Return	Chassis Ground

Specify "P" for positive polarity or "N" for negative polarity, and PN = reversible as illustrated below.

Sample Model Number: SL150P1200/BFP/LL(20)


Where SL = power supply series, 150 = maximum output voltage in kV, P = positive output polarity, 1200 = maximum output power (watts), BFP = Blank Front Panel, LL(20) = 20 foot HV cable.







BACK VIEW







PAGE 1 OF 4



Spellman's SL2KW Series of 2kW high voltage power supplies are designed to meet uncompromising performance standards in a minimum of space. Their circuitry includes a resonant high frequency inverter with proprietary control which provides fault-free operation in extreme transient and arcing environments with greater than 85% efficiency. These full featured supplies are available in a wide range of outputs with many options.

TYPICAL APPLICATIONS

Semiconductor Manufacturing CPT/CRT Testing Electrostatics **Hipot Testing** E-Beam Systems General Laboratory Capacitor Charging **CW Lasers**

OPTIONS

See page 4 for options and descriptions

SPECIFICATIONS

Status Indicators:

Voltage and Current Control Mode, Interlock Open and Closed, High Voltage Inhibit, Overcurrent and Overvoltage, Arc, Regulation Error, Overtemperature.

Input:

Standard: 208Vac ±10%, 50/60Hz @ 8.5A/phase, three phase Optional: 220Vac ±10%, 50/60Hz @ 19.75A, single phase

Output:

Models available from 0.5kV to 50kV. Each model is available in positive, negative or reversible polarity output.

Front Panel Controls:

Voltage and current are continuously adjustable by ten-turn potentiometers with lockable counting dials, ON/OFF circuit breaker/lamp, high voltage ON switch/indicator and high voltage OFF switch/indicator.

Voltage Regulation:

Load: 0.005% of maximum voltage +500mV for full load change. Line: ±0.005% of full voltage +500mV over specified input range

Current Regulation:

Load: 0.01% of maximum current ±100µA

for full voltage change.

Line: ±0.005% of maximum current for a ±10%

input line change.

Very Compact and Lightweight

- Low EMI and RFI
- Voltage Range from 500V to 50kV
- Reversible Polarity Standard up to 8kV
- Optional VFD Front Panel/Ethernet Interface
- Extensive Analog and Digital Interface
- Arc Quench/Arc Count/Arc Trip
- OEM Customization Available

Ripple:

0.1% p-p +1Vrms, three phase line input 0.3% p-p +1Vrms, single phase line input

Temperature Coefficient:

100ppm/°C voltage or current regulated. Higher stability is available on special order.

Environmental:

Temperature Range: Operating: 0°C to 50°C. Storage: -40°C to 85°C.

10 to 90% relative humidity, non-condensing

Stability:

100ppm/hour after 1/2 hour warm-up for both voltage and current regulation.

Digital voltage and current meters, 31/2 digit ±1 least significant digit.

Interface Connector:

25 pin male D connector

Output Cable:

10' (3.3m) of shielded high voltage cable removable at the rear panel.

AC Line Input Cable:

A 6 foot (1.83m) cable is permanently attached to the unit. Single phase units use 3 conductor 12AWG cable, three phase units use 4 conductor 16AWG cable.

Dimensions:

3.5" H(2U) x 19" W x 19" D (8.9cm x 48.3cm x 48.3cm)

17 to 26lbs (7.7 to 11.8kg) depending on model.

Regulatory Approvals:

Compliant to EEC EMC Directive for 3 phase units, conducted and radiated emission only for single phase units. Compliant to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

SL2KW series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The SL2KW series is not intended to be operated by end users as a stand-alone device. The SL2KW series power supply can only be fully assessed when installed within a system, and as a component part within that system.



SL2KW 2000W COMPACT HV POWER SUPPLY

eSL OPTION



The eSL Option provides a vacuum fluorescent front panel display and Ethernet connectivity. Using the front panel local controls the main menu has the following features:

Local/Remote Control

Allows operation from either the local front panel or remotely via the Ethernet Category 5 connector.

Features Menu

Allows control over Adjustable Overload Trip and Slow Start features.

Tutorial Menu

Provides information on how to use the local front panel interface.

Diagnostics Menu

Provides information on the revisions of the hard ware, firmware and IP address. Additionally the Diagnostics Menu provides information on the status of the internal low voltage housekeeping power supply voltages.

eSL Option power supplies can still be fully controlled via the SL2KW's comprehensive remote analog interface, so these units are fully backwards compatible with standard SL2KW power supplies.

Typical Front Panel Screens

Model Number

eSL 50P2000 Spellman

Standby



HV ON



Digital Interface

A front panel accessible Category 5 connector provides Ethernet connectivity. Spellman provides a basic demo GUI for convenience of the user, but most customers implement their own software.

About Screen

DSP part number, DSP revision, GUI part number, GUI revision, Command set part number, Command set revision



Coms Screen

Communications, IP address, IP port



HV Power and System Voltages Screen

HV power (watts) +24V, +15V, +10V, +5V, +3.3V



User Configuration Screen

Slow Start – kV, Slow Start – mA, Adjustable Over Load (AOL), Arc Control, Fault Indicators



Main Screen

kV Setpoint, kV Readback, mA Setpoint, mA Readback, HV OFF Button, HV ON Button, Arc Counter, System Diagnostics, Reset Faults Button



PAGE 3 OF 4

SL2KW SELECTION TABLE

MAXIMUM RATING		MODEL NUMBER
kV	mA	
0.5	4000	SL0.5PN2000
1	2000	SL1PN2000
2	1000	SL2PN2000
3	666	SL3PN2000
6	333	SL6PN2000
8	250	SL8PN2000
10	200	SL10*2000
15	133	SL15*2000
20	100	SL20*2000
30	66.6	SL30*2000
40	50	SL40*2000
50	40	SL50*2000

^{*}Specify "P" for positive polarity or "N" for negative polarity or "PN" for reversible polarity

SL2KW 25 PIN D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS	
1	Power Supply Common	Signal Ground	
2	External Inhibit	Ground=Inhibit, Open=HV On	
3	External Interlock	+15V at Open, <15mA at Closed	
4	External Interlock Return	Return for Interlock	
5	Current Monitor	0 to 10V=0 to 100% Rated Output	
6	kV Test Point	0 to 10V=0 to 100% Rated Output	
7	+10Vdc Reference	+10Vdc, 1mA Max	
8	Remote Current Program In	0 to 10V=0 to 100% Rated Output	
9	Local Current Program Out	Front Panel Program Voltage	
10	Remote Voltage Program In	0 to 10V=0 to 100% Rated Output	
11	Local Voltage Program Out	Front Panel Program Voltage	
12	EFR Common	Optional External Fault Relay	
13	EFR-NC/EFR-NO	30V @ 2A Maximum	
14	Local HV Off Out	+15V at Open, <25mA at Closed	
15	HV Off	Connect to HV OFF for FP Operation	
16	Remote HV On	+15V, 10mA Max=HV Off	
17	Remote HV Off Indicator	0=HV On, +15V, 10mA Max=HV Off	
18	Remote HV On Indicator	0=HV Off, +15V, 10mA Max=HV On	
19	Remote Voltage Mode	Open Collector 35V Max, 10mA Max,	
20	Remote Current Mode	On=Active	
21	Remote Power Mode		
22	Remote PS Fault	0=Fault, +15V, 0.1mA Max=No Fault	
23	+15V Output	+15V, 100mA Max	
24	Power Supply Common	Signal Ground	
25	Shield Return	Chassis Ground	

How To Order:


Sample model number: SL20PN2000/NSS/DPM4

SL2KW Series unit, 20kV maximum output voltage, reversible polarity output, 2000 watts, no slow start, 4.5 digit panel meters


There may be some restrictions on multiple option combinations. Please contact our Sales department for more details.

DIMENSIONS: in.[mm]


FRONT VIEW



TOP VIEW



BACK VIEW







Corporate Headquarters

Hauppauge, New York USA



SL2KW SERIES OPTIONS

AOL Adjustable Overload Trip

A control board jumper is moved to make the power supply shut down if it ever operates in current mode. This allows the user to set the current programming level as a trip point that will turn the power supply off with an Over Current fault if it ever tries to operate in Current Mode.

APT Adjustable Power Trip

A third control loop is installed in the power supply, a power loop. This power loop uses an analog multiplier chip to multiply the voltage and current feedback signals to create a power feedback signal. Programming and feedback scaling is 0-10Vdc = 0-100% of rated power. The circuit is configured to trip the power supply off with an Over Power fault if the power loop ever tries to regulate.

ARC Arc Sense

A signal is provided on a spare pin (TB1-21) that changes state whenever the power supply detects an arc.

AT Arc Trip

A control board jumper is moved such that the first arc sensed will shut the power supply off with an ARC fault.

CMS Current Mode Select

A front panel switch is provided to allow the power supply to either regulate in current mode or create an over current fault when operated in current mode, which will shut down the supply. This is basically a switch selectable AOL option.

CPC Constant Power Control

Identical to the APT Option with the exception the power supply will run and regulate when the power loop becomes active.

DPM4 Digital Panel Meter, 4.5 digits

The standard 3.5 digit front panel meters are replaced with 4.5 digit panel meters.

EFR External Fault Relay

A set of relay contacts are provided via the rear panel interface that will change state if the power supply shuts down due to a fault condition.

Ethernet Connectivity/VFD Front Panel The eSL Option provides a vacuum fluorescent

front panel display, Ethernet connectivity and comprehensive front panel controls.

FCV Fine Control Voltage

This option adds a second potentiometer to the front panel of the unit. This allows for a finer local adjustment of the output voltage setting.

10 Instant On

A jumper is placed between TB1-15 and TB1-16 on the rear panel, causing the power supply to automatically toggle into HV ON when ever the line voltage is applied.

LL(X) Lead Length

Extra long high voltage output cable. 20, 40, 60 and 100 feet are standard lengths. Non standard lengths can be custom ordered.

NAD No Arc Detect

This option removes the arc intervention circuitry from the power supply. Care must be exercised when using this option as damage to the HV multiplier could occur.

NSS No Slow Start

The standard 6 second long linear ramp of output voltage is removed allowing the high voltage to "step" to its set point when enabled.

PΝ Positive/Negative

Reversible polarity option. Units that are not inherently reversible by design (10kV to 50kV) can have their output polarity reversed by the process of exchanging the high voltage multiplier section.

RFR Remote Fault Reset

This option provides the ability to reset any power supply faults that might occur via toggling a signal on the rear panel interface.

ROV Remote Over Voltage

The programming signal for the over voltage comparator circuit is made available to the customer remotely, allowing the power supply to be set to trip the OVP circuit anywhere from 0 -110% of rated output voltage.

SL Slides

Industry standard rack mounted slides are installed on the power supply.

SS(X) Slow Start(X)

The standard slow start is modified to provide a time of (X) seconds. Time frames of 0.1 seconds to 120 seconds can be accommodated.

There may be some restrictions on multiple option combinations. Please contact our Sales department for more details.





- 160kV 360kV Outputs
- Low Ripple
- High Stability
- Overcurrent, Overvoltage and Arc Protection
- Arc Detect
- Lightweight, Compact Size
- OEM Customization Available

The SLS series of high voltage power supplies provide up to 2000 watts of power with voltage outputs ranging from 160kV to 360kV. These power supplies utilize high frequency resonant inverters with proprietary controls for reliable operation in extreme environments. The high voltage multiplier unit is built with a hybrid design of solid encapsulation and air, thus reducing its overall size. Comprised of 20kV interlocking wafers, the multiplier unit offers flexible building blocks for many different output configurations.

TYPICAL APPLICATIONS

Ion Implantation
Particle Accelerators
Electron Guns

OPTIONS

eSL Ethernet Connectivity/VFD Front Panel

SPECIFICATIONS

Input Voltage:

Standard: 220Vac $\pm 10\%$, 50/60Hz @ 8A/phase, three phase Optional: 200Vac $\pm 10\%$, 50/60Hz @ 8.9A/phase, three phase

Output Voltage Range:

Models available from 160kV to 360kV and up to 2000W. Each model is available with positive or negative polarity outputs.

Voltage Regulation:

Better than 0.05% for specified line variations and load variations.

Ripple:

0.1% p-p of maximum output voltage.

Remote Voltage Control:

0 to +10V for 0 to maximum voltage. Accuracy and repeatability: 1% of maximum rating.

Remote Current Control:

0 to +10V for 0 to maximum voltage. Accuracy and repeatability: 1% of maximum rating.

+1-631-630-3000

e-mail: sales@spellmanhv.com

Voltage Monitor:

0 to 10V equivalent to rated voltage. Accuracy, 1% reading.

Current Monitor:

0 to 10V equivalent to rated current. Accuracy, 1% reading.

Stability:

0.05% per hour after 1/2 hour warm-up. 0.05% per 8 hours.

Slow Start:

Slow start times: 6 seconds standard.

Temperature Coefficient:

0.01% per degrees C.

Protection:

Overcurrent, Overvoltage, Arc protection, Overtemperature.

Arc Detect:

If 8 arcs occur in a 10 second, non-synchronous time window, the supply reverts to the Power Down Mode with an ARC fault displayed on the front panel default diagnostic display.

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -20°C to 85°C

Humidity:

10% to 70%, non-condensing.

Dimensions:

Inverter Driver Chassis: 3.50" (2U) H x 19.0" W x 19.0" D (8.9cm x 48.3cm x 48.3cm) Multiplier Unit: See page 3.

Distance from Stack to Driver:

2.5 meters ±0.1 meter maximum.

Signal Connector:

25 pin, male D connector, J3.

Metering:

Front panel, 3.5 digit, digital voltage and current meters.

Front Panel Controls:

Voltage and current are continuously adjustable by ten-turn potentiometers with lockable counting dials, ON/OFF circuit breaker/lamp, high voltage ON switch/indicator and high voltage OFF switch/indicator.





Front Panel Status Indicators:

Voltage Control Mode Current Control Mode Interlock Open Interlock Closed High Voltage Inhibit Regulation Error Overtemperature
Overpower (optional)
Overcurrent
Overvoltage
Arc

Regulatory Approvals:

RoHS compliant

Electronic Component (Power Source)

SLS series is intended for installation as a component of a system. It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The SLS series is not intended to be operated by end users as a stand-alone device. The SLS series power supply can only be fully assessed when installed within a system, and as a component part within that system.

Corona Dome Terminations:

The SLS Series of "stack" configured high voltage power supplies come in a various output voltages and different physical configurations. Appropriate corona relief is required for these units to operate at maximum output voltage. Frequently users will provide the corona relief needed so Spellman will provide stack assemblies that by themselves will not be able to operate at maximum output voltage corona free. Please be certain to discuss your requirements with Spellman to be assured you get a stack assembly in the physical configuration you require for your application. The optional K941 Toroid (5" x 20") should be considered if customer corona relief will not be provided.



SLS SELECTION TABLE

MAXIMUM RATING		MODEL NUMBER
kV	mA	
160	12.5	SLS160*2000
200	10.0	SLS200*2000
260	7.7	SLS260*2000
300	6.6	SLS300*2000
360	5.5	SLS360*2000

^{*}Specify "P" for positive polarity or "N" for negative polarity Other combinations of voltage and current are available.

SLS I/O INTERFACE CONNECTOR 25 PIN

PIN	SIGNAL	
1	Power Supply Common	
2	External Inhibit	
3	External Interlock	
4	External Interlock Return	
5	Current Monitor	
6	Voltage Monitor	
7	+10V Reference	
8	Remote Current Program In	
9	Local Current Program Out	
10	Remote Voltage Program In	
11	Local Voltage Program Out	
12	Optional EFR (common)	
13	Optional EFR (normally closed)	
14	Local HV OFF Out	
15	HV OFF	
16	Remote HV ON	
17	Remote HV OFF Indicator	
18	Remote HV ON Indicator	
19	Remote Voltage Mode	
20	Remote Current Mode	
21	Spare	
22	Remote PS Fault	
23	+15V Output	
24	Power Supply Common	
25	Shield Return	



eSL OPTION



The eSL Option provides a vacuum fluorescent front panel display and Ethernet connectivity. Using the front panel local controls the main menu has the following features:

Local/Remote Control

Allows operation from either the local front panel or remotely via the Ethernet Category 5 connector.

Features Menu

Allows control over Adjustable Overload Trip and Slow Start features.

Tutorial Menu

Provides information on how to use the local front panel interface.

Diagnostics Menu

Provides information on the revisions of the hard ware, firmware and IP address. Additionally the Diagnostics Menu provides information on the status of the internal low voltage housekeeping power supply voltages.

eSL Option power supplies can still be fully controlled via the SL2KW's comprehensive remote analog interface, so these units are fully backwards compatible with standard SL2KW power supplies.

Typical Front Panel Screens

Model Number



Standby



HV ON



Digital Interface

A front panel accessible Category 5 connector provides Ethernet connectivity. Spellman provides a basic demo GUI for convenience of the user, but most customers implement their own software.

About Screen

DSP part number, DSP revision, GUI part number, GUI revision, Command set part number, Command set revision



Coms Screen

Communications, IP address, IP port



HV Power and System Voltages Screen

HV power (watts) +24V, +15V, +10V, +5V, +3.3V



User Configuration Screen

Slow Start – kV, Slow Start – mA, Adjustable Over Load (AOL), Arc Control, Fault Indicators




Main Screen


kV Setpoint, kV Readback, mA Setpoint, mA Readback, HV OFF Button, HV ON Button, Arc Counter, System Diagnostics, Reset Faults Button



PAGE 4 OF 4


DIMENSIONS: in.[mm]





TOP VIEW

19.13 [485.78]





300kV Model

360kV Model









- 4kW's in Single 3U (5.25") Chassis
- Models from 1kV to 70kV
- Remote Analog and Remote Ethernet Interface
- Arc and Short Circuit Protected
- Customer Configurable Features Via Ethernet Interface
- OEM Customization Available

Spellman's STA Series of 4kW high voltage power supplies are available in positive or negative polarities in 15 different models with outputs ranging from 1kV to 70kV. A full featured front panel allows easy local control, while an extensive analog interface provides comprehensive remote capability. The standard Ethernet and RS-232 digital interfaces simplify integrating the STA into your system design.

The STA's robust IGBT inverter is inherently fault tolerant and is ideal for demanding applications like semiconductor processing and vacuum deposition. Many operational features can be configured by the user to suit their particular requirements.

TYPICAL APPLICATIONS

Ion Beam Implantation Semiconductor Processing Electron Beam Welding Capacitor Charging High Power RF Transmitters Electrostatic Precipitators X-Ray Systems

HARDWARE BASED OPTIONS

BFP Blank Front Panel High Stability

LL(X) High Voltage Cable Length1PH 180-264Vac, Single Phase Input

SOFTWARE CONFIGURABLE FEATURES

Adjustable Overload Trip Arc Trip Count Arc Quench Time Arc Re-Ramp Time Constant Power Control Adjustable Power Trip Slow Start Ramp Times

SPECIFICATIONS

Input Voltage:

Standard: 180-264Vac, 50/60Hz, three phase, 90% efficiency, 0.85 power factor

Optional: 180-264Vac 50/60Hz, single phase (1PH)

Input Current:

Standard: 180-264Vac, three phase 17 amps, maximum Optional: 180-264Vac, single phase 38 amps, maximum

Output Voltage:

15 models from 1kV to 70kV. Each model is available with positive or negative outputs.

Local Output Controls:

Voltage and current are continuously adjustable over entire range via ten-turn potentiometers with lockable counting dials.

Voltage Regulation:

Load: 0.05% of full voltage +500mV for full load change.
Line: 0.05% of full voltage +500mV over specified input range.

Current Regulation:

Load: 0.05% of full current ±100µA for any voltage change. Line: 0.05% of full current over specified input range.

Ripple:

0.1% p-p +1Vrms

Stability:

0.02%hr. after 1 hour warm-up.

Temperature Coefficient:

100ppm/°C. Higher stability (50ppm/°C) available on special order via the HS option

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -40°C to 85°C
Humidity:

10% to 90% RH, non-condensing.

Cooling:

Forced air; inlet through side panels, outlet at rear panel

Metering:

Digital voltage and current meters, accurate to within 1%

System Status Display:

"Dead Front" type indicators provide status of up to 12 system operations including voltage and current regulation, fault conditions and circuit control.



55



Analog Interface Connector:

50 pin female D connector

High Voltage Output Cable:

A detachable 10' (3.05m) long shielded HV cable is provided

Dimensions:

1kV to 70kV:

5.25" (3U)H X 19" W X 21" D (133mm x 482mm x 533mm)

Weight:

1kV to 8kV: 46 lbs. (20.87kg) 10kV to 70kV: 58 lbs. (26.31kg) Individual kV models may vary

Regulatory Approvals:

Designed to meet EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

STA series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The STA series is not intended to be operated by end users as a stand-alone device. The STA series power supply can only be fully assessed when installed within a system, and as a component part within that system.

Digital Interface

The STA features a standard RS-232 and Ethernet digital interface. Utilizing these standard digital interfaces can dramatically simplify power supply interfacing requirements saving the user both time and money, while enhancing functionality and overall capability. Spellman provides a GUI with the STA that allows the customer to both customize operational features of the STA while also providing basic power supply operational features. Details of the STA's digital interface capability are described in the STA manual, downloadable via the link on the first page of this data sheet.

Arc Intervention

Spellman's STA power supplies have an arc intervention feature that senses arc currents via a fast acting current sense transformer. The purpose of the arc intervention circuitry is to prevent power supply damage from continuous, long term arcing. The factory default configuration will trip off the unit with an Arc Fault if 4 arcs occur in a 10 second time period. Customers can change basic arc intervention parameters (Arc Count, Arc Quench, Reramp Time, and Window Time) within preset limits via the digital interface interface; customized units can be provided for unique arc prone environments, contact Spellman for details.

STA SELECTION TABLE

MAX	IMUM RATING	MODEL NUMBER
kV	mA	
1	4,000	STA1*4
2	2,000	STA2*4
3	1,333	STA3*4
4	1,000	STA4*4
6	667	STA6*4
8	500	STA8*4
10	400	STA10*4
12	333	STA12*4
15	267	STA15*4
20	200	STA20*4
30	133	STA30*4
40	100	STA40*4
50	80	STA50*4
60	67	STA60*4
70	57	STA70*4

^{*}Substitute "P" for positive polarity and "N" for negative polarity. Polarity must be specified at time of order.



STA rear panel shown with local operation plug installed in 50 pin D connector


PAGE 3 OF 3

JB1 STA ANALOG INTERFACE— 50 PIN FEMALE D CONNECTOR


PIN	SIGNAL	PARAMETERS
1	Power Supply Common	Power Supply Ground
2	Reset/HV Inhibit	Normally open, Low = Reset/Inhibit
3	External Interlock	+24Vdc @ open, <25mA @ closed
4	External Interlock Return	Return for External Interlock
5	mA Test Point	0-10Vdc = 0-100% rated output, Zout= 1KΩ, 1%
6	kV Test Point	0-10Vdc = 0-100% rated output, Zout= 1KΩ, 1%
7	+10Vdc Reference Output	+10Vdc @ 1mA
8	mA Program Input	$0-10Vdc = 0-100\%$ rated output, Zin> $10M\Omega$
9	Local mA Program Output	0-10Vdc = 0-100% rated output, front panel pot
10	kV Program Input	0-10Vdc = 0-100% rated output, Zin>10MΩ
11	Local kV Program Output	0-10Vdc = 0-100% rated output, front panel pot
12	Remote Power On Output	+24Vdc @ open, 2A peak, 1Adc @ closed
13	Remote Power On Return	Return for Remote Power On
14	Remote HV Off	+24Vdc @ open, 2A peak, 1Adc @ closed,
		connect to pin15 for front panel operation
15	Remote HV Off/On Common	HV On/Off Common
16	Remote HV On	+24Vdc @ open, 2A peak, 1Adc @ closed,
17	HV Off Indicator	momentarily connect to pin 15 enable high voltage +24Vdc @ 25mA = HV Off
17	HV On Indicator	+24Vdc @ 25mA = HV On
19	Power Supply Common	
20	+24Vdc Output	Supply Ground +24Vdc @ 100mA, maximum
21	Voltage Mode Status	Open Collector, Low = Active
22	Current Mode Status	Open Collector, Low = Active
23	Power Mode Status	Open Collector, Low = Active
24	Interlock Closed Status	Open Collector, Low = Active
25	Power Test Point	0-10Vdc = 0-100% rated output, Zout= $5KΩ$, 1%
26	Spare	0 10 vac = 0 100 % rated output, 20at = 01\(\text{x2}\), 170
27	Spare	
28	Remote Overvoltage Adjust	0-10Vdc = 0-100% rated output
29	Over Power Fault	Open Collector, Low = Active
30	Over Voltage Fault	Open Collector, Low = Active
31	Over Current Fault	Open Collector, Low = Active
32	System Fault	Open Collector, Low = Active
33	RGLT Error Fault	Open Collector, Low = Active
34	Arc	Open Collector, Low = Active
35	Over Temp Fault	Open Collector, Low = Active
36	AC Fault	Open Collector, Low = Active
37	Spare	
38	Spare	
39	Spare	
40	Spare	
41	Spare	
42	Remote Power Program Input	0-10Vdc = 0-100% rated output, Zin>10MΩ
43	Local Power Program Output	0-10Vdc = 0-100% rated output, internal pot
44	+5Vdc Output	+5Vdc @ 100mA, maximum
45	+15Vdc Output	+15Vdc @ 100mA, maximum
46	-15Vdc Output	-15Vdc @ 10mA, maximum
47	RS232 Tx	
48	RS232 Rx	
49	RS232 GND	
50	Power Supply Common	Power Supply Ground

DIMENSIONS: in.[mm]


FRONT VIEW



TOP VIEW



BACK VIEW






Corporate Headquarters

Hauppauge, New York USA







- Models from 1kV to 150kV
- Remote Analog and Remote Ethernet Interface
- Arc and Short Circuit Protected
- Customer Configurable Features Via Ethernet Interface
- OEM Customization Available

Spellman's STR Series of 6kW high voltage power supplies are available in positive or negative polarities in 19 different models with outputs ranging from 1kV to 150kV. A full featured front panel allows easy local control, while an extensive analog interface provides comprehensive remote capability. The standard Ethernet and RS-232 digital interfaces simplify integrating the STR into your system design.

The STR's robust IGBT inverter is inherently fault tolerant and is ideal for demanding applications like semiconductor processing and vacuum deposition. Many operational features can be configured by the user to suit their particular requirements.

TYPICAL APPLICATIONS

Ion Beam Implantation Semiconductor Processing Electron Beam Welding Capacitor Charging High Power RF Transmitters Electrostatic Precipitators X-Ray Systems

HARDWARE BASED OPTIONS

BFP Blank Front Panel HS High Stability

LL(X) High Voltage Cable Length 400VAC 360-528Vac, Three Phase Input 1PH 180-264Vac, Single Phase Input

SOFTWARE CONFIGURABLE FEATURES

Adjustable Overload Trip Arc Trip Count Arc Quench Time Arc Re-Ramp Time Constant Power Control Adjustable Power Trip Slow Start Ramp Times

SPECIFICATIONS

Input Voltage:

180-264Vac. 50/60Hz. three phase. Standard:

90% efficiency, 0.85 power factor

360-528Vac 50/60Hz, three phase (400VAC) Optional:

180-264Vac 50/60Hz, single phase (1PH)

Input Current:

Standard: 180-264Vac, three phase 25 amps, maximum Optional: 360-528Vac, three phase 12.5 amps, maximum 180-264Vac, single phase 57 amps, maximum

Output Voltage:

19 models from 1kV to 150kV. Each model is available with positive or negative outputs. 1kV to 10kV units are internally reversible.

Local Output Controls:

Voltage and current are continuously adjustable over entire range via ten-turn potentiometers with lockable counting dials.

Voltage Regulation:

Load: 0.05% of full voltage +500mV for full load change. 0.05% of full voltage +500mV over specified input range. Line:

Current Regulation:

Load: 0.05% of full current ±100µA for any voltage change. Line: 0.05% of full current over specified input range.

Ripple:

0.1% p-p +1Vrms

Stability:

0.02%hr. after 1 hour warm-up.

Temperature Coefficient:

100ppm/°C. Higher stability (50ppm/°C) available on special order via the HS option

Environmental:

Temperature Range: Operating: 0°C to 40°C Storage: -40°C to 85°C Humidity:

10% to 90% RH, non-condensing

Cooling:

Forced air; inlet through side panels, outlet at rear panel

Metering:

Corporate Headquarters

Digital voltage and current meters, accurate to within 1%

System Status Display:

"Dead Front" type indicators provide status of up to 12 system operations including voltage and current regulation, fault conditions and circuit control.



Analog Interface Connector:

50 pin female D connector

High Voltage Output Cable:

A detachable 10' (3.05m) long shielded HV cable is provided

Dimensions:

1kV to 120kV:

10.5" (6U)H X 19" W X 21" D (266mm x 482mm x 533mm) 150kV:

10.5" (6U)H X 19" W X 23" D (266mm x 482mm x 584mm)

Weight:

1kV to 50kV: <100 pounds (45.36kg) 60kV to 120kV: <140 pounds (63.50kg) 150kV: <150 pounds (68kg) Individual kV models may vary

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

STR series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The STR series is not intended to be operated by end users as a stand-alone device. The STR series power supply can only be fully assessed when installed within a system, and as a component part within that system.

STR SELECTION TABLE

MAXIMUM RATING		MODEL NUMBER
kV	mA	
1	6,000	STR1*6
2	3,000	STR2*6
3	2,000	STR3*6
4	1,500	STR4*6
6	1,000	STR6*6
8	750	STR8*6
10	600	STR10*6
12	500	STR12*6
15	400	STR15*6
20	300	STR20*6
30	200	STR30*6
40	150	STR40*6
50	120	STR50*6
60	100	STR60*6
70	86	STR70*6
80	75	STR80*6
100	60	STR100*6
120	50	STR120*6
150	40	STR150*6

^{*}Substitute "P" for positive polarity and "N" for negative polarity. Polarity must be specified at time of order.

Digital Interface

The STR features a standard RS-232 and Ethernet digital interface. Utilizing these standard digital interfaces can dramatically simplify power supply interfacing requirements saving the user both time and money, while enhancing functionality and overall capability. Spellman provides a GUI with the STR that allows the customer to both customize operational features of the STR while also providing basic power supply operational features. Details of the STR's digital interface capability are described in the STR manual, downloadable via the link on the first page of this data sheet.



Main control screen



Status screen



User configuration screen

Arc Intervention

Spellman's STR power supplies have an arc intervention feature that senses arc currents via a fast acting current sense transformer. The purpose of the arc intervention circuitry is to prevent power supply damage from continuous, long term arcing. The factory default configuration will trip off the unit with an Arc Fault if 4 arcs occur in a 10 second time period. Customers can change basic arc intervention parameters (Arc Count, Arc Quench, Reramp Time, and Window Time) within preset limits via the digital interface interface; customized units can be provided for unique arc prone environments, contact Spellman for details.



STR rear panel view

Hauppauge, New York USA

Corporate Headquarters


¹⁻¹⁰kV units are inherently reversible by design requiring an internal wiring change to swap polarities. Intermediate voltage units are available by special order.


PAGE 3 OF 3

JB1 STR ANALOG INTERFACE— 50 PIN FEMALE D CONNECTOR

	OLONIAL	DADAMETERS
PIN		PARAMETERS
1	Power Supply Common	Power Supply Ground
2	Reset/HV Inhibit	Normally open, Low = Reset/Inhibit
3	External Interlock	+24Vdc @ open, <25mA @ closed
4	External Interlock Return	Return for External Interlock
5	mA Test Point	0-10Vdc = 0-100% rated output, Zout= $1K\Omega$, 1%
6	kV Test Point	0-10Vdc = 0-100% rated output, Zout= 1KΩ, 1%
7	+10Vdc Reference Output	+10Vdc @ 1mA
8	mA Program Input	0-10Vdc = 0-100% rated output, Zin>10MΩ
9	Local mA Program Output	0-10Vdc = 0-100% rated output, front panel pot
10	kV Program Input	0-10Vdc = 0-100% rated output, Zin>10MΩ
11	Local kV Program Output	0-10Vdc = 0-100% rated output, front panel pot
12	Remote Power On Output	+24Vdc @ open, 2A peak, 1Adc @ closed
13	Remote Power On Return	Return for Remote Power On
14	Remote HV Off	+24Vdc @ open, 2A peak, 1Adc @ closed,
Ш		connect to pin15 for front panel operation
15	Remote HV Off/On Common	HV On/Off Common
16	Remote HV On	+24Vdc @ open, 2A peak, 1Adc @ closed,
47	10/06/1	momentarily connect to pin 15 enable high voltage
17	HV Off Indicator	+24Vdc @ 25mA = HV Off
18	HV On Indicator	+24Vdc @ 25mA = HV On
19	Power Supply Common	Supply Ground
20	+24Vdc Output	+24Vdc @ 100mA, maximum
21	Voltage Mode Status	Open Collector, Low = Active
22	Current Mode Status	Open Collector, Low = Active
23	Power Mode Status	Open Collector, Low = Active
24	Interlock Closed Status	Open Collector, Low = Active
25	Power Test Point	0-10Vdc = 0-100% rated output, Zout= 5KΩ, 1%
26	Spare	
27	Spare	
28	Remote Overvoltage Adjust	0-10Vdc = 0-100% rated output
29	Over Power Fault	Open Collector, Low = Active
30	Over Voltage Fault	Open Collector, Low = Active
31	Over Current Fault	Open Collector, Low = Active
32	System Fault	Open Collector, Low = Active
33	RGLT Error Fault	Open Collector, Low = Active
34	Arc	Open Collector, Low = Active
35	Over Temp Fault	Open Collector, Low = Active
36	AC Fault	Open Collector, Low = Active
37	Spare	
38	Spare	
39	Spare	
40	Spare	
41	Spare	
42	Remote Power Program Input	0-10Vdc = 0-100% rated output, Zin>10MΩ
43	Local Power Program Output	0-10Vdc = 0-100% rated output, internal pot
44	+5Vdc Output	+5Vdc @ 100mA, maximum
45	+15Vdc Output	+15Vdc @ 100mA, maximum
46	-15Vdc Output	-15Vdc @ 10mA, maximum
47	RS232 Tx	
48	RS232 Rx	
49	RS232 GND	
50	Power Supply Common	Power Supply Ground

DIMENSIONS: in.[mm] FRONT VIEW















Spellman's ST Series of 12kW high voltage power supplies are available in positive or negative polarities in 20 different models with outputs ranging from 1kV to 225kV. A full featured front panel allows easy local control, while an extensive analog interface provides comprehensive remote capability. The standard Ethernet and RS-232 digital interfaces simplify integrating the ST into your system design.

The ST's robust IGBT inverter is inherently fault tolerant and is ideal for demanding applications like semiconductor processing and vacuum deposition. Many operational features can be configured by the user to suit their particular requirements. Power >100kW's can be provided by configuring additional chassis in parallel.

TYPICAL APPLICATIONS

Ion Beam Implantation Semiconductor Processing Electron Beam Welding Capacitor Charging High Power RF Transmitters Electrostatic Precipitators X-Ray Systems

HARDWARE BASED OPTIONS

BFP Blank Front Panel High Stability

LL(X) High Voltage Cable Length

400VAC 360-528Vac Input

SOFTWARE CONFIGURABLE FEATURES

Adjustable Overload Trip Arc Trip Count Arc Quench Time Arc Re-Ramp Time Constant Power Control Adjustable Power Trip Slow Start Ramp Times

• 12kW's in Single 6U (10.5") Chassis

- Models from 1kV to 225kV
- Remote Analog and Remote Ethernet Interface
- Parallel Units for >100kW's
- Arc and Short Circuit Protected
- Customer Configurable Features
 Via Ethernet Interface
- OEM Customization Available

SPECIFICATIONS

Input Voltage:

Standard: 180-264Vac, 50/60Hz, three phase,

90% efficiency, 0.85 power factor

Optional: 360-528Vac 50/60Hz, three phase (400Vac)

Input Current:

Standard: 180-264Vac, three phase; 50 amps, maximum Optional: 360-528Vac, three phase; 25 amps, maximum

Output Voltage:

20 models from 1kV to 225kV. Each model is available with positive or negative outputs. 1kV to 10kV units are internally reversible.

Local Output Controls:

Voltage and current are continuously adjustable over entire range via ten-turn potentiometers with lockable counting dials.

Voltage Regulation:

Load: 0.05% of full voltage +500mV for full load change. Line: 0.05% of full voltage +500mV over specified

input range.

Current Regulation:

Load: 0.05% of full current $\pm 100\mu A$ for any voltage change. Line: 0.05% of full current over specified input range.

Ripple:

0.3% p-p +1Vrms. Lower ripple available via special order

Stability:

0.02%hr. after 1 hour warm-up.

Temperature Coefficient:

100ppm/°C. Higher stability (50ppm/°C) available on special order via the HS option

Environmental:

Temperature Range: Operating: 0°C to 40°C Storage: -40°C to 85°C Humidity:

10% to 90% RH, non-condensing.

Cooling:

Forced air; inlet through side panels, outlet at rear panel

Meterina:

Digital voltage and current meters, accurate to within 1%

System Status Display:

"Dead Front" type indicators provide status of up to 12 system operations including voltage and current regulation, fault conditions and circuit control.

Input Line Connector:

A 6 foot (1.8 meter) long captive line cord is provided.





Analog Interface Connector:

50 pin female D connector

High Voltage Output Cable:

1-150kV: A detachable 10' (3.05m) long shielded

HV cable is provided

225kV: R-28 type X-Ray connector.

No output cable is provided

Dimensions:

1kV to 120kV:

10.5" (6U)H X 19" W X 21" D (266mm x 482mm x 533mm)

10.5" (6U)H X 19" W X 23" D (266mm x 482mm x 584mm) 225kV:

20.55" H X 17.01" W X 29.7" D (521mm x 432mm x 754mm)

Weight:

1kV to 50kV: <100 pounds (45.36kg) 60kV to 120kV: <140 pounds (63.50kg) 150kV: <150 pounds (68.03kg) 225kV: <260 pounds (117.9kg) Individual kV models may vary

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

ST series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The ST series is not intended to be operated by end users as a stand-alone device. The ST series power supply can only be fully assessed when installed within a system, and as a component part within that system.

Parallel Capability

The ST series is designed to offer additional power capability by adding a chassis in parallel to create a main/secondary configuration providing up to and beyond 100kW's. The main chassis is the point of connection for customer interfacing; this multichassis system effectively functions as a single power supply. The main unit retains the full featured front panel, while secondary units have a Blank Front Panel. To configure an orderable model number, simply use Spellman's applicable base ST model number and increment the power denominator in 12kW steps as required:

ST60P24 This would be an ST with a 60kV, positive polarity, providing 24kW's of power (2 chassis)



Rear panel showing connections for parallel operation



Main/secondary 24kW ST

Digital Interface

The ST features a standard RS-232 and Ethernet digital interface. Utilizing these standard digital interfaces can dramatically simplify power supply interfacing requirements saving the user both time and money, while enhancing functionality and overall capability. Spellman provides a GUI with the ST that allows the customer to both customize operational features of the ST while also providing basic power supply operational features. Details of the ST's digital interface capability are described in the ST manual, downloadable via the link on the first page of this data sheet.



Main control screen



Status screen



User configuration screen

Arc Intervention

Spellman's ST power supplies have an arc intervention feature that senses arc currents via a fast acting current sense transformer. The purpose of the arc intervention circuitry is to prevent power supply damage from continuous, long term arcing. The factory default configuration will trip off the unit with an Arc Fault if 4 arcs occur in a 10 second time period. Customers can change basic arc intervention parameters (Arc Count, Arc Quench, Reramp Time, and Window Time) within preset limits via the digital interface interface; customized units can be provided for unique arc prone environments, contact Spellman for details.



ST SELECTION TABLE

MAXIMU	M RATING	MODEL NUMBER
kV	mA	
1	12,000	ST1*12
2	6,000	ST2*12
3	4,000	ST3*12
4	3,000	ST4*12
6	2,000	ST6*12
8	1,500	ST8*12
10	1,200	ST10*12
12	1,000	ST12*12
15	800	ST15*12
20	600	ST20*12
30	400	ST30*12
40	300	ST40*12
50	240	ST50*12
60	200	ST60*12
70	171	ST70*12
80	150	ST80*12
100	120	ST100*12
120	100	ST120*12
150	67	ST150*10
225	40	ST225*10

^{*}Substitute "P" for positive polarity and "N" for negative polarity. Polarity must be specified at time of order. 1-10kV units are inherently reversible by design requiring an

NOTE: ST225 units cannot be paralled!

Parallel operation:

Additional power can be provided in increments of 12kW's by connecting chassis in parallel via the use of the ST's main/secondary configuration.

Use the applicable base ST model number and increment the power denominated in 12kW steps as required.

ST10P24 10kV @ 24kW's ST10P36 10kV @ 36kW's ST10P48 10kV @ 48kW's



JB1 ST ANALOG INTERFACE— **50 PIN FEMALE D CONNECTOR**

PIN	SIGNAL	PARAMETERS
1	Power Supply Common	Power Supply Ground
2	Reset/HV Inhibit	Normally open, Low = Reset/Inhibit
3	External Interlock	+24Vdc @ open, <25mA @ closed
4	External Interlock Return	Return for External Interlock
5	mA Test Point	0-10Vdc = 0-100% rated output, Zout= 1K Ω , 1%
6	kV Test Point	0-10Vdc = $0-100$ % rated output, Zout= 1 KΩ, 1% $0-10$ Vdc = $0-100$ % rated output, Zout= 1 KΩ, 1%
7	+10Vdc Reference Output	+10Vdc @ 1mA
8	mA Program Input	0-10Vdc = 0-100% rated output, Zin>10MΩ
9	Local mA Program Output	0-10Vdc = 0-100% rated output, front panel pot
10	kV Program Input	$0-10$ Vdc = $0-100\%$ rated output, from panel por $0-10$ Vdc = $0-100\%$ rated output, Zin> 10 M Ω
11	Local kV Program Output	0-10Vdc = 0-100% rated output, front panel pot
12	Remote Power On Output	+24Vdc @ open, 2A peak, 1Adc @ closed
13	Remote Power On Return	Return for Remote Power On
14	Remote HV Off	+24Vdc @ open, 2A peak, 1Adc @ closed,
	Hemote IIV On	connect to pin15 for front panel operation
15	Remote HV Off/On Common	HV On/Off Common
16	Remote HV On	+24Vdc @ open, 2A peak, 1Adc @ closed,
		momentarily connect to pin 15 enable high voltage
17	HV Off Indicator	+24Vdc @ 25mA = HV Off
18	HV On Indicator	+24Vdc @ 25mA = HV On
19	Power Supply Common	Supply Ground
20	+24Vdc Output	+24Vdc @ 100mA, maximum
21	Voltage Mode Status	Open Collector, Low = Active
22	Current Mode Status	Open Collector, Low = Active
23	Power Mode Status	Open Collector, Low = Active
24	Interlock Closed Status	Open Collector, Low = Active
25	Power Test Point	0-10Vdc = 0-100% rated output, Zout= 5KΩ, 1%
26	Spare	
27	Spare	
28	Remote Overvoltage Adjust	0-10Vdc = 0-100% rated output
29	Over Power Fault	Open Collector, Low = Active
30	Over Voltage Fault	Open Collector, Low = Active
31	Over Current Fault	Open Collector, Low = Active
32	System Fault	Open Collector, Low = Active
33	RGLT Error Fault	Open Collector, Low = Active
34	Arc	Open Collector, Low = Active
35	Over Temp Fault	Open Collector, Low = Active
36	AC Fault	Open Collector, Low = Active
37	Spare	
38	Spare	
39	Spare	
40	Spare	
41	Spare	0.40\/ 0.4000/ 1.1 7/ 121.12
42	Remote Power Program Input	0-10Vdc = 0-100% rated output, Zin>10MΩ
43	Local Power Program Output	0-10Vdc = 0-100% rated output, internal pot
44	+5Vdc Output	+5Vdc @ 100mA, maximum
45	+15Vdc Output	+15Vdc @ 100mA, maximum
46	-15Vdc Output	-15Vdc @ 10mA, maximum
47	RS232 Tx	
48	RS232 Rx	
49	RS232 GND	Davier Cupply Cround
50	Power Supply Common	Power Supply Ground

Corporate Headquarters


internal wiring change to swap polarities. Intermediate voltage units are available by special order. 150kV and 225kV units are limited to a maximum output of 10kW's




DIMENSIONS: in.[mm]

FRONT VIEW


ST 1kV-150kV



TOP VIEW



BACK VIEW









PAGE 5 OF 5

ST 225kV




SIDE VIEW



FRONT VIEW

REAR VIEW



Corporate Headquarters



NOTE: Blank front panel on ST 225kV units

www.spellmanhv.com

PAGE 1 OF 2



Spellman's XLG Series of X-Ray generators are well regulated high voltage power supplies with output voltages to 130kV and very low ripple achieved through the use of advanced resonant conversion techniques. Extremely stable voltage and emission current outputs result in significant performance improvements over previously available technology. The XLG Series provides all the power, control and support functions required for X-Ray applications including a regulated dc filament supply. These units incorporate local and remote programming, monitoring, safety interlock, short-circuit and overload protection.

TYPICAL APPLICATIONS

Plating Measurement Mineral Analysis X-Ray Fluorescence

OPTIONS

APT Adjustable Power Trip

AT Arc Trip

SS(x) Non-Standard Slow Start

NSS No Slow Start IO Instant ON

LL(x) Extra Length HV Cable

SL Slides

FRONT PANEL STATUS INDICATORS:

Overvoltage Voltage Control Mode
Overtemperature Current Control Mode
Regulation Error Interlock Open
Arc Interlock Closed
HV ON: Red HV OFF: Green

SPECIFICATIONS

Input Voltage:

115Vac±10%, 50-60Hz single phase or 220Vac±10%, 50-60Hz single phase. For input current see table on page 2.

Voltage and Current Control:

Local: continuously adjustable from zero to maximum rating via a ten-turn potentiometer with a lockable

counting dial.

Remote: 0 to +10Vdc proportional from 0 to full output. Accuracy: ±1%. Input Impedance: 10Mohm. Output Voltages to 130kV

Integrated Ground Referenced Filament Supply

Low Ripple

"Hot Anode"

Positive Polarity

Local & Remote Programming

OEM Customization Available

Filament:

Specify at time of order:

FH: 9A, 3V. FL: 3A, 3V.

Preheat level is 0.45 amps in standby

Voltage Regulation:

Load: 0.005% of full output voltage no load to full load. Line: 0.005% for input voltage range change.

Current Regulation:

Load: 0.05% of full current $\pm 100\mu A$ from 0 to full voltage. Line: 0.05% of rated current over specified input range.

Ripple

0.03% rms below 1kHz. 0.75% rms above 1kHz.

Temperature Coefficient:

100ppm/°C.

Stability:

0.01%/8 hrs after 1/2 hour warm-up. 0.02% per 8 hours (typical).

Cooling:

Free air convection.

Metering:

Digital voltage and current meters (3.5 digits), 1% accuracy.

HV Output Cable:

10' (3.3m) of shielded HV cable removable at rear.

I/O Connectors:

25 pin D-type for control interface with mating connector provided.

Dimensions:

30 to 60kV:

3.5"H x 19"W x 19"D (8.9cm x 48.3cm x 48.3cm).

80 to 130kV:

3.5"H x 19"W x 24"D (8.9cm x 48.3cm x 61.0cm).

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

XLG series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The XLG series is not intended to be operated by end users as a stand-alone device. The XLG series power supply can only be fully assessed when installed within a system, and as a component part within that system.





PAGE 2 OF 2

XLG INPUT CURRENT

MODEL	115Vac	220Vac
3W-30W	0.6A	0.3125A
40W-60W	1.2A	0.625A
70W-150W	3.0A	1.56A
160W-260W	5.25A	2.71A

XLG SELECTION TABLE 0.1mA, 0.2mA, 0.5mA

	kV	0.1mA	0.2mA	.5mA
l	30	XLG30P3*	XLG30P6*	XLG30P15*
1	35	XLG35P3.5*	XLG35P7*	XLG35P17.5*
	40	XLG40P4*	XLG40P8*	XLG40P20*
	50	XLG50P5*	XLG50P10*	XLG50P25*
1	60	XLG60P6*	XLG60P12*	XLG60P30*
	80	XLG80P8*	XLG80P16*	XLG80P40*
	100	XLG100P10*	XLG100P20*	XLG100P50*
1	120	XLG120P12*	XLG120P24*	XLG120P60*
	130	XLG130P13*	XLG130P26*	XLG130P65*

^{*}Specify FH for High power (27W) filament, FL for Low power (9W) filament.

XLG SELECTION TABLE 1.0mA, 2.0mA, 3.0mA


	kV	1.0mA	2.0mA	3.0mA
	30	XLG30P30*	XLG30P60*	XLG30P90*
ı	35	XLG35P35*	XLG35P70*	XLG35P105*
	40	XLG40P40*	XLG40P80*	XLG40P120*
	50	XLG50P50*	XLG50P100*	XLG50P150*
	60	XLG60P60*	XLG60P120*	XLG60P180*
	80	XLG80P80*	XLG80P160*	
	100	XLG100P100*	XLG100P200*	
	120	XLG120P120*	XLG120P240*	
	130	XLG130P130*	XLG130P260*	


^{*}Specify FH for High power (27W) filament, FL for Low power (9W) filament.

XLG CONNECTOR 25 PIN


PIN	SIGNAL	SIGNAL PARAMETERS
1	Power Supply Common	Signal Ground
2	External Inhibit	Ground=Inhibit, Open=HV On
3	External Interlock	+15V at Open, <15mA at Closed
4	External Interlock Return	Return for Interlock
5	Current Monitor	0 to 10V=0 to 100% Rated Output
6	kV Test Point	0 to 10V=0 to 100% Rated Output
7	+10V Reference	+10V, 1mA Max
8	Remote Current Program In	0 to 10V=0 to 100% Rated Output
9	Local Current Program Out	Front Panel Program Voltage
10	Remote Voltage Program In	0 to 10V=0 to 100% Rated Output
11	Local Voltage Program Out	Front Panel Program Voltage
12	Power Monitor	0 to 10V=0 to 100% Rated Output
13	Remote Power Program In	(Optional)
14	Local HV Off Out	+15V at Open, <25mA at Closed
15	HV Off	Connect to HV OFF for Fp Operation
16	Remote HV On	+15V, 10mA Max=HV Off
17	Remote HV Off Indicator	0=HV On, +15V, 10mA Max=HV Off
18	Remote HV On Indicator	0=HV Off, +15V, 10mA Max=HV On
19	Remote Voltage Mode	Open Collector FOV May, 10mA May
20	Remote Current Mode	Open Collector 50V Max, 10mA Max On=Active
21	Remote Power Mode	On=Active
22	Remote PS Fault	0=Fault, +15V, 0.1mA Max=No Fault
23	+15V Output	+15V, 100mA Max
24	Power Supply Common	Signal Ground
25	Shield Return	Shield Return

DIMENSIONS: in.[mm]





BACK VIEW







Corporate Headquarters





The XMPF is a modular 10kV @ 5W X-Ray generator designed to drive a floating filament X-Ray tube via closed loop filamentary control of the 0 to 500uA emission current. The floating filament supply is rated at 0 to 0.42 amps @ 3.5Vac. The filament supply features an adjustable 0 to 0.42 amp filament limit.

The high voltage program and emission current program have internal preset capability simplify interfacing to this X-Ray generator. Alternatively, a customer provided 0 to 10Vdc signal can be used to remotely control these two signals. A high voltage monitor signal and emission current monitor signal is provided. Additionally a filament current monitor signal is also provided. A High Voltage Enable input provides control the high voltage output.

SPECIFICATIONS

Input Voltage:

+24 Vdc, ±10%

Input Current:

500mA maximum

Cathode Supply:

Voltage: 10kV, controllable over the range -20V to -10kV

Accuracy: <2% Polarity: Negative

Line Regulation: <0.05% for input voltage change of $\pm 10\%$

Load Regulation: <0.1% for zero to full load

Stability: <0.1% per 24 hours at constant operating conditions, after 30 minutes warm up

Temperature Coefficient: <250 ppm/°C

Ripple: <0.01% p-p of output voltage at full voltage

and current

Output Current Limit: 550µA ±10%

Ramp Rate: <20kV/sec

Output Voltage -20V to -10kV

- Integrated Floating Filament Supply
- Low Ripple
- Local and Remote Programming
- OEM Customization Available

Current Characteristics:

Maximum Emission Current: 500uA

Stability: 0.5% using the internal reference and setting potentiometer. For increased stability an external reference can be used.

Filament Supply:

Voltage: 0V to 3.5Vac referenced to Cathode output Load Current: 0.42A max, pre set adjustable limit Stability: <0.1% over a 30 minute period at constant operating conditions.

Environmental:

Temperature Range:

Operating: 5°C to 40°C Storage: -40°C to 70°C

Humidity:

Operating: 20% to 80% RH, non-condensing

Storage: 5% to 95%

High Voltage Output:

Flying leads, Reynolds 18kV rated FEP insulated wire, 1.02mm diameter. Conductors are 19/40 AWG. Overall length is 500mm, the two wires are sleeved together.

Dimensions:

1.18"H x 2.75"W x 6.69"D (30mm x 70mm x 170mm)

Weight:

4.4 lbs. (2.0kg)

Regulatory Approvals:

Designed to meet IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. RoHS compliant.

As the unit is designed for incorporation within the users system it is not tested against any specific EMC standards. The user will need to take sensible EMC precautions when designing the unit in and verify the overall system EMC performance against any relevant standards.





CUSTOMER INTERFACE— 15 PIN MALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	+24Vdc	+24Vdc @ 500mA, max.
2	Power Ground	Power Ground
3	N/C	N/C
4	Signal Ground	Signal Ground
5	HV Enable	0-0.8V = HV ON, 2.4V-12V = HV OFF
6	N/C	N/C
7	HV Program Output	0-10V from pre-set potentiometer. See note below.
8	HV Program Input	0-10Vdc = 0-10kV, Zin = 470kΩ, accuracy $\pm 2\%$ of FS
9	High Voltage Monitor	0-10Vdc = 0-10kV, Zout = $2.2k\Omega$, accuracy ±2% of FS
10	Emission Current Monitor	0-10Vdc = 0-500uA, Zout = $2.2k\Omega$, accuracy ±3% of FS
11	Filament Current Monitor	0-10Vdc = 0-500mA, Zout = $2.2k\Omega$, accuracy ±5% of FS
12	Emission Current Program Input	0-10Vdc = 0-500uA, Zin = 10M Ω , accuracy ±3% of FS
13	Emission Current Program Output	0-10V from pre-set potentiometer. See note below.
14	Signal Ground	Signal Ground
15	Filament Current Limit	0-10V = 0-0.42A from pre-set potentiometer. See note below.

The pre-set potentiometers are accessible through the side of the case. To pre-set the filament current limit, adjust the potentiometer (indicated "Preset fil max" on the case).

If external programming is not required:


To pre-set the HV, adjust the potentiometer (indicated RV4 on the case) to desired value, and link pins 7 and 8.


To pre-set the emission current, adjust the potentiometer (RV3), and link pins 12 and 13.

How To Order: Model number: XMPF10N5/24




FRONT VIEW






SIDE VIEW



BOTTOM VIEW





Corporate Headquarters

Hauppauge, New York USA





The XMPG is a modular 10kV @ 10W X-Ray generator designed to drive a grounded filament X-Ray tube via closed loop filamentary control of the 0 to 1mA emission current. The grounded filament supply is rated at 0-5 amps @ 3Vdc. The filament supply features an internally adjustable 0.5 to 2.5 amp filament preheat and a internally adjustable 0 to 5 amp filament limit.

The high voltage program and emission current program have internal preset capability simplify interfacing to this X-Ray generator. Or a customer provided 0 to 10Vdc signal can be used to remotely control these two signals. A high voltage monitor signal and emission current monitor signal is provided. A High Voltage Enable input provides control of the high voltage output and a Filament Stable output indicates the filament current is stable and the X-Ray tube is producing X-Rays.

SPECIFICATIONS

Input Voltage:

+24 Vdc, ±10%

Input Current:

2 amp maximum

Output Voltage:

10kV, controllable over the range 4kV to 10kV

Voltage Accuracy:

<2%

Polarity:

Positive

Voltage Regulation:

Line: <0.01% for input voltage change of ±10%

Load: <0.01% for zero to full load

Voltage Stability:

< 0.1% per 24 hours at constant operating conditions, after 30 minutes warm up

Ripple:

< 500mV p-p of output voltage at full load

Ramp Rate:

< 20kV/second

Temperature Coefficient:

<250ppm per degree C

Output Voltage 4kV to 10kV

- Integrated Ground Referenced Filament Supply
- Low Ripple
- Local and Remote Programming
- OEM Customization Available

Current Regulation:

Line: ≤0.01% for 10% input voltage change under

any load conditions

Load: ≤0.01% for full load to short circuit

Emission Current:

0-1mA

Current Accuracy:

<1% (above 10% of maximum output current)

Current Stability:

< 0.02%

Environmental:

Temperature Range:

Operating: 5°C to 40°C Storage: -40°C to 70°C

Humidity:

Operating: 20% to 80% RH, non-condensing

Storage: 5% to 95%

Filament Supply:

Voltage: 0V to 3Vdc referenced to ground Load Current: 5A max, preset adjustable limit

Stability: < 0.25% per 8 hours at constant operating conditions

Ripple: <50mV p-p (at maximum load current). Temperature Coefficient: <300ppm/°C

Filament Output:

A captive 500mm long unterminated 16 AWG twisted wire pair is provided.

High Voltage Output:

A captive 500mm long unterminated length of URM76 shielded cable

A red High Voltage On LED is provided next to the high voltage output to indicate that high voltage is being produced by the unit

Dimensions:

1.31"H x 4.13"W x 7.28"D (33.5mm x 105mm x 185mm)

Weight:

4.4 lbs. (2.0kg)

Regulatory Approvals:

Designed to meet IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. RoHS compliant.

As the unit is designed for incorporation within the users system it is not tested against any specific EMC standards. The user will need to take sensible EMC precautions when designing the unit in and verify the overall system EMC performance against any relevant standards.



FILAMENT OUTPUT

COLOR	NAME
Red	Filament +
Black	Filament -

CUSTOMER INTERFACE— 15 PIN MALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	+24Vdc	+24Vdc
2	Ground	Ground
3	Preheat (set value)	0-5Vdc from internal preset
4	Test (Filament Current Direct Program)	Do not connect
5	HV Enable	Digital Input
6	Filament Stable	Digital Output
7	HV Program Output	0-10Vdc from Internal Preset
8	HV Program Input	0-10Vdc = 0-10kV, Zin = $5M\Omega$, accuracy ±2% of full scale
9	High Voltage Monitor	0-10Vdc = 0-10kV, Zout = 10kΩ, accuracy ±2% of full scale
10	Emission Current Monitor	$0-10Vdc = 0-1mA$, $Zout = 10kΩ$, accuracy $\pm 3\%$ of full scale
11	Filament Current Monitor	0-10Vdc = 0-5A, Zout = $2.2kΩ$, accuracy ±5% of full scale
12	Emission Current Program Input	0-10Vdc = 0-1mA, Zin = $1MΩ$, accuracy ±3% of full scale
13	Emission Current Program Output	0-10Vdc from Internal Preset
14	Ground	Ground
15	Preset Max. Filament Current (set value)	0-10Vdc from Internal Preset

The filament Preheat level and current limit are set by internal preset potentiometers accessible through the side of the case.

If external high voltage enable control is not required link pins 7 and 8. If external emission current control is not required link pins 12 and 13.

How	To	Ordor:


Model number: XMPG10P10/24

DIMENSIONS: in.[mm]


FRONT VIEW




TOP VIEW



BOTTOM VIEW



SIDE VIEW







71

PAGE 1 OF 3







The MNX Series is the result of Spellman's exceptional high voltage packaging and surface mount fabrication techniques coupled with proprietary encapsulation technology producing this ultra-compact X-Ray generator module. The MNX powers grounded cathode X-Ray tubes from a variety of well-known manufacturers, featuring a 0 to 50kV/65kV high voltage output @ 2mA limited to 50, 65 or 75 Watts. The MNX uses closed loop filament control circuitry providing highly regulated beam current. The ground referenced low noise dc filament supply operates between 0.3 and 3.5 amps. Offering tight regulation, high stability and low ripple, the MNX provides users local and remote analog control to set beam voltage, emission current and filament current limit.

TYPICAL APPLICATIONS

The MNX is designed to run a variety of tubes from industry leading manufacturers. Contact Spellman sales to determine if the X-Ray tube of interest can be powered by the MNX.

OPTIONS

XCC XRM Compatible HV Cable (50kV only) 5VPM 0 to 5 Volt Programming and Monitor Scaling 5302 Mammoflex HV cable for MNX

2001 Mammoflex HV cable for MNX w/XCC option

SPECIFICATIONS

Input Voltage:

+24Vdc $\pm 10\%$, for 50W or 75W units +24Vdc ±1V, for 65kV @ 65W unit

Input Current:

MNX50P50: 4.0 amps, maximum MNX50P75: 6.0 amps, maximum MNX65P65: 5.0 amps, maximum

GB Option: 1.0 amp additional, maximum

Efficiency:

80-85%, typical

0 to 50kV at 0 to 2mA, limited to a maximum of 50 watts or 75 Watts. 0-65kV at 2mA limited to 65 Watts.

Voltage Control:

Internal multi-turn potentiometer to set voltage Local:

from 0 to full output voltage.

Remote: 0 to +10Vdc proportional from 0 to full output voltage.

Accuracy: ±1%. Z_{IN}: 10Mohm.

Ask about our X-Ray subsystem capabilities

- 50kV at 2mA, 50 or 75 Watt Max
- 65kV at 2mA, 65 Watt Max
- Adjustable Integrated Filament Supply
- Arc & Short Circuit Protection
- Voltage & Current Programming
- Local and Remote Emission Control
- Safety Interlock
- OEM Customization Available
- CE Marked, UL Recognized

Emission Control:

Local: Internal potentiometer to set beam current

between 0 and full output current.

Remote: 0 to +10Vdc proportional from 0 to full output current. Accuracy: ±1%. Z_{IN}: 10Mohm. Filament limit and filament preheat control capability is also provided.

DC Filament Supply:

Current: 3.5A, adjustable limit

Voltage: 5.0 volt limit

Voltage Regulation:

Load: 0.01% of output voltage no load to full load. Line: ±0.01% for ±10% change in input voltage.

Current Regulation:

0.01% of output current from 0 to rated voltage. Load: Line: ±0.01% for ±10% change in input voltage.

Ripple:

0.1% p-p of maximum rated output voltage, 50kV units (50/75W) 0.1% rms maximum rated output voltage, 65kV units (65W)

Environmental:

Operational: 0°C to +50°C Storage: -40°C to +85°C

Humidity: 0% to 90%, non-condensing

Temperature Coefficient:

0.01% per °C, voltage and current.

Stability:

0.05% per 8 hours after 1/2 hour warm-up.

Voltage and Current Monitors:

0 to +10Vdc proportional from 0 to rated output. Accuracy ±1%.

Dimensions:

50kV Unit: 5.00"H x 2.87"W x 8"D

(127.00mm x 72.90mm x 203.25mm)

65kV Unit: 5.00"H x 2.87"W x 9"D

(127.00mm x 72.90mm x 228.65mm)

5.00"H x 2.87"W x 9"D (50/75W units only) XCC Option: (127.00mm x 72.90mm x 228.65mm)

Weight:

6.5 lbs. (2.9kg)

Regulatory Approvals:


Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588; MNX65P65 is not UL/CUL recognized. RoHS Compliant.







DIMENSIONS: in.[mm]

50kV 0 8.00 [203.25] 7.00 [177.60] M4X 7 BI IND .50 [12.70] **FASTENER** - 3.25 [82.55] TYP 4 PLCS



50kV with XCC Option





J2 POWER INPUT CONNECTOR

PIN	SIGNAL	PARAMETER
1	+24V Input	+24 volts @ 5A, max.
2	24V Return (Gnd.)	Power Ground

J3 FILAMENT CONNECTOR

PIN	SIGNAL	PARAMETER
1	Filament Out	0.3A to 3.5A, 5 volt, max.
2	Filament Return	Filament Ground

J4 ANALOG INTERFACE CONNECTOR MALE 15 PIN MINI "D"

PIN	SIGNAL	PARAMETER
1	Monitor Return	Signal Ground
2	Voltage Monitor	0-10 volts = 0 to full scale, Zout=1KΩ
3	Current Monitor	0-10 volts = 0 to full scale, Zout=1KΩ
4	Interlock Output	Connect 12V HVON bulb to pin 15 to enable
5	+10 Volt Reference	+10 Volts at 1mA, maximum
6	Filament Monitor	1 volt = 1 amp, Zout=1KΩ
7	Voltage Program Input	0-10 volts = 0 to full scale, Zin=10MΩ
8	Local Voltage Program*	0-10 volts, screwdriver adjust
9	Filament Limit Setpoint*	1 volt = 1 amp, screwdriver adjust
10	Current Program Input	0-10 volts = 0 to full scale, Zin=10MΩ
11	Local Current Program*	10 turn pot, screwdriver adjust
12	Not used (+24V Out for Interlock)	(Optional Interlock configuration)
13	Not used (Interlock Coil)	(Optional Interlock configuration)
14	Filament Preheat Setpoint*	1 volt = 1 amp, screwdriver adjust
15	Interlock Return	Interlock Ground

^{*}Denotes 10 turn potentiometer located on front panel

J1 HIGH VOLTAGE OUTPUT CONNECTOR

Spellman drywell type detachable connector.

Standard: A one meter (39.4") long polyethylene mating high

voltage cable is provided.

A one meter (39.4") long Mammoflex mating high voltage cable is provided, SHV p/n 201946-007 5302:

A one meter (39.4") long Mammoflex mating high voltage cable 2001:

is provided, compatible with the XCC Option SHV p/n 201946-002

Drywell connector depth:

50kV: 7.25 65kV: 8.25 XCC Option: 8.25°

How To Order:

Sample model number:

50 Watt unit: MNX50P50 65 Watt unit: MNX65P65 75 Watt unit: MNX50P75


Options are added to the model number as follows:


MNX50P50/XCC

Corporate Headquarters



DIMENSIONS: in.[mm]







Hauppauge, New York USA

e-mail: sales@spellmanhv.com

+1-631-630-3000 FAX: +1-631-435-1620

PAGE 1 OF 5



The uX Series is the result of Spellman's exceptional high voltage packaging and surface mount fabrication techniques coupled with proprietary encapsulation technology producing this ultra-compact X-Ray generator module. The uX powers grounded cathode X-Ray tubes from a variety of well-known manufacturers, featuring a 0 to 50kV/65kV high voltage output @ 2mA limited to 50, 65 or 75 Watts. The uX uses closed loop filament control circuitry providing highly regulated beam current. The low noise dc filament supply operates between 0.3 and 3.5 amps. Offering tight regulation, high stability and low ripple, the uX provides users local and remote analog control to set beam voltage, emission current and filament current limit, USB, RS-232 and Ethernet interface is standard.

TYPICAL APPLICATIONS

The uX is designed to run a variety of tubes from industry leading manufacturers. Contact Spellman sales to determine if the X-Ray tube of interest can be powered by the uX.

OPTIONS

XCC XRM Compatible HV Cable (50kV only) 5VPM 0 to 5 Volt Programming and Monitor Scaling

GB Grid Bias

GF Grounded Filament

5302 Mammoflex HV cable for uX

2001 Mammoflex HV cable for uX w/XCC option

SPECIFICATIONS

Input:

+24Vdc ±10%, 5.0A maximum for either 50 Watts or 75 Watts. +24Vdc ±1V, 5.0A maximum for 65kV/65W units.

Efficiency:

75%, typical

Output:

0 to 50kV at 0 to 2mA, limited to a maximum of 50 watts or 75 Watts. 0-65kV at 2mA limited to 65 Watts.

Voltage Control:

Internal multi-turn potentiometer to set voltage Local:

from 0 to full output voltage.

Remote: 0 to +10Vdc proportional from 0 to full output voltage.

Accuracy: ±1%. Z_{IN}: 10Mohm.

Ask about our X-Ray subsystem capabilities

- 50kV at 2 mA. 50 or 75 Watt Max.
- 65kV at 2 mA. 65 Watt Max.
- Adjustable Isolated Filament Supply
- Overvoltage & Short Circuit Protection
- Voltage & Current Programming
- Local and Remote Emission Control
- Safety Interlock
- RS-232, Ethernet, & USB Standard
- Redundant HV Monitor Signal Available
- OEM Customization Available

Emission Control:

Local: Internal potentiometer to set beam current

between 0 and full output current.

Remote: 0 to +10Vdc proportional from 0 to full output current.

Accuracy: ±1%. Z_{IN}: 10Mohm. Filament limit and filament preheat control capability is also provided.

DC Filament Supply:

Isolated filament power supply generates emission current feedback signal for accurate low X-Ray tube current performance.

Current: 3.5A, adjustable limit

Voltage: 5.0 volt limit

Environmental:

Operational: 0°C to +50°C Storage: -40°C to +85°C

Humidity: 0% to 90%, non-condensing

Temperature Coefficient:

0.01% per °C, voltage and current.

Stability:

0.05% per 8 hours after 1/2 hour warm-up.

Voltage and Current Monitors:

0 to ± 10 Vdc proportional from 0 to rated output. Accuracy $\pm 1\%$.

Redundant Voltage Monitor:

A redundant high voltage feedback divider with proportional 0 to +10Vdc = 0 to 100% output voltage signal can be provided on a custom basis.

Dimensions:

50kV Unit: 4.00"H x 2.87"W x 8.00"D

(101.6mm x 72.95mm x 202.20mm).

4.00"H x 2.87"W x 9.00"D 65kV Unit:

(101.6mm x 72.95mm x 228.60mm).

4.00"H x 2.87"W x 9.00"D XCC Option:

(101.6mm x 72.95mm x 228.60mm).

Weight:

4.5 lbs. (2.1kg) typical

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant. UL/CUL recognized, File E227588





Digital Interface

The uX features a standard USB, RS-232 and Ethernet digital interface. Utilizing these standard digital interfaces can dramatically simplify power supply interfacing requirements saving the user both time and money, while enhancing functionality and overall capability. Spellman provides a GUI with the uX that allows the customer to both customize operational features of the uX while also providing basic power supply operational features. Details of the uX's digital interface capability are described in detail in the uX manual.



Closeup showing digital interface connectors



Main Control Screen



Communication Screen



Filament Status Screen

Grid Bias Option (GB):


Spellman's Grid Bias Option for the uX Series is specifically designed for popular commercially available grid bias X-Ray tubes. The Grid Bias voltage is developed via the use of a separate integrated high frequency switching circuit, providing maximum flexibility and control. The Grid Bias output is a voltage regulated, current compliant topology ideally suited for Wehnelt electrode applications. Arc and short circuit protection of the Grid Bias output prevents any damage due to transient events or installation errors.

Tracking Mode Operation

Functioning in tracking mode the voltage monitor (0-10Vdc = 0 to 50kV) of the main high voltage output is internally connected to the Grid Bias programming input (0-10Vdc = 0 to -300Vdc of Grid Bias). Connected in this manner the Grid Bias output will track in a linearly proportional fashion the setting of the main kV output.

A multiturn potentiometer limits the maximum magnitude of Grid Bias output applied to the X-Ray tube, providing unparalleled flexibility.

The output of the Grid Bias option is provided via an auxiliary two position Phoenix Contact terminal block, the mating connecter is provided.



GRID BIAS SPECIFICATIONS

Output Voltage: 0 to -300Vdc
Output Current: 0.25mA, maximum

Load Regulation: 1% of output voltage, no load to full load **Line Regulation:** 1% for a ±10% change in input voltage

Ripple: 1% of maximum rated voltage



e-mail: sales@spellmanhv.com



HIGH VOLTAGE OUTPUT CONNECTOR

Spellman drywell type detachable connector.

A one meter (39.4") long polyethylene mating high Standard:

voltage cable is provided.

A one meter (39.4") long Mammoflex mating high voltage 5302:

cable is provided, SHV p/n 201946-007

2001: A one meter (39.4") long Mammoflex mating high voltage cable

is provided, compatible with the XCC Option SHV p/n 201946-002

POWER INPUT CONNECTOR

PIN	SIGNAL	PARAMETER
1	+24V Input	+24 volts @ 5A, max.
2	24V Return (Gnd.)	Power Ground

FILAMENT CONNECTOR

PIN	SIGNAL	PARAMETER
1	Filament Out	0.3A to 3.5A, 5 volt max.
2	Filament Return	Filament Return

Note: On the standard uX unit, the filament return wire cannot be grounded as this would short circuit the tube return current monitoring to the uX. If grounding of the filament is required, please select the GF (Grounded Filament) option when ordering.

ANALOG INTERFACE CONNECTOR MALE 15 PIN MINI "D'

PIN	SIGNAL	PARAMETER
1	Monitor Return	Signal Ground
2	Voltage Monitor	0-10 volts = 0 to full scale, Zout=1KΩ
3	Current Monitor	0-10 volts = 0 to full scale, Zout=1KΩ
4	Interlock Output	Connect 12V HVON bulb to pin 15 to enable
5	+10 Volt Reference	+10 Volts at 1mA, maximum
6	Filament Monitor	1 volt = 1 amp, Zout=1 $K\Omega$
7	Voltage Program Input	0-10 volts = 0 to full scale, $Zin=10M\Omega$
8	Local Voltage Program*	0-10 volts, screwdriver adjust
9	Filament Limit Setpoint*	1 volt = 1 amp, screwdriver adjust
10	Current Program Input	0-10 volts = 0 to full scale, $Zin=10M\Omega$
11	Local Current Program*	10 turn pot, screwdriver adjust
12	Not used (+24V Out for Interlock)	(Optional Interlock configuration)
13	Not used (Interlock Coil)	(Optional Interlock configuration)
14	Filament Preheat Setpoint*	1 volt = 1 amp, screwdriver adjust
15	Interlock Return	Interlock Ground

^{*}Denotes 10 turn potentiometer accessable through holes in cover

GRID BIAS CONNECTOR 2 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETER
1	Ground	Chassis Ground
2	Grid Bias	0 to -300Vdc

USB DIGITAL INTERFACE-4 PIN USB "B" CONNECTOR

	PIN	SIGNAL	PARAMETER
	1	VBUS	+5 Vdc
ı	2	D-	Data -
ı	3	D+	Data +
ı	4	GND	Ground

ETHERNET DIGITAL INTERFACE— **8 PIN RJ45 CONNECTOR**

PIN	SIGNAL	PARAMETER
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receive Data +
4	NC	No Connection
5	NC	No Connection
6	RX-	Receive Data -
7	NC	No Connection
8	NC	No Connection

RS-232 DIGITAL INTERFACE— 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETER
1	NC	No Connection
2	TX out	Transmit Data
3	RX in	Receive Data
4	NC	No Connection
5	SGND	Ground
6	NC	No Connection
7	NC	No Connection
8	Voltage Monitor 2	0-10V = 0 to full scale, Zout = 1KΩ
9	Power Supply OK	+15V = OK,
		0V = Fault, Sink/Source 3mA max

How To Order:

Sample model number:

50 Watt unit: uX50P50 65 Watt unit: uX65P65 75 Watt unit: uX50P75

Options are added to the model number as follows:

uX50P50/XCC or uX50P75/GB

Ask about our X-Ray subsystem capabilities








DIMENSIONS: in.[mm] 50kV


DIMENSIONS: in.[mm] 50kV with XCC Option


BACK VIEW M5X.8 GROUND STUD 2.87 [72.95] (=) 4.00 [101.60]


















PAGE 5 OF 5

DIMENSIONS: in.[mm] 65kV


2.87 [72.95] 4.00 [101.60]

SIDE VIEW






FRONT VIEW













PAGE 1 OF 3







The MFX Series is the result of Spellman's exceptional high voltage packaging and surface mount fabrication techniques, coupled with its proprietary encapsulation technology producing this ultra compact-sized OEM X-Ray generator module.

The MFX Series is designed to power floating filament X-Ray tubes from various manufacturers. It features a 0 to 50kV (or 0 to 65kV) high voltage output, and up to 2mA of emission current limited to 50, 65 or 75 Watts, operating from a +24Vdc input. The MFX utilizes a closed loop filamentry beam control circuit to provide a highly regulated beam current. The floating ac filament supply operates between 0.3 and 4 amps. Offering tight regulation, high stability and low ripple, the MFX provides users both local and remote analog control to set beam voltage, emission current and filament current limit. An optional USB, RS-232 and Ethernet interface is available.

OPTIONS

Standard Interface Controller (Ethernet, USB & RS-232)

5VPM 0 to 5 Volt Programming and Monitor Scaling

SPECIFICATIONS

Input:

+24Vdc ±10%, 5.0A maximum for either 50 Watts or 75 Watts. +24Vdc ±1V, 5.0A maximum for 65kV/65W units.

Efficiency:

80-85%, typical

Output:

0 to 50kV at 0 to 2mA, limited to a maximum of 50 watts or 75 Watts. 0-65kV at 2mA limited to 65 Watts. Negative output polarity.

Voltage Control:

Local: Internal multi-turn potentiometer to set voltage

from 0 to full output voltage.

Remote: 0 to +10Vdc proportional from 0 to full output voltage.

Accuracy: ±1%. Z_{IN}: 10Mohm.

• 50kV at 2mA, 50 or 75 Watt Max

- 65kV at 2mA, 65 Watt Max
- Floating Integrated Filament Supply
- Arc & Short Circuit Protection
- Voltage & Current Programming
- Local and Remote Emission Control
- Safety Interlock
- Optional Digital Interface

Emission Control:

Local: Internal potentiometer to set beam current

between 0 and full output current.

Remote: 0 to +10Vdc proportional from 0 to full output current. Accuracy: $\pm 1\%$. $Z_{\mathbb{N}}$: 10Mohm. Filament limit and filament preheat control capability is also provided.

High Frequency AC Filament Supply:

Current: 0-4A, adjustable limit

Voltage: 5.0 volt limit

Voltage Regulation:

Load: 0.01% of output voltage no load to full load. Line: ±0.01% for ±10% change in input voltage.

Current Regulation:

Load: 0.01% of output current from 0 to rated voltage. Line: ±0.01% for ±10% change in input voltage.

Ripple:

0.1% p-p of maximum rated output voltage, 50kV units (50/75W) 0.1% rms maximum rated output voltage, 65kV units (65W)

Environmental:

Operational: 0°C to +50°C Storage: -40°C to +85°C

Humidity: 0% to 90%, non-condensing

Temperature Coefficient:

0.01% per °C, voltage and current.

Stability:

0.05% per 8 hours after 1/2 hour warm-up.

Voltage and Current Monitors:

0 to ± 10 Vdc proportional from 0 to rated output. Accuracy $\pm 1\%$.

Dimensions:

50kV Unit: 7.00"H x 2.87"W x 8"D

(177.80mm x 72.90mm x 203.25mm)

65kV Unit: 7.00"H x 2.87"W x 9"D

(177.80mm x 72.90mm x 228.65mm)

SIC Option: 7.75"H x 2.87"W x 8"D/9"D

(196.85mm x 72.90mm x 203.25mm/228.65mm)

Weight:

7.0 lbs. (3.2kg)

Regulatory Approvals:

RoHS compliant.





J2 POWER INPUT CONNECTOR


PIN	SIGNAL	PARAMETER
1	+24V Input	+24 volts @ 5A, max.
2	24V Return (Gnd.)	Power Ground


J4 ANALOG INTERFACE CONNECTOR **MALE 15 PIN MINI "D"**

PIN	SIGNAL	PARAMETER
1	Monitor Return	Signal Ground
2	Voltage Monitor	0-10 volts = 0 to full scale, Zout=1KΩ
3	Current Monitor	0-10 volts = 0 to full scale, Zout=1KΩ
4	Interlock Output	Connect 12V HVON bulb to pin 15 to enable
5	+10 Volt Reference	+10 Volts @ 1mA, maximum
6	Filament Monitor	1 volt = 1 amp, Zout=1KΩ
7	Voltage Program Input	0-10 volts = 0 to full scale, $Zin=10M\Omega$
8	Local Voltage Program*	10 turn pot., screwdriver adjust
9	Filament Limit Setpoint*	1 volt = 1 amp, screwdriver adjust
10	Current Program Input	0-10 volts = 0 to full scale, $Zin=10M\Omega$
11	Local Current Program*	10 turn pot, screwdriver adjust
12	Not used (+24V Out for Interlock)	(Optional Interlock configuration)
13	Not used (Interlock Coil)	(Optional Interlock configuration)
14	Filament Preheat Setpoint*	1 volt = 1 amp, screwdriver adjust
15	Interlock Return	Interlock Ground

^{*}Denotes 10 turn potentiometer located on front panel

DIMENSIONS: in.[mm]





J1 CATHODE OUTPUT **CLAYMOUNT HV CONNECTOR**

PIN	OUTPUT CONNECTION
C (common)	-High Voltage Output
S (small)	-High Voltage Output
L (large)	Filament Output
G (grid)	Filament Output

Note: No high voltage cable is provided

Recommended Cable:

Claymount part number: 11470

Cable assembly, L3 CA11, CA11, 10F, CS=Bare 10 foot, Mini Federal Connectors on both ends, "C" and "S" are

both connected to the bare wire



Sample model number:


50 Watt unit: MFX50N50 65 Watt unit: MFX65N65 75 Watt unit: MFX50N75


Options are added to the model number as follows:

MFX50N75/SIC

50KV WITH SIC OPTION











PAGE 3 OF 3


DIMENSIONS: in.[mm]








65KV WITH SIC OPTION











PAGE 1 OF 2









Rack-Mountable

Floating Filament

Internal Grid Power Supply (80W Model)

Power Factor Correction

Closed-loop Emission Control

OEM Customization Available

Spellman's XRF Series allow for a wide range of input voltages and supply either 80W, 320W or 640W of output power at up to 160kVdc. These lightweight rack-mountable X-Ray generators house a miniaturized high voltage system in a solid encapsulated, oil-free design. The XRF Series is designed with a power factor corrected input circuit which reduces harmonic emissions and noise normally associated with other high frequency switching power supplies. The XRF Series incorporates an internal floating filament and a closed-loop emission control circuit for precise regulation of emission current. Remote monitoring and control of voltage, current and filament current is

TYPICAL APPLICATIONS

X-Ray Inspection, Non-Destructive Testing

OPTIONS

also provided.

DF Dual Filament Arc Trip AT 10 **GS** Grid Supply Instant ON

SL Slides SS(X) Non Standard Slow Start

SPECIFICATIONS

Input Voltage:

80W: 90-125Vac at 48-62Hz @ 1.9A

180-264Vac at 48-62Hz @ 0.9A 320W: 180-264Vac at 48-62Hz @ 3.5A

640W: 180-264Vac at 48-62Hz @ 7A

Power Factor:

0.9 or better.

High Voltage Supply:

Output Voltage:

0-160kV, negative polarity.

Output Current:

80W: 0.5mA max. 320W: 2.0mA at 160kV

640W: 4.0mA

Output Voltage Stability:

Within 0.1% of set value after warm-up period at full load.

Output Voltage Ripple:

80W & 320W: <0.1%, or 160V p-p for high freq. and line freq. at full load.

640W: 0.03% rms <1kHz, 0.75% rms above 1kHz.

Beam Current Stability

80W: Within 0.1% of set value after 1/2 hour warm-up at constant output setting of 30-160kV and line

voltage of 90-125 & 180-264Vac.

320W & 640W:

Same as 80W except line voltage of 180-264Vac.

Constant current DC filament supply with Filament Supply:

closed-loop current feedback.

Filament Voltage: 7V rms (high frequency) max.

5A max., adjustable 0-5.0A by external Filament Current:

Filament Limit Programming input.

Floating Grid Power Supply:

Grid Supply: The grid supply controls tube beam current

in a closed-loop regulation design.

Grid Voltage: 0 to 1200Vdc.

Grid Voltage Ripple: Less than 1.0V rms at any frequency. Grid Supply Response: Less than 0.5mA in less than 10ms.

Control and Monitoring:

Analog Control Inputs: Three inputs have internal load

resistance greater than 330kohms.

Voltage Programming: 80W, 320W & 640W:

0 to ± 10 Vdc, where ± 10.0 Vdc = ± 160 kV output.

Beam Tube Current Control:

80W: 0 to \pm 10Vdc, where 10.0Vdc = 0.5mA tube current. 320W: 0 to +10Vdc, where 10.0Vdc = 2.0mA tube current. 640W: 0 to \pm 10Vdc. where 10.0Vdc = 4.0mA tube current.

Filament Current Control:

0 to +10Vdc, where 5.0Vdc = 5.0A filament current.

Analog Monitor Outputs: (See tables for details) Digital Control Inputs: (See tables for details) Digital Outputs: (See tables for details)

Connections:

Output Connector:

R24 (see owners manual for details)

Input Power Connector:

5-pin male MS-type, Amphenol P/N 97-3102A-18-20P

Control Connector:

25-pin "D" connector, male, chassis-mounted.

Environmental:

0 to +50°C at 10-95% RH, non-condensing. Forced convection cooling.

Dimensions:

7"H x 19"W x 22"D (17.8cm x 48.3cm x 55.9cm).

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

XRF series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The XRF series is not intended to be operated by end users as a stand-alone device. The XRF series power supply can only be fully assessed when installed within a system, and as a component part within that system.



e-mail: sales@spellmanhv.com

160kV XRF SELECTION TABLE

OUTPUT VOLTAGE kV	OUTPUT CURRENT mA	OUTPUT POWER W	MODEL NUMBER XRFxxx
160	0.5	80	XRF160N80
160	2.0	320	XRF160N320
160	4.0	640	XRF160N640

J2 AC INPUT CONNECTOR WIRING

5 Pin MS Type	7 Pin UTG Type	CONNECTION
А	1	Auxiliary (Logic) Line
В	2	Auxiliary (Logic) Neutral
С	3	Ground
D	4	Main (Inverter) Line
Е	5	Main (Inverter) Neutral


JB1 160kV XRF 80W, 320W, 640W 25 PIN

PIN	SIGNAL	SIGNAL PARAMETERS
1	Filament Limit	0-5V = 0-5A Filament Limit
2	High Voltage on Control	+12VDC IN = HV ON
3	N/C	
4	N/C	
5	High Voltage On Status	Low = HV ON
6	A-Ground	Ground
7	kV Monitor	0-10V = 0-160kV
8	Interlock Control	+12VDC IN = Interlock Closed
9	N/C	
10	mA Demand	0-10V = 0-100% Rated Output
11	N/C	
12	N/C	
13	D-Ground	Ground
14	Fil. Monitor	0-5V = 0-5A
15	N/C	
16	N/C	
17	N/C	
18	N/C	
19	mA Monitor	0-10V = 0-100% Rated Output
20	N/C	
21	+12VDC Out	
22	kV Demand	0-10V = 0-160kV
23	Grid Inhibit/Fil. Select	Low = Grid Inhibit
24	N/C	
25	Chassis Gnd (I/O Shield)	Chassis Gnd.

160kV XRF 80W, 320W, 640W TERMINAL BLOCK 10 PIN

PIN	SIGNAL	SIGNAL PARAMETERS
1	Interlock	Jumper to TB1-2 to close interlock
2	Interlock Return	
3	kV Monitor	0-10V=0-160kV
4	mA Monitor	0-10V = 0-100% Rated Output
5	Filament Monitor	0-5V=0-5A
6	N/C	
7	HV ON Indicator	+15V = HV ON
8	Voltage Mode Indicator	Low = Voltage Mode.
9	Current Mode Indicator	Low = Current Mode.
10	GND	Ground

DIMENSIONS: in.[mm]



TOP VIEW



BACK VIEW





Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

+1-631-630-3000 FAX: +1-631-435-1620

PAGE 1 OF 4



The uXHP Series is the result of Spellman's exceptional high voltage packaging and surface mount fabrication techniques coupled with proprietary encapsulation technology producing this ultra-compact X-Ray generator module. The uXHP powers grounded cathode X-Ray tubes from a variety of well-known manufacturers, featuring a 0 to 50kV/65kV/80kV high voltage output @ 5mA limited to 100W. The uXHP uses closed loop filament control circuitry providing highly regulated beam current. The low noise dc filament supply operates between 0.3 and 3.5A. Offering tight regulation, high stability and low ripple, the uXHP provides users local and remote analog control to set beam voltage, emission current and filament current limit. USB, RS-232 and Ethernet interface is standard.

TYPICAL APPLICATIONS

Powering grounded cathode X-Ray tubes from Varex, Kevex, Oxford, RTW, Superior and Trufocus.

SPECIFICATIONS

Input:

+24Vdc ±1V; 7.75A maximum

Efficiency:

75%, typical

Output:

See model selection table on page 2

Voltage Control:

Local: Internal multi-turn potentiometer to set voltage

from 0 to full output voltage.

Remote: 0 to 10Vdc = 0 to 100% rated output voltage.

Accuracy: $\pm 1\%$. $Z_{IN} = 10$ Mohm.

Emission Control:

Local: Internal potentiometer to set beam current

from 0 to full output current.

Remote: 0 to 10Vdc = 0 to 100% rated output current.

Accuracy: $\pm 1\%$. $Z_{IN} = 10$ Mohm. Filament limit and filament preheat control capability is also provided.

Ask about our X-Ray subsystem capabilities

- 50kV, 65kV and 80kV Output Voltage
- 100W Output Power
- Adjustable Ground Isolated Filament Supply
- Overvoltage & Short Circuit Protection
- Voltage & Current Programming
- Local and Remote Emission Control
- Safety Interlock
- RS-232, Ethernet, & USB Standard
- Redundant HV Monitor Signal

Voltage and Current Monitors:

0 to 10Vdc = 0 to 100% rated output Accuracy: $\pm 1\%$. $Z_{OUT} = 1$ kohm

Redundant Voltage Monitor:

A redundant high voltage feedback divider where 0 to 10Vdc = 0 to 100% rated output is monitored via firmware. The analog monitor signal can be provided by special order.

Temperature Coefficient:

0.01% per °C, voltage and current.

Stability:

0.05% per 8 hours after 1/2 hour warm-up.

Digital Interface:

RS-232, Ethernet and USB is standard

DC Filament Supply:

Ground isolated filament power supply allows actual tube current feedback signal for monitoring accurate low X-Ray tube current performance.

Current: 0-3.5A, adjustable limit Voltage: 5.0V, maximum compliance

Environmental:

Operational: 0° C to +50° C Storage: -40° C to +85° C

Humidity: 0% to 90%, non-condensing

Dimensions:

50/65kV Unit: 7.00"H x 3.07"W x 9.00"D

(177.80mm x 78.00mm x 228.60mm)

80kV Unit: 7.00"H x 3.07"W x 10.50"D

(177.80mm x 78.00mm x 266.70mm)

Weight:

50/65kV Unit: 8.5 lbs. (3.85kg) 80kV Unit: 10.0 lbs. (4.53kg)

Cooling:

User provided forced air cooling is required

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588. RoHS Compliant.





uXHP MODEL SELECTION TABLE

OUTPUT VOLTAGE	OUTPUT CURRENT	OUTPUT POWER	MODEL NUMBER
0-50kV	0-5mA	100W	uXHP50P100
0-65kV	0-5mA	100W	uXHP65P100
0-80kV	0-5mA	100W	uXHP80P100

CONTROL POWER INPUT CONNECTOR

PIN	SIGNAL	PARAMETER
1	+24V Control Power	+24 volts @ 1A, max.
2	+24V Control Power Return	Power Ground

FILAMENT CONNECTOR

PIN	SIGNAL	PARAMETER
1	Filament Output	0.3A to 3.5A @ 5V, max.
2	Filament Return	Filament Return

Note: The filament return wire cannot be grounded as this would short circuit the tube return current monitoring to the uXHP. If grounding of the filament is required, please consult the factory.

ANALOG INTERFACE CONNECTOR **MALE 15 PIN MINI "D"**

PIN	SIGNAL	PARAMETER
1	Monitor Return	Signal Ground
2	Voltage Monitor	0-10V = 0 to full scale, Zout=1KΩ
3	Current Monitor	0-10V = 0 to full scale, Zout=1KΩ
4	Interlock Output	Connect 12V HV ON bulb to pin 15 to enable
5	+10V Reference	+10V at 1mA, maximum
6	Filament Monitor	1V = 1A, Zout=1KΩ
7	Voltage Program Input	$0-10V = 0$ to full scale, $Zin=10M\Omega$
8	Local Voltage Program*	0-10V, screwdriver adjust
9	Filament Limit Setpoint*	1V = 1A, screwdriver adjust
10	Current Program Input	$0-10V = 0$ to full scale, $Zin=10M\Omega$
11	Local Current Program*	10 turn pot, screwdriver adjust
12	Not used (+24V Out for Interlock)	(Optional Interlock configuration)
13	Not used (Interlock Coil)	(Optional Interlock configuration)
14	Filament Preheat Setpoint*	1V = 1A, screwdriver adjust
15	Interlock Return	Interlock Ground

^{*}Denotes 10 turn potentiometer accessable through holes in cover

USB DIGITAL INTERFACE-4 PIN USB "B" CONNECTOR

PIN	SIGNAL	PARAMETER
1	VBUS	+5Vdc
2	D-	Data -
3	D+	Data +
4	GND	Ground

HIGH VOLTAGE OUTPUT CONNECTOR


Spellman drywell type detachable connector.

50/65kV: A one meter (39.4") long polyethylene mating high

voltage cable with banana plug termination is provided.

A one meter (39.4") long polyethylene mating high 80kV:

voltage cable with corona ball termination is provided.



HV Cable Options:

5302:

(50kV unit only) A one meter (39.4") long Mammoflex mating high voltage cable is provided, SHV p/n 201946-007

2001: (50kV with XCC option and 65kV units only)

A one meter (39.4") long Mammoflex mating high voltage cable is provided, compatible with the XCC Option SHV p/n 201946-002

HIGH VOLTAGE POWER INPUT CONNECTOR PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETER
1	+24V High Voltage Power Input	+24V @ 7.75A max
2	+24V High Voltage Power Return	Power Ground

ETHERNET DIGITAL INTERFACE— **8 PIN RJ45 CONNECTOR**

PIN	SIGNAL	PARAMETER
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receive Data +
4	NC	No Connection
5	NC	No Connection
6	RX-	Receive Data -
7	NC	No Connection
8	NC	No Connection

RS-232 DIGITAL INTERFACE— 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETER
1	NC	No Connection
2	TX out	Transmit Data
3	RX in	Receive Data
4	NC	No Connection
5	SGND	Ground
6	NC	No Connection
7	NC	No Connection
8	Voltage Monitor 2	$0-10V = 0$ to full scale, Zout = $1K\Omega$
9	Power Supply OK	+15V = OK, 0V = Fault, Sink/Source 3mA max

How To Order:

Sample model number:


50kV unit: uXHP50P100 65kV unit: uXHP65P100 80kV unit: uXHP80P100

Ask about our X-Ray subsystem capabilities




e-mail: sales@spellmanhv.com





ALTERNATE INTERLOCK CONFIGURATION



Digital Interface

The uXHP features a standard USB, RS-232 and Ethernet digital interface. Utilizing these standard digital interfaces can dramatically simplify power supply interfacing requirements



saving the user both time and money, while enhancing functionality and overall capability. Spellman provides a GUI with the uXHP that allows the customer to both customize operational features of the uXHP while also providing basic power supply operational features. Details of the uXHP's digital interface capability are described in detail in the uXHP manual.

Closeup showing digital interface connectors



Varex VF-80J X-Ray Tube

The uXHP was specifically designed in cooperation with Varex to power their new VF-80J X-Ray tube. This joint effort resulted in the creation of both the VF-80J X-Ray tube and the uXHP X-Ray generator. The Varex VF-80J tube is uniquely rated to run at up to 80kV @ 100 watts, 4mA maximum. The uXHP was explicitly designed to operate at up to 80kV



and provide 100 watts down to 25kV, so customers could make full use of the capabilities of the VF-80J X-Ray tube. Varex and Spellman, working together to push the boundaries of X-Ray technology.



Copyright © 2014 Spellman High Voltage Electronics Corp.

Corporate Headquarters

Hauppauge, New York USA


PAGE 4 OF 4


SIDE VIEW


DIMENSIONS: in.[mm]

SOKV, 50kV/XCC and 65kV BACK VIEW M5X.8 GROUND STUD


7.00 [177.8]







BOTTOM VIEW





FRONT VIEW











Spellman's new DXM Series of X-Ray generator modules are designed for OEM applications up to 160kV at 1200 watts. Its universal input, small package size and choice of three standard digital interfaces simplifies integrating the DXM into your X-Ray analysis system. Models are available to operate either floating filament (negative HV polarity) or ground referenced filament (positive HV polarity), X-Ray tube designs. DSP based emission control circuitry provides excellent regulation of emission current, along with outstanding stability performance.

TYPICAL APPLICATIONS

Plastics Sorting Crystal Inspection Plating Measurement Diamond Inspection Mineral Analysis X-Ray Fluorescence X-Ray Diffraction

SPECIFICATIONS

Input Voltage:

Power factor corrected input 100-240Vac ±10% (90-264Vac): 47-63Hz @ 4.6A for 300 watt units 200-240Vac ±10% (180-264Vac): 47-63Hz @ 4.3A for 600 watt units 47-63Hz @ 8.2A for 1200 watt units

Output Voltage:

8 models—20kV, 30kV, 40kV, 50kV, 60kV, 70kV, 75kV and 160kV

Output Polarity:

Negative- for floating filament X-Ray tubes
Positive- for ground referenced filament X-Ray tubes

+1-631-630-3000

- Compact & Lightweight
- Models from 20kV-160kV, 300W, 600W and 1200W
- Universal Input, Power Factor Corrected
- Hot Anode or Hot Cathode X-Ray Tube Capable
- Standard Digital Interfaces: USB, Ethernet and RS-232
- CE Compliant, UL Recognized and RoHS Compliant
- User Programmable Ramping and Arc Detect Feature

Power:

3 power ranges available: 300 watts, 600 watts and 1200 watts. Other power levels available on special order.

Output Voltage Regulation:

≤0.01% of rated output voltage over specified input voltage range≤0.01% of rated output voltage for a full load change

Emission Current Regulation:

≤0.01% of rated output current over specified input voltage range ≤0.01% of rated output current for a change from 30% to 100% of rated output voltage Filament is disabled when kV is <30% of full scale output

Ripple

≤1%rms at >20kHz, 0.1%rms below 20kHz

Stability:

≤25ppm/hr after a 2 hour warm up

Temperature Coefficient:

≤50ppm per degree C

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -40°C to 85°C
Humidity:
20% to 85% RH, non-condensing.

Filament Configuration:

Closed loop emission control regulates filament setting to provide desired X-Ray tube emission current. Two types are available: Floating Filament (ac output referenced to negative output voltage) and Ground Referenced Filament (dc output referenced to ground).

Output: 0-5 amps at a compliance of 10 volts, maximum.

The filament loop is disabled when the kV output is less than 30% of full scale output to protect the X-Ray tube. Standard filament Preheat adjustable 0-2.5 amps. Other filament levels available on special order.





Control Interface

Local Interface:

Potentiometers are provided to adjust filament limit and preheat levels

Remote Interface:

USB, Ethernet and RS-232 are standard. All digital monitors have an accuracy specification of 2%

Control Software:

A Windows graphical user interface example is provided

High Voltage Enable:

A hardware based, dry contact closure will enable the power supply into the high voltage on mode

Monitor Signals:

Voltage and current monitor signals are scaled 0-10Vdc equals 0-100% of full scale, accuracy is 1%

Dimensions:

300/600 Watts: 4.75" H X 6"W X 12" D

(120.65mm x 152.4mm x 304.8mm)

1200 Watts: 4.75" H X 12" W X 12" D

(120.65mm x 304.8mm x 304.8mm)

160kV: 10.5"H X 19"W X 21.5"D

(266.7mm x 482.6mm x 546.1mm)

Weight:

300/600 Watts: 14 pounds (6.35kg) 1200 Watts: 26 pounds (11.8kg) 160kV: 142 pounds (66.4kg)

Cooling:

Forced air

Input Line Connector:

IEC320 with EMI filter

Output Connector:

Depends upon polarity selected.

See table and drawing. Other connectors and pinouts available on special order.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588. RoHS Compliant. DXM160N1200 is not UL recognized.

DXM SELECTION TABLE— 300W, 600W, 1200W

300 Watt		600 Watt		1200 Watt		
kV	mA.	Model	mA	Model	mA	Model
20	15	DXM20*300	30	DXM20*600	60	DXM20*1200
30	10	DXM30*300	20	DXM30*600	40	DXM30*1200
40	7.5	DXM40*300	15	DXM40*600	30	DXM40*1200
50	6	DXM50*300	12	DXM50*600	24	DXM50*1200
60	5	DXM60*300	10	DXM60*600	20	DXM60*1200
70	4.28	DXM70*300	8.56	DXM70*600	17.12	DXM70*1200
75	4	DXM75*300	8	DXM75*600	16	DXM75*1200
160					7.5	DXM160N1200

^{*}Specify "P" for positive polarity or "N" for negative polarity

FILAMENT TERMINAL BLOCK— TB1 TWO POSITION TERMINAL BLOCK

POSITION	SIGNAL	SIGNAL PARAMETERS
1	Filament Output	0-5 amps, 10Vdc Maximum
2	Filament Return	Filament Return

For positive polarity/ground referenced filament units

DXM ANALOG INTERFACE— J2 15 PIN MALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power Supply Fault	Open Collector, 35V @ 10mA Maximum
2	Current Program In	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
3	Voltage Program In	0 to 10V=0 to 100% Rated Output, Zin=10M Ω
4	Filament Limit Input	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
5	Local Filament Limit	Multi-turn front panel potentiometer
6	Filament Preheat Input	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
7	Local Filament Preheat	Multi-turn front panel potentiometer
8	Voltage Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%
9	Signal Ground	Ground
10	Current Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%
11	X-Ray Enable Input	Connect to Pin 12 to HV Enable Supply
12	X-Ray Enable Output	+15V @ Open, ≤15mA @ Closed
13	Filament Monitor	1 Volt=1 Amp, Zout=10kΩ
14	X-Ray On Output Signal	Open Collector, 35V @10mA Maximum
15	Spare	N/C

RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	N/C	No Connection
2	TX out	Transmit Data
3	RX in	Receive Data
4	N/C	No Connection
5	SGND	Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

PAGE 3 OF 5

USB DIGITAL INTERFACE— J4 4 PIN USB "B" CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	VBUS	+5 Vdc
2	D-	Data -
3	D+	Data +
4	GND	Ground

ETHERNET DIGITAL INTERFACE— J5 8 PIN RJ45 CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receive Data +
4	N/C	No Connection
5	N/C	No Connection
6	RX-	Receive Data -
7	N/C	No Connection
8	N/C	No Connection

R24 HV CONNECTOR PINOUT J6 CATHODE OUTPUT (160kV)

	PIN	OUTPUT CONNECTION
ı	C (common)	High Voltage Output
ı	S (small)	Filament Output
ı	L (large)	Filament Output

HIGH VOLTAGE OUTPUT CONNECTOR— J6 FLOATING FILAMENT

20kV-75kV Negative Polarity:

Claymount Mini Federal standard X-Ray connector 160kV Negative Polarity:

R24 (cable not provided)

HIGH VOLTAGE OUTPUT CONNECTOR— J6:GROUND FILAMENT

Positive Polarity: Spellman High Voltage

Delrin Drywell connector.

4 foot (1.21m) long high voltage

cable provided

For positive polarity units a ground referenced filament output is provided on a two position terminal TB1. See table

CLAYMOUNT HV CONNECTOR

	PIN	OUTPUT CONNECTION
l	C (common)	High Voltage Output
ı	S (small)	High Voltage Output
1	L (large)	Filament Output
ı	G (grid)	Filament Output

Note: No high voltage cable is provided

Recommended Cable: Claymount part number: 12096 Cable assembly, L3 CA11, CA11, 10F, CS=Bare 10 foot, Mini Federal Connectors on both ends, "C" and "S" are both connected to the bare shield wire





FRONT VIEW



SIDE VIEW












PAGE 4 OF 5

DIMENSIONS: in.[mm] 1200 Watt

Negative Polarity - Floating Filament

Positive Polarity - Ground Filament




FRONT VIEW





SIDE VIEW SIDE VIEW





+1-631-630-3000



Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

FAX: +1-631-435-1620




PAGE 5 OF 5


DIMENSIONS: in.[mm] 300/600 Watt

Negative Polarity - Floating Filament


BOTTOM VIEW




Positive Polarity - Ground Filament




FRONT VIEW




FRONT VIEW



SIDE VIEW



SIDE VIEW



60-75kV



Spellman's new DXB Series of bipolar X-Ray generator modules are designed for OEM applications up to 320kV (±160kV) at 1200 watts. Its universal input, small package size and choice of three standard digital interfaces simplifies integrating the DXB into your X-Ray analysis system. DSP based emission control circuitry provides excellent regulation of emission current, along with outstanding stability performance.

TYPICAL APPLICATIONS

Plastics Sorting Crystal Inspection Plating Measurement Thickness Gauging Food Inspection

Mineral Analysis X-Ray Fluorescence X-Ray Diffraction Cargo Screening

SPECIFICATIONS

Input Voltage:

Power factor corrected input 100-240Vac, ±10% (90-264Vac): 47-63Hz @ 5.7A for 300 watt units 200-240Vac, ±10% (180-264Vac): 47-63Hz @ 4.8A for 600 watt units 47-63Hz @ 8.0A for 1200 watt units

Output Voltage:

7 models: 40kV, 60kV, 80kV, 100kV, 120kV, 140kV and 320kV

Output Polarity:

± bipolar output, filament referenced to negative output

Power:

3 power ranges available—300 watts, 600 watts and 1200 watts

Other power levels available on special order.

Output Voltage Regulation:

≤0.01% of rated output voltage over specified input voltage range

≤0.01% of rated output voltage for a full load change

Emission Current Regulation:

≤0.01% of rated output current over specified input voltage range ≤0.01% of rated output current for a change from 30% to 100% of rated output voltage

Filament is disabled when kV is <30% of full scale output

- Bipolar Outputs in a Single Unit
- Compact & Lightweight
- Models from 40kV to 320kV. 300W. 600W and 1200W
- Universal Input, Power Factor Corrected
- Standard Digital Interfaces: USB. Ethernet and RS-232
- CE Compliant, UL Recognized

Ripple:

≤1%rms at >20 kHz, 0.1%rms below 20 kHz

Stability:

≤25ppm/hr after a 2 hour warm up

Temperature Coefficient:

≤50ppm per degree C

Environmental:

Temperature Range:

Operating: 0°C to 40°C Storage: -40°C to 85°C

Humidity:

20% to 85% RH, non-condensing.

Filament Configuration:

Closed loop emission control regulates filament setting to provide desired X-Ray tube emission current. Floating Filament (ac output referenced to negative output voltage).

Output: 0-5 amps at a compliance of 10 volts, maximum. The filament loop is disabled when the kV output is less than 30% of full scale output to protect the X-Ray tube. Standard filament Preheat adjustable 0-2.5 amps. Other filament levels available on special order.

Control Interface

Local Interface: Potentiometers are provided to adjust filament limit and preheat levels

Remote Interface: USB, Ethernet and RS-232 are standard. All digital monitors have an accuracy specification of 2%

Control Software: A Windows graphical user interface example is provided.

High Voltage Enable: A hardware based, dry contact closure will enable the power supply into the high voltage on mode

Monitor Signals: Voltage and current monitor signals are scaled 0-10Vdc equals 0-100% of full scale, accuracy is 1%

Cooling:

Forced air

Dimensions:

40-140kV:

4.75" H X 12" W X 12" D (120.65mm x 304.8mm x 304.8mm)

10.5" H X 19.0" W X 21.5" D (266.7mm x 482.6mm x 546.1mm)

Weight:

40-140kV: 26 pounds (11.8kg) 320kV: 150 pounds (68kg)





Input Line Connector:

IEC320 with EMI filter

Output Connectors:

40-140kV:

Claymount Mini Federal Standard X-Ray connectors.

Other connectors and pinouts available on special order.

320kV:

R24 X-Ray connectors.

Other connectors and pinouts available on special order.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588. RoHS Compliant. DXB320PN1200 is not UL recognized.

DXB SELECTION TABLE - 300W, 600W, 1200W

	300 Watt		600 Watt		1200 Watt	
kV	mA	Model	mA	Model mA	mA	Model
40	7.50	DXB40PN300	15.0	DXB40PN600	30.0	DXB40PN1200
60	5.00	DXB60PN300	10.0	DXB60PN600	20.0	DXB60PN1200
80	3.75	DXB80PN300	7.50	DXB80PN600	15.0	DXB80PN1200
100	3.00	DXB100PN300	6.00	DXB100PN600	12.0	DXB100PN1200
120	2.50	DXB120PN300	5.00	DXB120PN600	10.0	DXB120PN1200
140	2.14	DXB140PN300	4.28	DXB140PN600	8.57	DXB140PN1200
320	320 Not Available			Not Available	3.75	DXB320PN1200

DXB ANALOG INTERFACE— J2 15 PIN MALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power Supply Fault	Open Collector, 35V @ 10mA Maximum
2	Current Program In	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
3	Voltage Program In	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
4	Filament Limit Input	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
5	Local Filament Limit	Multi-turn front panel potentiometer
6	Filament Preheat Input	0 to 10V=0 to 100% Rated Output, Zin=10MΩ
7	Local Filament Preheat	Multi-turn front panel potentiometer
8	Voltage Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%
9	Signal Ground	Ground
10	Current Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%
11	X-Ray Enable Input	Connect to Pin 12 to HV Enable Supply
12	X-Ray Enable Output	+15V @ Open, ≤15mA @ Closed
13	Filament Monitor	1 Volt=1 Amp, Zout=10kΩ
14	X-Ray On Output Signal	Open Collector, 35V @10mA Maximum
15	Spare	N/C

RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	N/C	No Connection
2	TX out	Transmit Data
3	RX in	Receive Data
4	N/C	No Connection
5	SGND	Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

+1-631-630-3000

USB DIGITAL INTERFACE— J4 4 PIN USB "B" CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS		
1	VBUS	+5 Vdc		
2	D-	Data -		
3	D+	Data +		
4	GND	Ground		

ETHERNET DIGITAL INTERFACE— J5 8 PIN RJ45 CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS		
1	TX+	Transmit Data +		
2	TX-	Transmit Data -		
3	RX+	Receive Data + No Connection		
4	NC			
5	NC	No Connection		
6	RX-	Receive Data - No Connection No Connection		
7	NC			
8	NC			

CLAYMOUNT HV CONNECTOR PINOUT J6 CATHODE OUTPUT (40-140kV)

PIN	OUTPUT CONNECTION		
C (common)	-High Voltage Output		
S (small)	-High Voltage Output		
L (large)	Filament Output		
G (grid)	Filament Output		

CLAYMOUNT HV CONNECTOR PINOUT J7 ANODE OUTPUT (40-140kV)

PIN	OUTPUT CONNECTION
C (common)	+High Voltage Output
S (small)	+High Voltage Output
L (large)	+High Voltage Output
G (grid)	+High Voltage Output

Note: No high voltage cable is provided

Recommended Cable:

Claymount part number: 12096

Cable assembly, L3 CA11, CA11, 10F, CS=Bare 10 foot, Mini Federal Connectors on both ends, "C" and "S" are

both connected to the bare wire

R24 HV CONNECTOR PINOUT J6 CATHODE OUTPUT (320kV)


PIN	OUTPUT CONNECTION		
C (common)	-High Voltage Output		
S (small)	Filament Output		
L (large)	Filament Output		

R24 HV CONNECTOR PINOUT J7 ANODE OUTPUT (320kV)

PIN	OUTPUT CONNECTION		
C (common)	+High Voltage Output		
S (small)	+High Voltage Output		
L (large)	+High Voltage Output		



PAGE 3 OF 3





Spellman's new DXM100 X-Ray generator module is designed for OEM applications up to 100kV at 1200 watts. Its universal input, small package size and choice of three standard digital interfaces simplifies integrating the DXM100 into your X-Ray analysis system. DSP based emission control circuitry provides excellent regulation of emission current, along with outstanding stability.

TYPICAL APPLICATIONS

NDT Analysis
Plating Measurement
Mineral Analysis

Crystal Inspection
Diamond Inspection
Food/Product Inspection

SPECIFICATIONS

Input Voltage:

Power factor corrected input, ≥0.98 180-264Vac, 47-63Hz, 8.25A maximum

Output Voltage:

100kV, maximum

Output Polarity:

Negative for floating filament X-Ray tubes

Output Current:

12mA maximum

Output Power:

1200 Watts maximum

Output Voltage Regulation:

≤0.01% of rated output voltage over specified input voltage range

≤0.01% of rated output voltage for a full load change

Emission Current Regulation:

≤0.01% of rated output current over specified input voltage range

≤0.01% of rated output current for a change from 30% to 100% of rated output voltage

Filament is disabled when kV is <30% of full scale output

Ripple:

≤1%rms at >20 kHz, 0.1%rms below 20 kHz

Stability:

≤25ppm/hr after a 2 hour warm up

Temperature Coefficient:

≤50ppm per degree C

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -40°C to 85°C

Humidity:

20% to 85% RH, non-condensing.

100kV @ 1200W

- Compact & Lightweight Modular Unit
- Universal Input, Power Factor Corrected
- Standard Digital Interfaces: USB, Ethernet and RS-232
- Programmable Power Trip Feature
- User Programmable Ramping and Arc Detect Feature
- CE Compliant

Filament Configuration:

Closed loop emission control regulates filament setting to provide desired X-Ray tube emission current.

Output: 5.0 amps at a compliance of 10.0 volts, maximum. The filament loop is disabled when the kV output is less than 30% of full scale output to protect the X-Ray tube. Standard filament Preheat adjustable 0-2.5 amps. Other filament levels available on special order.

Control Interface:

Local Interface:

Potentiometers are provided to adjust filament limit and preheat levels

Remote Interface: USB, Ethernet and RS-232 are standard.
All digital monitors have an accuracy specification of 2%

Control Software: A Windows graphical user interface example is provided.

High Voltage Enable: A hardware based, dry contact closure will enable the power supply into the high voltage on mode

Monitor Signals: Voltage and current monitor signals are scaled 0-10Vdc equals 0-100% of full scale, accuracy is 1%

Over Power Fault: The maximum power the unit can supply can be programmed (0-1200 watts) via the digital interface, this setting will be stored in memory. An over power fault will occur if the output power is ≥105% of the set point value. When an over power fault occurs the high voltage output will be disabled and the Over Power Fault indictor will be activated on the GUI/Applet. Additionally both the UV and OV fault LED's on the DXM100 will be illuminated.

Cooling:

Forced air

Dimensions:

6.25" H X 12" W X 15.5" D (158.75mm x 304.79mm x 393.7mm)

Weight:

43 pounds (19.5kg)

Input Line Connector:

IEC320 with EMI filter, 6' (1.83 meter) cord set provided

Output Connector:

CA10 (R10). See table for pin out information

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File E227588. RoHS Compliant.






DXM100 ANALOG INTERFACE— J2 15 PIN MALE D CONNECTOR

	PIN	SIGNAL	SIGNAL PARAMETERS			
	1	Power Supply Fault	Open Collector, 35V @ 10mA Maximum			
	2	Current Program In	0 to 10V=0 to 100% Rated Output, Zin=10MΩ			
	3	Voltage Program In	0 to 10V=0 to 100% Rated Output, Zin=10MΩ			
	4	Filament Limit Input	0 to 10V=0 to 100% Rated Output, Zin=10MΩ			
	5	Local Filament Limit	Multi-turn front panel potentiometer			
	6	Filament Preheat Input	0 to 10V=0 to 100% Rated Output, Zin=10MΩ			
1	7	7 Local Filament Preheat Multi-turn front panel potentiometer				
1	8	Voltage Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%			
	9	Signal Ground	Ground			
	10	Current Monitor	0 to 10V=0 to 100% Rated Output, Zout =4.99k, 1%			
	11	X-ray Enable Input	Connect to Pin 12 to HV Enable Supply			
	12	X-ray Enable Output	+15V @ Open, ≤15mA @ Closed			
	13	Filament Monitor	1 Volt=1 Amp, Zout=10kΩ			
	14	X-ray On Output Signal	Open Collector, 35V @10mA Maximum			
	15	Spare	NC			

Typical DXM100 Cable Wiring



RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS		
1	NC	No Connection		
2	TX out	Transmit Data		
3	RX in	Receive Data		
4	NC	No Connection		
5	SGND	Ground		
6	NC	No Connection		
7	NC	No Connection		
8	NC No Connection			
9	NC	No Connection		

USB DIGITAL INTERFACE— J4 4 PIN USB "B" CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS		
1	VBUS	+5 Vdc		
2	D-	Data -		
3	D+	Data +		
4	GND	Ground		

ETHERNET DIGITAL INTERFACE— J5 8 PIN RJ45 CONNECTOR

	PIN	SIGNAL	SIGNAL PARAMETERS		
	1	TX+	Transmit Data +		
	2	TX-	Transmit Data -		
	3 RX+		Receive Data +		
	4	NC No Connection			
	5	NC	No Connection		
	6 RX- 7 NC		Receive Data -		
			No Connection		
	8	NC	No Connection		

J6 CA10 (R10) HV CONNECTOR

PIN	OUTPUT CONNECTION		
C (common)	High Voltage Output		
S (small)	High Voltage Output		
L (large)	Filament Output		

Note: No high voltage cable is provided


e-mail: sales@spellmanhv.com

+1-631-630-3000



DIMENSIONS: in.[mm]


BOTTOM VIEW




FRONT VIEW



HIGH VOLTAGE MATING FLANGE **BOLT CIRCLE DETAIL**



SIDE VIEW













Spellman's XLF Series of X-Ray generators are well regulated high voltage power supplies with output voltages to 60kV and very low ripple achieved through the use of advanced resonant conversion techniques. Extremely stable voltage and emission current outputs result in significant performance improvements over previously available technology. The XLF Series provides power, control and support functions required for X-Ray applications including a regulated ac filament supply referenced to the cathode. These units also incorporate local and remote programming, monitoring, safety interlock, short-circuit and overload protection.

TYPICAL APPLICATIONS

Plastics Sorting Crystal Inspection Diamond Inspection

OPTIONS

APT Adjustable Power Trip

AT Arc Trip

SS(x) Non-Standard Slow Start

NSS No Slow Start
IO Instant ON
SL Slides

FRONT PANEL STATUS INDICATORS:

Overvoltage Voltage Control Mode
Overtemperature Current Control Mode
Regulation Error Interlock Open

Arc Interlock Open
HV ON: Red HV OFF: Green

SPECIFICATIONS

Input Voltage:

XLF 600W:

115Vac ±10% @ 11.4A, 50-60Hz single phase 220Vac ±10% @ 5.9A, 50-60Hz single phase

XLF 1200W:

220Vac ±10% @ 11.8A, 50-60Hz single phase

Voltage and Current Control:

Local:continuously adjustable from zero to maximum rating via a ten-turn potentiometer

Remote: 0 to +10Vdc proportional from 0 to full output

Accuracy: ±1%

Input Impedance: 10Mohm

Output Voltages to 60kV

- Integrated Floating Filament Supply
- Low Ripple
- "Hot Cathode"
- Negative Polarity
- Local & Remote Programming
- OEM Customization Available

Filament:

12 volts @ 5 amps, preheat level is 0.45 amps in standby

Voltage Regulation:

Load: 0.005% of full output voltage no load to full load Line: 0.005% for input voltage range change

Current Regulation:

Load: 0.05% of full current ±100µA from 0 to full voltage Line: 0.05% of rated current over specified input range

Ripple:

0.03% rms below 1kHz 0.75% rms above 1kHz

Temperature Coefficient:

100ppm/°C.

Stability:

0.01%/8 hrs after 1/2 hour warm-up 0.02% per 8 hours (typical)

Cooling:

Fan cooled

Metering:

Digital voltage and current meters (3.5 digits), 1% accuracy

Voltage and Current Monitors:

0 to +10Vdc proportional to rated output

HV Output:

75kV, 3 conductor Federal Standard X-Ray connector

I/O Connectors:

25 pin D-type for control interface with mating connector provided

Dimensions:

3.5"H x 19"W x 20"D (8.9cm x 48.3cm x 50.8cm)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.

Electronic Component (Power Source)

XLF series is intended for installation as a component of a system.

It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The XLF series is not intended to be operated by end users as a stand-alone device. The XLF series power supply can only be fully assessed when installed within a system, and as a component part within that system.



PAGE 2 OF 2


600W, 1200W XLF SELECTION TABLE

600 Watt		1200 Watt			
kV	mA	Model	kV	mA	Model
30	20	XLF30N600	30	40	XLF30N1200
40	15	XLF40N600	40	30	XLF40N1200
50	12	XLF50N600	50	24	XLF50N1200
60	10	XLF60N600	60	20	XLF60N1200

JB1 CONNECTOR 25 PIN

PIN	SIGNAL	SIGNAL PARAMETERS
1	Power Supply Common	Signal Ground
2	External Inhibit	Ground=Inhibit, Open=HV On
3	External Interlock	+15V at Open, <15mA at Closed
4	External Interlock Return	Return for Interlock
5	Current Monitor	0 to 10V=0 to 100% Rated Output
6	kV Test Point	0 to 10V=0 to 100% Rated Output
7	+10V Reference	+10Vdc @ 1mA Max
8	Remote Current Program In	0 to 10V=0 to 100% Rated Output
9	Local Current Program Out	Front Panel Program Voltage
10	Remote Voltage Program In	0 to 10V=0 to 100% Rated Output
11	Local Voltage Program Out	Front Panel Program Voltage
12	Power Monitor	0 to 10V=0 to 100% Rated Output
13	Remote Power Program In	(Optional)
14	Local HV Off Out +15V at Open, <25mA at Closed	
15	5 HV Off Connect to HV OFF for Fp Ope	
16	Remote HV On	+15V, 10mA Max=HV Off
17	Remote HV Off Indicator	0=HV On, +15V, 10mA Max=HV Off
18	Remote HV On Indicator	0=HV Off, +15V, 10mA Max=HV On
19	Remote Voltage Mode	
20	Remote Current Mode	Open Collector 50V Max, 10mA Max
21	Remote Power Mode	On=Active
22	Remote PS Fault	0=Fault, +15V, 0.1mA Max=No Fault
23	+15V Output	+15V, 100mA Max
24	Power Supply Common	Signal Ground
25	Shield Return	Shield Return


HIGH VOLTAGE CONNECTOR PINOUT




DIMENSIONS: in.[mm]

FRONT VIEW 19.00 [482.6] 3.47 [88.1] 18.313 [465.1] 0.24 [6.0]

TOP VIEW



BACK VIEW







Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

FAX: +1-631-435-1620

+1-631-630-3000

PAGE 1 OF 4







Spellman's XRV series of X-Ray high voltage power supplies sets the standard for compact 1.8kW to 6.0kW, high performance X-Ray inspection generators. Spanning an output voltage range of 160kV to 450kV in negative, positive or bipolar output configurations, there's a model available for virtually every application requirement.

Active power factor correction circuitry reduces input current requirements while minimizing line related EMI. Spellman's proprietary inverter topology allows for unprecedented efficiencies and power densities. A solid encapsulated high voltage section further reduces size and weight and provides reliable, maintenance free operation.

DSP based SMT control circuitry provides your choice of USB, Ethernet and RS-232 along with analog interfacing, simplifying OEM system integration. The two DC output, current regulated filament power supplies are controlled via sophisticated emission current regulation circuitry to provide accurate and stable X-Ray tube currents. Comprehensive fault diagnostic circuitry, and Arc Sense, Arc Quench and Arc Count functionality is also incorporated into this compact, space saving X-Ray generator.

TYPICAL APPLICATIONS

Non Destructive Testing X-Ray Scanning Security Applications Medical Applications

OPTIONS

400Vac ±10% (6kW only) GUI Control Software for XRV XRVC (XRV Controller)

SPECIFICATIONS

Input Voltage:

1.8kW, 3.0kW, 4.0kW and 4.5kW models:

180-264Vac, single phase, 47-63 Hertz, active power factor corrected input to ≥0.98

6.0kW models:

208 or 400Vac, ±10%, three phase, 47-63 Hertz, passive power factor corrected

Input Current:

1.8kW, 3.0kW, 4.0kW and 4.5kW models: <30 amps 6.0kW models: <25 amps per phase for 208Vac <15 amps per phase for 400Vac

NOW AVAILABLE

1800 Watt units specifically designed for the HP and HPX families of X-Ray tubes used in high speed digital and industrial CT applications.

- 160kV, 225kV, 320kV, 350kV and 450kV Models
- Complete X-Ray Generator Package
- Power Factor Corrected AC Input Circuitry
- Integrated Dual Filament Supplies
- Digital Interface—USB, Ethernet and RS-232
- Excellent Stability and Regulation
- Available with Black Powder Coated Finish

Output Voltage:

Accuracy: 0.25%

Stability: ≤0.1% per 8 hours, after 1 hour warm up

1.8kW, 3.0kW, 4.0kW and 4.5kW models:

Load:±0.05% of rated output voltage for a full load change

Line: ±0.05% of rated output voltage over specified input voltage range

6.0kW models:

Load:±0.1% of rated output voltage for a full load change Line: ±0.1% of rated output voltage over specified input voltage range

Output Polarity:

See "model selection" table

Output Current:

See "model selection" table

Ripple:

See "model selection" table

Temperature Coefficient:

1.8kW, 3.0kW, 4.0kW and 4.5kW models:

±50ppm/°C

6.0kW models:

±50ppm/°C

Emission Current:

Accuracy: 0.25% Stability: 100ppm/°C

1.8kW, 3.0kW, 4.0kW and 4.5kW models:

Load: ±0.05% of rated output current for a change from 30% to 100% of rated output voltage

Line: ±0.05% of rated output current over specified

input voltage range

6.0kW models:

Load: ±0.1% of rated output current for a change from 30% to 100% of rated output voltage
Line: ±0.1% of rated output current over specified

input voltage range

Filament:

Output:

0-6 amps at a compliance of 10Vdc, maximum Dual Focal Spot:

Small and large, selectable via interface signal Configuration:

DC filament drive. Closed loop emission control regulates filament setting to provide desired X-Ray tube emission current



e-mail: sales@spellmanhv.com

PAGE 2 OF 4

Control Interface:

Remote Interface:

Analog, USB, Ethernet and RS-232 are standard

Control Software:

A Windows graphical user interface example is provided.

Environmental:

Temperature Range:

Operating: 0°C to 50°C Storage: -40°C to 85°C

Humidity

20% to 85% RH, non-condensing.

Mains Input Connector:

1.8kW, 3.0kW, 4.0kW and 4.5kW models:

Type 97-3102A-24-11P

6.0kW models:

Type 97-3102A-24-22P

Interface Connectors:

Digital—Ethernet, RS-232 and USB Analog—25 pin connector

Output Connector:

See "model selection" table

Cooling:

Forced air

Regulatory Approvals:

Compliant to EEC EMC Directive/Compliant to EEC Low Voltage Directive, all but 6000 watt unit. UL/CUL recognized, File E227588, all but 6000 watt unit. RoHS Compliant.

GUI Control Software for the XRV



- Automatic warm-up of the X-Ray tube
- Max watts operation
- Timed or Continuous Exposure modes
- Configuration menu for user options setting of HVPS
- Fault and status monitor

GUI is specifically designed for controlling XRV series power supplies. As an alternative to the analog control, the GUI will allow the user to control all necessary functions of the HVPS from a user-friendly windows based menu. Additionally the GUI can be used as a diagnostic tool when the HVPS is controlled via the analog interface.

XRV160/320/350 SPECIFICATIONS

	XRV160*1800	XRV160*3000	XRV160*4000	XRV160*6000	XRV320P&N1800	XRV320P&N4500	XRV350P&N4500
DC Output Voltage	5kV to 160kV	5kV to 160kV	5kV to 160kV	5kV to 160kV	5kV to ±160kV	5kV to ±160kV	5kV to ±175kV
Polarity*	Pos or Neg	Pos or Neg	Pos or Neg	Pos or Neg	Bipolar	Bipolar	Bipolar
Output Rated Current	0-30mA	0-30mA	0-50mA	0-50mA	0-30mA	0-30mA	0-30mA
Output Power	1.8kW	3.0kW	4.0kW	6.0kW	1.8kW	4.5kW	4.5kW
Ripple/Noise (p-p)	<0.025%	<0.05%	<0.1%	<0.25%	<0.025%	<0.1%	<0.1%
Dimensions	10.09″H x 17	.16"W x 24"D (2	56mm x 436mm x	609mm)	2X 10.09"H x 17.16	″W x 24″D (256mm x 4	136mm x 609mm)
Weight	150 lbs. (68kg)	150 lbs. (68kg)	150 lbs. (68kg)	155 lbs. (70.3kg)	300 lbs. (136 kg)	300 lbs. (136 kg)	300 lbs. (136 kg)
Output Connector	R24	R24	R24	R24	Two R24	Two R24	Two R24

XRV225/450 SPECIFICATIONS

	XRV225*1800	XRV225*3000	XRV225*4000	XRV225*6000	XRV450P&N1800	XRV450P&N4500
DC Output Voltage	5kV to 225kV	5kV to 225kV	5kVto 225kV	5kV to 225kV	5kV to ±225kV	5kV to ±225kV
Polarity*	Pos or Neg	Pos or Neg	Pos or Neg	Pos or Neg	Bipolar	Bipolar
Output Rated Current	0-30mA	0-30mA	0-30mA	0-30mA	0-30mA	0-30mA
Output Power	1.8kW	3.0kW	4.0kW	6.0kW	1.8kW	4.5kW
Ripple/Noise (p-p)	<0.025%	<0.05%	<0.1%	<0.25%	<0.025%	<0.1%
Dimensions	15.90″H	x 17″W x 30.72″D	(404mm x 432mm	x 780mm)	2X 15.90" H x 17" W x 30.72"[O (404mm x 432mm x 780mm)
Weight	240 lbs. (109kg)	240 lbs. (109kg)	240 lbs. (109kg)	240 lbs. (109kg)	480 lbs. (218 kg)	480 lbs. (218 kg)
Output Connector	R28**	R28**	R28**	R28**	Two R28**	Two R28**

Units are available in positive output polarity without filament, see model selection table for ordering details.

*Specify "P" for positive or "N" for negative polarity.

^{**}Order SHV HV cable flange p/n 407141-024 if using Comet HV cable with R28SL spring loaded plug.



J1 HV CONNECTOR—R24/R28

PIN	SIGNAL	PARAMETERS
С	HV Output	XRV160 and XRV320—R24 Connector XRV225 and XRV450—R28 Connector
S	Small Filament Output	0 to 6 amps @ 10Vdc
L	Large Filament Output	0 to 6 amps @ 10Vdc

J2 ANALOG INTERFACE - 25 PIN D CONNECTOR

Power Supply Fault	PIN	SIGNAL	PARAMETERS
open collector, 50V @ 10mA max mA Program loto 10V FS Z in = 10M ohms Filament Limit L/S Ref.* loto 10V FS Z in = 10M ohms Filament Preheat L/S Ref.* loto 10V FS Z in = 10M ohms Filament Preheat L/S Ref.* loto 10V FS Z in = 10M ohms Filament Preheat L/S Ref.* loto 10V FS Z in = 10M ohms loto 10V FS Z out = 4.99k ohms loto 10V FS Z out = 4.99k ohms Filament Current Monitor loto 10V FS Z out = 4.99k ohms Filament Current Monitor* loto 10V FS Z out = 4.99k ohms Filament Current Monitor* loto 10V FS Z out = 4.99k ohms Filament Current Monitor* loto 10V FS Z out = 4.99k ohms Filament Current Monitor* loto 10V FS Z out = 4.99k ohms Filament ON status, low, filament is ON open collector 50V, @ 10mA max loto 10V FS Z out = 4.99k ohms Filament ON status, low, filament is ON open collector 50V, @ 10mA max filament Current Monitor* Active low, interlock is closed, safe to enable HV loto 10V FS Z out = 4.99k ohms Filament Enable* Active low, interlock is closed, safe to enable HV loto 20V Government of the status of t	1	Power Supply Fault	Low, sum of faults, HVPS detected a fault,
3 kV Program			
4 Filament Limit L/S Ref.* 0 to 10V FS Z in = 10M ohms 5 Filament Preheat L/S Ref.* 0 to 10V FS Z in = 10M ohms 6 kV Monitor 0 to 10V FS Z out = 4.99k ohms 7 mA Monitor 0 to 10V FS Z out = 4.99k ohms 8 Filament Current Monitor* 0 to 10V FS Z out = 4.99k ohms 9 Signal Ground Ground 10 X-Ray Enable +24Vdc = X-Ray ON, connect to pin 14 with dry contact relay 11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON Status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	2	mA Program	0 to 10V FS Z in = 10M ohms
5 Filament Preheat L/S Ref.* 0 to 10V FS Z in = 10M ohms 6 kV Monitor 0 to 10V FS Z out = 4.99k ohms 7 mA Monitor 0 to 10V FS Z out = 4.99k ohms 8 Filament Current Monitor* 0 to 10V FS Z out = 4.99k ohms 9 Signal Ground Ground 10 X-Ray Enable +24Vdc = X-Ray ON, connect to pin 14 with dry contact relay 11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc	3	kV Program	0 to 10V FS Z in = 10M ohms
6 kV Monitor 0 to 10V FS Z out = 4.99k ohms 7 mA Monitor 0 to 10V FS Z out = 4.99k ohms 8 Filament Current Monitor* 0 to 10V FS Z out = 4.99k ohms 9 Signal Ground Ground 10 X-Ray Enable +24Vdc = X-Ray ON, connect to pin 14 with dry contact relay 11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, turn filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	4	Filament Limit L/S Ref.*	0 to 10V FS Z in = 10M ohms
7 mA Monitor 0 to 10V FS Z out = 4.99k ohms 8 Filament Current Monitor* 0 to 10V FS Z out = 4.99k ohms 9 Signal Ground Ground 10 X-Ray Enable +24Vdc = X-Ray ON, connect to pin 14 with dry contact relay 11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	5	Filament Preheat L/S Ref.*	0 to 10V FS Z in = 10M ohms
8 Filament Current Monitor* 0 to 10V FS Z out = 4.99k ohms 9 Signal Ground Ground 10 X-Ray Enable +24Vdc = X-Ray ON, connect to pin 14 with dry contact relay 11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	6	kV Monitor	0 to 10V FS Z out = 4.99k ohms
9 Signal Ground 10 X-Ray Enable +24Vdc = X-Ray ON, connect to pin 14 with dry contact relay 11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	7	mA Monitor	0 to 10V FS Z out = 4.99k ohms
10 X-Ray Enable +24Vdc = X-Ray ON, connect to pin 14 with dry contact relay 11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	8	Filament Current Monitor*	0 to 10V FS Z out = 4.99k ohms
11 Filament ON* Filament ON status, low, filament is ON open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	9	Signal Ground	Ground
open collector 50V, @ 10mA max 12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition Low, arc fault, the HVPS has detected an arc	10	X-Ray Enable	+24Vdc = X-Ray ON, connect to pin 14 with dry contact relay
12 Interlock 1 Active low, interlock is closed, safe to enable HV 13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	11	Filament ON*	Filament ON status, low, filament is ON
13Interlock 2 Active low, interlock is closed, safe to enable HV 14 +24Vdc +24Vdc 0100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V 010mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V 010mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V 010mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V 010mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V 010mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc			
14 +24Vdc +24Vdc @ 100mA, maximum 15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc			,
15 Filament Enable* Active low, turn filament ON 16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc			
16 Filament Control* Active low, filament is regulated by ECR (HV must be ON). Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc			
Not active, the filament is regulated by the preheat reference 17 Filament L/S Select Filament selection large or small, low = small spot is selected 18 Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc			
Filament L/S Select Filament selection large or small, low = small spot is selected Open collector, 50V @ 10mA max Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition Low, arc fault, the HVPS has detected an arc	16		
Filament L/S Confirm Open collector, 50V @ 10mA max Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max Z-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 20 GND Digital ground X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max Active low, minimum 10mS transition Low, arc fault, the HVPS has detected an arc			
Filament selection confirm, low = small spot is selected 19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max 20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc			
19 HVPS RDY Low = HVPS ready, open collector, 50V @ 10mA max X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 10 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 11 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 12 GND Digital ground Digital ground Y-re-warning, low, before X-Ray ON open collector, 50V @ 10mA max 13 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 14 Reset Active low, minimum 10mS transition 15 Arc fault Low, arc fault, the HVPS has detected an arc	18	Filament L/S Confirm	
20 X-Ray ON X-Ray ON status, low = X-Rays are ON open collector, 50V @ 10mA max 21 Interlock Status Low, interlocks are closed, can enable HV open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	40	L II / DO DD) /	
open collector, 50V @ 10mA max 21 Interlock Status			37 1
open collector, 50V @ 10mA max 22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	20	X-Ray ON	
22 GND Digital ground 23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	21	Interlock Status	
23 X-Ray ON Pre-Warn Pre-warning, low, before X-Ray ON open collector, 50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc	22	GND	
50V @ 10mA max 24 Reset Active low, minimum 10mS transition 25 Arc fault Low, arc fault, the HVPS has detected an arc			8 8
25 Arc fault Low, arc fault, the HVPS has detected an arc	دے	A-nay Olvi 16-vvaiii	50V @ 10mA max
open collector, 50V @ 10mA max	25	Arc fault	
			open collector, 50V @ 10mA max

^{*}Not active on positive models

MODEL SELECTION TABLE

MODEL	VOLTAGE	POWER	POLARITY
XRV160*1800	160kV	1.8kW	Pos or Neg
XRV160*3000	160kV	3.0kW	Pos or Neg
XRV160*4000	160kV	4.0kW	Pos or Neg
XRV160*6000/208V	160kV	6.0kW	Pos or Neg
XRV160*6000/400V	160kV	6.0kW	Pos or Neg
XRV225*1800	225kV	1.8kW	Pos or Neg
XRV225*3000	225kV	3.0kW	Pos or Neg
XRV225*4000	225kV	4.0kW	Pos or Neg
XRV225*6000/208V	225kV	6.0kW	Pos or Neg
XRV225*6000/400V	225kV	6.0kW	Pos or Neg
XRV320P&N1800	±160kV	1.8kW	Bipolar
XRV320P&N4500	±160kV	4.5kW	Bipolar
XRV350P&N4500	±175kV	4.5kW	Bipolar
XRV450P&N1800	±225kV	1.8kW	Bipolar
XRV450P&N4500	±225kV	4.5kW	Bipolar

^{*}Specify P for positive polarity and N for negative polarity. Positive polarity models do not have integrated filament power supplies. Contact Spellman for custom output voltage/power models.

RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	TX out	Receive Data
3	RX in	Transmit Data
4	N/C	No Connection
5	SGND	Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

ETHERNET DIGITAL INTERFACE— J4 8 PIN RJ45 CONNECTOR

PIN	SIGNAL	PARAMETERS
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receive Data +
4	N/C	No Connection
5	N/C	No Connection
6	RX-	Receive Data -
7	N/C	No Connection
8	N/C	No Connection

USB DIGITAL INTERFACE— J5 4 PIN USB "B" CONNECTOR

PIN	SIGNAL	PARAMETERS
1	VBUS	+5 Vdc
2	D-	Data -
3	D+	Data +
4	GND	Ground

JB1 MAIN AND AUXILIARY INPUT POWER— TYPE 97-3102A-24-11P (Single Phase Units)

PIN	SIGNAL	PARAMETERS
Α	Auxiliary AC Line Power	180-264Vac
В	Auxiliary Ground	Ground
С	Auxiliary AC Neutral	Neutral
D	Main AC Line Power	180-264Vac
Е	Main Ground	Ground
F	Main AC Neutral	Neutral

JB1 MAIN AC INPUT POWER— TYPE 97-3102A-24-22P (Three Phase Units)

PIN	SIGNAL	PARAMETERS
Α	Line 1	208Vac, ±10%, 50/60Hz @ 25 amps
В	Line 2	208Vac, ±10%, 50/60Hz @ 25 amps
С	Line 3	208Vac, ±10%, 50/60Hz @ 25 amps
D	GND	Ground

Note: Use 4 conductor cable or single isolated wires rated no less that 600Vac, 30 amps (10AWG, minimum) $\,$

JB2 AUXILIARY AC INPUT POWER— TYPE 97-3102A-20-3P (Three Phase Units)


PIN	SIGNAL	PARAMETERS
Α	Line 1	208Vac, ±10%, 50/60Hz (source 3 phase L1, L2)
В	Line 2	208Vac, ±10%, 50/60Hz (source 3 phase L1, L2)
С	GND	Ground

System Ground: System ground wires (10AWG minimum) to the ground terminal E1 GND to the power supply using ground stud M6 X 20MM, with M6 nut.

Corporate Headquarters Hauppauge, New York USA +1-631-630-3000 FAX: +1-631-435-1620 e-mail: sales@spellmanhv.com



XRV160 TOP VIEW



DIMENSIONS: in.[mm]

XRV225 TOP VIEW




FRONT VIEW




FRONT VIEW



REAR VIEW



XRV320 is comprised of two XRV160 units configured in a bipolar arrangement



XRV450 is comprised of two XRV225 units configured in a bipolar arrangement



Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

+1-631-630-3000 FAX: +1-631-435-1620

PAGE 1 OF 2



Spellman's DF/FF Series of X-Ray Generators feature our new inverter design which incorporates IGBTs for power switching and provides new levels of reliability. In addition, re-engineering of the DF/FF's internal filament power supply eliminates audio noise at normal operating levels by operating at a higher frequency. The DF/FF's utilize a sine wave current source, produced by phase shifting series resonant circuits at switching frequencies greater than 20kHz to generate high voltage dc. This technique eliminates undesirable electromagnetic radiation normally associated with switching and power control regulators. The high efficiency of these units allows for air cooling in a 5.25" (3U) high chassis.

TYPICAL APPLICATIONS

X-Ray Diffraction (XRD) X-Ray Fluorescence (XRF)

OPTIONS

220FSI 220Vac Fail Safe Interlock 208-3P 208Vac Three Phase Input

SPECIFICATIONS

Input Voltage:

220Vac ±10%, 50-60Hz, single phase (three phase optional)

Input Current:

3kW: 220Vac @ 29.5A, single phase 208Vac @ 12.8A/phase, three phase 4kW: 220Vac @ 39.3A, single phase

208Vac @ 17.0A/phase, three phase

Output Voltage:

DF3: 0 to 60kV negative polarity FF3: 0 to 60kV positive polarity Other output voltages are available

Output Current:

DF3: 0 to 80mA **FF3:** 0 to 100mA

Other output currents are available

Maximum Output Power:

3kW (4kW optional)

Output Voltage Regulation:

Load: 0.005% of rated output for full load change Line: 0.005% of rated output over specified input range Temperature Coefficient: 50 ppm/°C (20 ppm/°C optional) Long Term Stability: 0.01%/8 hours.

Ideal for Common XRD & XRF X-Ray Tubes

- Compact Size, 5 1/4" (3U) High Chassis
- Solid Encapsulantion Insures Maintenance-Free Operation
- Auto Ramp of the HV Emission Current to Preset Values
- OEM Customization Available

Emission Current Regulation:

Load: 0.01% of rated output for a 10 to 60kV change Line: 0.005% of rated output over specified inputs Temperature Coefficient: 50 ppm/°C Long Term Stability: 0.01%/8 hours

Ripple:

0.03% rms <1kHz, 0.75% rms above 1kHz

Environmental:

Temperature Range:

Operating: 0°C to 40°C Storage: -20°C to 85°C

Humidity:

10% to 90%, non-condensing

Filament Voltage:

DF: 12Vac FF: 12Vdc

Filament Current:

5A (up to 12A max available)

5.25"(3U) H x 19" W x 22" D (13.3cm x 48.3cm x 55.9cm)

Weight:

90lbs (40kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive.

ADDITIONAL FEATURES

Water Flow Switch:

A 24Vdc signal is available on the rear panel to turn on the cooling water to the X-Ray tube. This signal can be enabled either when control power is on or when the high voltage is turned on. (Customer must specify)

Fail Safe Interlock:

A 24Vdc signal is available on the rear panel to energize an external X-Ray on lamp. This signal is energized when the high voltage is turned on. High voltage will not enable if this circuit is open. (A 220Vac signal is optional)

Preheat and Ramp:

Automatic preheat and ramp control circuits are provided which ramp the kV and mA slowly to set levels. kV ramps in approximately 10 seconds while mA ramps in approximately 20 seconds.

Output Connector:

75kV, 3 conductor Federal Standard X-Ray connector. 60kV is connect ed to terminal "C". Terminals "S" and "L" are jumped together. The filament output is connected between terminals "C" and "S". Other configurations are optional. (On the FF3, all output connections S, L, & C are connected together)

Remote Signal Connector:

Remote interface is available via a 50 pin mini D connector. Extensive remote programming and monitoring is provided.

Electronic Component (Power Source)


DF/FF series is intended for installation as a component of a system. It is designed to meet CE standards, with conditions of acceptance often being: customer provided enclosure mounting, EMC filtering, and appropriate protection, and isolation devices. The DF/FF series is not intended to be operated by end users as a stand-alone device. The DF/FF series power supply can only be fully assessed when installed within a system, and as a component part within that system.


JB1 MINI D CONNECTOR 50 PIN

PIN	SIGNAL
1	
2	+5Vdc (or connect to pin-11) Control Power On
3	Intlk
4	-
5	X-Ray On X-Ray Off
6	Spare
7	Spare
8	Reset
9	Reset Rmt/Lcl
10	24V Switched
11	+5Vcch
12	X-Ray On Status
13	
14	Overvoltage
15	kV Min Overpower
	Filament Current Limit
16 17	mA Current Limit
18	LCL Status
19	
20	Power Supply Fault Gnd
21	
	Spare (DE) Pomete V Pou On
22	(DF) Remote X-Ray On
23 24	(DF) Remote X-Ray On Ret
	Spare
25	Gnd
26 27	kV Ref kV Com
28	mA Ref
29 30	mA Com
31	Spare Spare
32 33	Spare
33	Pwr. Limit (OL Ref) Pwr. Limit Com (OL Com)
35	Filament Current Limit
36	Filament Current Limit Filament Current Limit Com
36	Spare
38	kV Monitor
39	mA Monitor
40	Spare
41	Spare kV Ref Mon
43	mA Ref Mon
43	
44	Spare
	Spare
46	Filament Monitor
47	Mon Common
48	Spare
49	Gnd
50	Spare

DIMENSIONS: in.[mm]

FRONT VIEW





BACK VIEW 17.00 [431.80] 6 ft OF LINE CABLE SUPPLIED WITH UNIT



Cost reduced version for OEM quantities available, contact Sales.











Spellman's VMX redefines the standard for high performance, low cost Mammography X-Ray generators. The VMX was born from an integrated, high performance, value added design perspective so there's no need to compromise critical specifications to meet ever demanding system price targets.

The 40kV/5kW X-Ray generator integrates a dual filament power supply and a dual speed starter. A DC current source filament power supply provides fast rise times with stable and accurate X-Ray tube emission currents. The solid encapsulated high voltage output section eliminates oil concerns while reducing the effects of environmental humidity and contamination.

Flexibility in interfacing is provided via RS-232 and optional Ethernet connectivity. The VMX supports advanced mammography application features including Smart AEC Exposure, Automatic Filament Calibration, Tube Anode Heat Calculator and user configurable Tube Library. Compact, full featured, high performance, low cost. Spellman's VMX, the next generation Mammography X-Ray generator.

SPECIFICATIONS

Input Voltage:

200-240Vac (±10%), single phase, 50Hz/60Hz

Input Current:

Minimum 35A service recommended for 5kW operation External EMC Filter (Schaffner FN2070-36-08-36A) required to meet CE/EMC specifications – Not provided with the generator

Mains Contactor – Not provided within the generator. Customer is responsible for mains safety disconnection.

Output Voltage

Output Voltage Range:

20kV to 40kV

Polarity:

Positive, grounded cathode X-Ray tube

Accuracy:

Within 1% of programmed values

Reproductibility:

<0.5%

Settling Time:

<10ms

- Custom Designed Specifically for Mammography Applications
- Compact Space Saving Modular Format
- Fast Settling Helps Minimize Unnecessary Patient Radiation Exposure
- Dual Speed Starter, Boost/Brake Capability
- RS-232 and Optional Ethernet Interfaces
- Low Cost, Value Added Design

Ripple:

≤1%

Stability:

≤0.01% per 8 hours

Temperature Coefficient:

 $\leq 100 ppm/^{\circ}C$

Output Current/Power

Output Current Range:

10mA to 200mA

Output Power:

5kW @ 0.1 second loading time 30W maximum average power

Maximum mAs:

600mAs

Exposure Timer:

5ms-10 seconds

Accuracy:

Within 2% of programmed values measured after mA rises to stable DC level

Reproductibility:

<0.5%

Settling Time:

<10ms

Filament Configuration:

DC filament drive: self corrected filament preheat settings with closed loop emission control and smart learning algorithm

Filament Output:

0-6 amps at a compliance of 5.5 volts, maximum

Dual Speed Starter:

High speed (180Hz) and low speed (60Hz) can be configured via the serial interface. Boost and Brake capability provided.

High Voltage Connector:

60kV, Claymount CA-3 type or equivalent

Optional Communication Interface:

Ethernet (RJ45)

Grounding Point:

M5 ground stud provided on chassis

Environmental:

Temperature Range:
Operating: 10°C to 40°C
Storage: -40°C to 85°C
Humidity:

20% to 85% RH, non-condensing.



PAGE 2 OF 3

Cooling:

Convection cooled, no internal fans. Forced air cooling not required

Dimensions:

9.38" H X 6.6" W X 12" D (237.5mm x 167.6mm x 304.8mm)

Weight:

<22 pounds (10kg)

Regulatory Approvals:

Compliant to EMC:IEC 60601-1-2. UL/CUL recognized file E242584. RoHS compliant.

Application Features:

- 2 point/3 point exposure modes
- AEC/Smart AEC exposure modes
- · Automatic filament current calibration
- · Tube anode heat calculator
- User configurable tube library

TB2 ROTOR INTERFACE

I	PIN	SIGNAL	PARAMETERS
	TB2-1	PHASE	To tube auxiliary winding
		RUN	To tube principle winding
	TB2-3	COM	To tube common winding
Г	TB2-4	GROUND	To tube housing ground

TB3 TUBE AND INTERLOCK INTERFACE

PIN	SIGNAL	PARAMETERS
TB3-1	SMALL FIL	Connection to tube small filament
TB3-2	COMMON	Connection to tube filament common
TB3-3	LARGE FIL	Connection to large filament
TB3-4	GROUND	Generator chassis for cable shield connection
TB3-5	Interlock 2+	Used if tube has separate thermostat switch.
TB3-6	Interlock 2-	Open = OVER TEMP. (short terminals if not used)
TB3-7	Interlock 3+	Used if tube has cooling circulator flow switch.
TB3-8	Interlock 3-	Open = NO FLOW. (short terminals if not used)
TB3-9	Safety Interlock+	User signal (Contact Closure) for safety interlocks
TB3-10	Safety Interlock-	such as door interlocks. Open turns HV OFF, or inhibits HV from being generated.
		Closed = OK 24Vdc @ <1A typical
TB3-11	Contactor Coil+	Option for contactor coil control
TB3-12	Contactor Coil-	
TB3-13	Spare	N/C
TB3-14	Spare	N/C
TB3-15	Tube Current+	Tube current flows out from this pin
TB3-16	Tube Current-	Tube current flows into this pin


VMX STANDARD SYSTEM INTERFACE— JB1 25 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	GND	Signal Ground
2	+5Vdc Out	+5Vdc, 100mA max.
3	RS-232 Tx Out	RS-232 Transmit
4	RS-232 Rx In	RS-232 Receive
5	PREP	User signal (Contact Closure) to alert the generator that exposure sequence will begin. Once this signal is active, exposure parameters are locked in and cannot be changed. The generator enables the starter to to boost the rotor. Contact connection to pin 24. Closed = PREP, the filament is placed in preheat mode
6	READY	Generator signal to user to indicate the rotor runs to speed and the generator is ready for X-Ray exposure Open Collector. Low/Active = Ready
7	ROTOR SHUTDOWN	User signal to brake the rotor drive
8	EXPOSURE	User signal (Contact Closure) to generator to generate X-Rays. Filament is boosted, and high voltage is generated after the boost time. Contact connection to pin 24. Closed = Exposure
9	X-Ray ON 75% Status	Transistor output to indicate X-Ray ON status synchronized with 75% of kVP setting point.
10	X-Ray ON Status	Transistor output to indicate X-Ray ON status synchronized with kV start up.
11	N/C	N/C
12	X-Ray SHUTDOWN/AEC	User signal to generator to rapidly turn HV OFF and ON during serial exposure sequence
13	RS-232 ISO Ground	Isolated ground from RS-232 transceiver IC
14	HVG FAULT Status	Generator signal indicating generator fault. Open collector transistor output. Low/Active = Fault
15	Status Bit 1	3 bit status lines for up to 6 status messages. See
16	Status Bit 2	separate matrix descibing functionality. Open
17	Status Bit 3	Collector. Low/Active = Message
18	N/C	N/C
19	N/C	N/C
20	kV Monitor	Signal from generator. $0-10V = 0-40kV$. Zout = $1k\Omega$
21	Emission Monitor	Signal from generator. 0-10V = 0-200mA. Zout = $1k\Omega$
22	Filament Current Monitor	Signal from generator. $0-10V = 0-6A$. Zout = $1k\Omega$
23	Program/Monitor Return	Ground for reference of program and monitor signals
24	+24Vdc Out	For connection to PREP and EXPOSURE control relay coils
25	SHIELD/GND	For connection of interface cable shield to generator chassis ground




DIMENSIONS: in.[mm]


FRONT VIEW




TOP VIEW



BOTTOM VIEW



SIDE VIEW













- **Mammography Applications**
 - Compact Space Saving Modular Format

Custom Designed Specifically for

- Fast Rise and Fall Times Help Minimize Unnecessary Patient Radiation Exposure
- Dual Speed Starter, Boost/Brake Capability
- RS-232 and Optional Ethernet Interfaces

Spellman's PMX is a high performance X-Ray generator designed specifically for mammography applications including FFDM and DBT. It features 2 and 3 point exposure modes as well as smart AEC with a pre exposure.

The PMX is a 5kW high frequency X-Ray generator integrated with a dual filament power supply, and a dual speed X-Ray tube starter. Due to the PMX's superior power conversion technology and inverter design it can provide stable and accurate X-Ray tube high voltage with fast rise and fall times.

Smooth system integration of the PMX is accomplished through the use of RS-232 and optional Ethernet digital interface, preloaded X-Ray tube parameters, easy access interlocks and I/O connections, and internal generator diagnostics. Optional GUI utility software is also offered to help with initial system integration.

SPECIFICATIONS

Input Voltage:

200-240Vac (±10%), single phase, 50Hz/60Hz

Input Current:

Minimum 35A service recommended for 5kW operation External EMC Filter (Schaffner FN2070-36-08-36A) required to meet CE/EMC specifications - Not provided

Mains Contactor - Not provided

Customer is responsible for mains safety disconnection.

Output (Tube) Voltage

Output Voltage Range:

20kV to 49kV

Polarity:

Positive, grounded cathode X-Ray tube

Accuracy:

2% (measured per IEC60601-2-45)

Reproductibility:

< 0.5%

Rise Time:

<1ms to within 98% of the programmed voltage

<10ms with a max HV cable length of 8 feet (2.4 meters)

Ripple:

≤4% p-p

Output (Tube) Current/Power:

Output Current Range:

10mA to 200mA

Output Power:

5kW @ 0.1 second loading time, 300 Watts maximum average power

< ±10% on exposure less than 10ms (measured per IEC60601-2-45)

Rise Time:

<1ms to within 95% of the programmed mA value

<10ms with a maximum HV cable length of 8 feet (2.4 meters)

Exposure Time (Loading Time):

Maximum Single Exposure Time:

10 seconds

Shortest Single Exposure Time:

5ms

Loading time accuracy:

±3% +1ms (measured per IEC60601-2-45)

Maximum mAs:

600mAs

Exposure Timer:

5mS-10 seconds

Accuracy:

< ±10% (measured per IEC60601-2-45)

Reproductibility:

< 0.5%

Filament Configuration:

DC filament drive: self corrected filament preheat settings with closed loop emission control and smart learning algorithm

Filament Output:

0-6 amps at a compliance of 5.5 volts, maximum.

Dual Speed Starter:

High speed (180Hz) and low speed (60Hz) can be configured via the serial interface.

Boost and Brake capability provided.



e-mail: sales@spellmanhv.com

111



High Voltage Connector:

60kV, Claymount CA-3 type or equivalent

Communication Interface:

RS-232 standard, optional Ethernet

Grounding Point:

M5 ground stud provided on chassis

Environmental:

Temperature Range: Operating: 10°C to 40°C Storage: -40°C to 85°C Humidity:

20% to 85% RH, non-condensing.

Cooling:

Internal fan

Dimensions:

9.47"H X 7.19"W X 13.72"D (240.5mm x 182.6mm x 348.5mm)

Weight:

<23 pounds (10.5kg)

Regulatory Approvals:

Designed to meet EMC:IEC 60601-1-2. UL/CUL recognized file E242584. RoHS compliant.

Application Features:

- 2 point/3 point exposure modes
- AEC/Smart AEC exposure modes
- Dual Speed Starter
- X-Ray tube anode heat calculator
- Preloaded X-Ray tube parameters and expandable X-Ray tube library

TB3 TUBE AND INTERLOCK INTERFACE

PIN	SIGNAL	PARAMETERS
TB3-1	SMALL FIL	Connection to tube small filament
TB3-2	COMMON	Connection to tube filament common
TB3-3	LARGE FIL	Connection to large filament
TB3-4	GROUND	Generator chassis for cable shield connection
TB3-5	Interlock 2+	Used if tube has separate thermostat switch.
TB3-6	Interlock 2-	Open = OVER TEMP. (short terminals if not used)
TB3-7	Interlock 3+	Used if tube has cooling circulator flow switch.
TB3-8	Interlock 3-	Open = NO FLOW. (short terminals if not used)
TB3-9	Safety Interlock+	User signal (Contact Closure) for safety interlocks
TB3-10	Safety Interlock-	such as door interlocks. Open turns HV OFF, or inhibits HV from being generated.
TD0 //	0 0 !!	Closed = OK 24Vdc @ <1A typical
TB3-11	Contactor Coil+	Option for contactor coil control
TB3-12	Contactor Coil-	
TB3-13	Spare	N/C
TB3-14	Spare	N/C
TB3-15	Tube Current+	Tube current flows out from this pin
TB3-16	Tube Current-	Tube current flows into this pin

TB2 ROTOR INTERFACE

PIN	SIGNAL	PARAMETERS
TB2-1	PHASE	To tube auxiliary winding
TB2-2	RUN	To tube principle winding
TB2-3	COM	To tube common winding
TB2-4	GROUND	To tube housing ground

PMX STANDARD SYSTEM INTERFACE— **JB1 25 PIN MALE D CONNECTOR**

PIN	SIGNAL	PARAMETERS
1	GND	Signal Ground
2	+5Vdc Out	+5Vdc, 100mA max.
3	RS-232 Tx Out	RS-232 Transmit
4	RS-232 Rx In	RS-232 Receive
5	PREP	User signal (Contact Closure) to alert the generator that exposure sequence will begin. Once this signal is active, exposure parameters are locked in and cannot be changed. The generator enables the starter to to boost the rotor. Contact connection to pin 24. Closed = PREP, the filament is placed in preheat mode
6	READY	Generator signal to user to indicate the rotor runs to speed and the generator is ready for X-Ray exposure Open Collector. Low/Active = Ready
7	ROTOR SHUTDOWN	User signal to brake the rotor drive
8	EXPOSURE	User signal (Contact Closure) to generator to generate X-Rays. Filament is boosted, and high voltage is generated after the boost time. Contact connection to pin 24. Closed = Exposure
9	X-Ray ON 75% Status	Transistor output to indicate X-Ray ON status synchronized with 75% of kVP setting point.
10	X-Ray ON Status	Transistor output to indicate X-Ray ON status synchronized with kV start up.
11	N/C	N/C
12	X-Ray SHUTDOWN/AEC	User signal to generator to rapidly turn HV OFF and ON during serial exposure sequence
13	RS-232 ISO Ground	Isolated ground from RS-232 transceiver IC
14	HVG FAULT Status	Generator signal indicating generator fault. Open collector transistor output. Low/Active = Fault
15	Status Bit 1	3 bit status lines for up to 6 status messages. See
16	Status Bit 2	separate matrix descibing functionality. Open
17	Status Bit 3	Collector. Low/Active = Message
18	N/C	N/C
19	N/C	N/C
20	kV Monitor	Signal from generator. $0.10V = 0.50kV$. Zout = $1k\Omega$
21	Emission Monitor	Signal from generator. $0.10V = 0.200\text{mA}$. Zout = $1\text{k}\Omega$
22	Filament Current Monitor	Signal from generator. $0-10V = 0-6A$. Zout = $1k\Omega$
23	Program/Monitor Return +24Vdc Out	Ground for reference of program and monitor signals For connection to PREP and EXPOSURE control
24	+24vac Out	relay coils
25	SHIELD/GND	For connection of interface cable shield to generator chassis ground




DIMENSIONS: in.[mm]


FRONT VIEW




SIDE VIEW



TOP VIEW



BOTTOM VIEW







The PMX70 is Spellman's new high performance X-Ray generator designed to power Varex Mammography X-Ray tubes. It features a 12kW peak high frequency inverter and high voltage section complete with a smart learning filament power supply and high speed starter. State of the art power conversion technology provides stable and accurate X-Ray tube high voltage with fast rise and fall times. Ethernet and RS-232 interfacing provides easy system integration. Preloaded X-Ray tube parameters, easy access interlocks and I/O connections, and internal generator diagnostics. Optional GUI utility software is also offered to help with initial system integration.

SPECIFICATIONS

Input Voltage:

230Vac ±10%, single phase, 50Hz/60Hz

Input Current:

30 amps, customer to fuse.

Mains Contactor - not provided.

Customer is responsible for mains safety disconnection.

Less than 30 amps over a typical scan is defined as following: Due to unknown line impeadance, customer supllied external inductors 100uH to 300uH in series with input connections, (200uH to 600uH total), may be required to keep rms currents below 30 amps and to avoid erroneous circuit breaker trips. Spellman can recommend appropriate inductors as required.

Output (Tube) Voltage Output Voltage Range:

-25kV to -70kV

Polarity:

Negative output polarity; to drive rotating anode, floating cathode X-Ray tube (Varex M-1581).

Accuracy:

2% (measured per IEC60601-2-45)

Reproductibility:

< 0.5%

Output (Tube) Current/Power Output Current Range:

10mA to 200mA

Output Power:

12kW peak, 400 watt average.

- Compact Space Saving Modular Format
- Fast Rise/Fall Time Minimize Patient Exposure
- High Speed Starter, Boost/Brake Capability
- Ethernet/RS-232 Interfaces

Duty Cycle:

25%. A typical scan being at fixed settings in the range of 40kV-70kV and 16mA-200mA. Pulsed operation is supported.

Accuracy

< ±10% on exposure less than 10ms (measured per IEC60601-2-45)

Rise Time:

1-2 milliseconds, typical (HV cable dependent). Fall time is load dependant, and the HV cable is a significant factor. The HV cable which is not provided with the PMX70, has a maximum length of 8 feet (2.4m).

Fall Time:

<10ms with a HV cable length of 8 feet (2.4 meters)

Exposure Time (Loading Time):

Maximum Single Exposure Time:

20 seconds

Shortest Single Exposure Time:

4ms

Loading time accuracy:

±3% +1ms (measured per IEC60601-2-45)

Maximum mAs:

3200mAs

Exposure Timer:

4ms-20 seconds

Reproductibility:

< 0.5%

Filament Configuration:

AC high frequency filament drive: self-corrected filament preheat settings with closed loop emission control and smart learning algorithm.

Filament Output:

0-6 amps at a compliance of 5.5 volts, maximum.

High Speed Starter:

High speed (360Hz) starter configured via the serial interface. Boost and Brake capability provided.

AC Input Connector:

Two position terminal block

System Interface Connector:

25 pin male D connector

Rotor Interface Connector:

Four position terminal block

Tube and Interlock Interface Connector:

16 pin terminal block



e-mail: sales@spellmanhv.com



High Voltage Connector:

Claymount CA-11 type or equivalent.

Communication Interface Connector:

Ethernet, RJ45 jack

Grounding Point:

M5 ground stud provided on chassis

Environmental:

Temperature Range:
Operating: 10°C to 40°C
Storage: -40°C to 85°C
Humidity:

20% to 85% RH, non-condensing.

Cooling:

Forced air, internal fan

Dimensions:

10.08" H X 19.49" W X 10.75" D (256mm x 495mm x 273mm)

Weight:

48.5 pounds (22.0kg)

Rotational Capability:

Capable of working on a rotating gantry with a nominal rotating speed of 0.5 Hertz.

Regulatory Approvals:

Designed to comply with IEC 60601. RoHS Compliant. Customer provided external EMC filter may be required to meet CE/EMC specifications.

X-Ray Tube Compatibility:

Varex M-1581

PMX70 STANDARD SYSTEM INTERFACE— JB1 25 PIN MALE D CONNECTOR

Р	IN	SIGNAL	PARAMETERS
Г	1	GND	Signal Ground
Г	2	+5Vdc Out	+5Vdc, 100mA max.
Г	3	RS-232 Tx Out	RS-232 Transmit
	4	RS-232 Rx In	RS-232 Receive
	5	PREP	User signal (Contact Closure) to alert the generator that exposure sequence will begin. Once this signal is active, exposure parameters are locked in and cannot be changed. The generator enables the starter to to boost the rotor. Contact connection to pin 24. Closed = PREP, the filament is placed in preheat mode
	6	READY	Generator signal to user to indicate the rotor runs to speed and the generator is ready for X-Ray exposure Open Collector. Low/Active = Ready
Г	7	ROTOR SHUTDOWN	User signal to brake the rotor drive
	8	EXPOSURE	User signal (Contact Closure) to generator to generate X-Rays. Filament is boosted, and high voltage is generated after the boost time. Contact connection to pin 24. Closed = Exposure
	9	X-Ray ON 75% Status	Transistor output to indicate X-Ray ON status synchronized with 75% of kVP setting point.
'	10	X-Ray ON Status	Transistor output to indicate X-Ray ON status synchronized with kV start up.
Г	11	N/C	N/C
	12	X-Ray SHUTDOWN/AEC	User signal to generator to rapidly turn HV OFF and ON during serial exposure sequence
-	13	RS-232 ISO Ground	Isolated ground from RS-232 transceiver IC
	14	HVG FAULT Status	Generator signal indicating generator fault. Open collector transistor output. Low/Active = Fault
Ŀ	15	Status Bit 1	3 bit status lines for up to 6 status messages. See
_	16	Status Bit 2 Status Bit 3	separate matrix descibing functionality. Open
_	17 18	N/C	Collector. Low/Active = Message N/C
	19	N/C	N/C
_	20	kV Monitor	Signal from generator. 0-10V = 0-50kV. Zout = $1k\Omega$
	-0 21	Emission Monitor	Signal from generator. 0-10V = 0-200mA. Zout = $1k\Omega$
	22	Filament Current Monitor	Signal from generator. 0-10V = 0-6A. Zout = $1k\Omega$
- 1-	23	Program/Monitor Return	Ground for reference of program and monitor signals
_	24	+24Vdc Out	For connection to PREP and EXPOSURE control relay coils
4	25	SHIELD/GND	For connection of interface cable shield to generator chassis ground

PAGE 3 OF 3


TB2 ROTOR INTERFACE

PIN	SIGNAL	PARAMETERS
TB2-1	PHASE	To tube auxiliary winding
TB2-2	RUN	To tube principle winding
TB2-3	COM	To tube common winding
TB2-4	GROUND	To tube housing ground


TB3 TUBE AND INTERLOCK INTERFACE

PIN	SIGNAL	PARAMETERS
TB3-1	SMALL FIL	Connection to tube small filament
TB3-2	COMMON	Connection to tube filament common
TB3-3	LARGE FIL	Connection to large filament
TB3-4	GROUND	Generator chassis for cable shield connection
TB3-5	Interlock 2+	Used if tube has separate thermostat switch.
TB3-6	Interlock 2-	Open = OVER TEMP. (short terminals if not used)
TB3-7	Interlock 3+	Used if tube has cooling circulator flow switch.
TB3-8	Interlock 3-	Open = NO FLOW. (short terminals if not used)
TB3-9	Safety Interlock+	
TB3-10	Safety Interlock-	such as door interlocks. Open turns HV OFF, or inhibits HV from being generated.
		Closed = OK 24Vdc @ <1A typical
TB3-11	Contactor Coil+	Option for contactor coil control
TB3-12	Contactor Coil-	
TB3-13	Spare	N/C
TB3-14	Spare	N/C
TB3-15	Tube Current+	Tube current flows out from this pin
TB3-16	Tube Current-	Tube current flows into this pin


DIMENSIONS: in.[mm] **TOP VIEW**



SIDE VIEW



FRONT VIEW







PAGE 1 OF 2



Spellman High Voltage has been designing, manufacturing and providing CT generators for OEM customers for over three decades. We have unrivaled experience being the first provider of a CT generator used in a commercially available continuous rotating CT scanner in 1985. Since then Spellman has enhanced performance and developed new CT generators year after year, setting the standard for CT generator technology.

Spellman's CCT series of CT generators provide a unique combination of performance and price. Ideally suited for the economy 16 slice CT scanner, this generator has the ability to be scaled from 32kW to 50kW. Its compact size and unique bend makes it suitable for small footprint gantry designs. Designed to easily pair with many off the shelf CT tubes.

OPTIONS

DG Deflection Grid CG Cutoff Grid

SPECIFICATIONS

Input Voltage:

Main: 400Vac, three phase, +15%/-20%, 50/60Hz 220/230Vac, single phase, +15%/-10%, 50/60Hz Auxiliary:

Output Voltage:

60kV to 140kV (bipolar, 30kV to 70KV) Range:

Accuracy: ±0.5% of setting

Output Current:

Range: 10mA to 420mA, 50kW maximum. 10mA to 350mA, 42kW maximum.

10mA to 275mA, 32kW maximum.

Filament Output:

Type: Two filament outputs, large and small

Voltage/Current:15Vac (30kHz-40kHz) @ 0-6A

maximum, referenced to cathode output

Power:

Maximum mA: 420mA, 50kW maximum Maximum kV: 140kV, 50kW maximum

Peak: 50kW

Maximum mA: 350mA, 42kW maximum Maximum kV: 140kV, 42kW maximum

42kW Peak:

Maximum mA: 275mA, 32kW maximum Maximum kV: 140kV, 32kW maximum

Peak: 32kW

Gantry Rotation: 0.5 seconds

Starter:

Type: **Dual Speed Starter**

Compatibility: All industry standard X-Ray tubes

- 32, 42 and 50kW all in the same footprint and volume
- Utilizes Spellman's own SPI interface (compatible with other Spellman CT generators)
- 16/32 slice with 0.5 second rotation
- Supports Spellman's add on Grid Box Option
- Integrated anode drive (supporting ball or liquid metal bearings)

GRID SPECIFICATIONS

Optional grid box for Deflection or Cutoff Grid



Deflection Grid:

The deflection grid (also called the Flying Focal Spot) allows for dynamic movement of the focal spot providing double X sampling which increases effective resolution while decreasing unwanted artifacts.

Type: Deflection grid, single box assembly Input Power: 24Vdc, ±10% @ 4.2A maximum, negative input ties to chassis ground internally

Connectors:

High Voltage Input:

3 pin 75kV Federal Standard (Cathode, Large, Small)

High Voltage Output:

4 pin 75kV CA7 (Cathode, Large, G1, G2) Number of Grids: 2 grids, switching out of phase

Bandwidth: DC to 5kHz

Output Voltage: 0V to -4KV, from grid to cathode. User

input will command the bi-level grids to switch between adjustable voltages,

VLow and VHI.

The two grids switch out of phase: If G1 is at VLow, G2 will be at VHI and vice versa. The VLow and VHI levels for G1 and G2 are independently adjustable from 0 to -4KV but VLow range is constrained

by: |VLOW | ≤ | VHI |

Cutoff Grid:

A cutoff grid truncates the high voltage at the end of the X-Ray exposure, reducing patient radiation dosing that does not contribute to the imaging process.

Type: Cutoff grid, single box assembly

Input Power: 24Vdc, ±10% @ 0.75A maximum, negative input ties to chassis ground internally

Connectors:

High Voltage Input:

3 pin 75kV Federal Standard (Cathode, Large, Small)

High Voltage Output:

4 pin 75kV CA7 (Cathode, Large, G1, G2)

Number of Grids:

One, switched between "Zero" (0V≥Vg-c zero ≥ -10V) and "Cutoff" (Vg-c cutoff = -4kV±10%

@ steady state)




117

PAGE 2 OF 2


CCT X-RAY GENERATOR

DIMENSIONS: in.[mm]

TOP VIEW



SIDE VIEW



How to Order:


32kW maximum: PART NO.: CCT70PN32 42kW maximum: PART NO.: CCT70PN42 50kW maximum: PART NO.: CCT70PN50

Consult sales for grid options

DEFLECTION / CUTOFF GRID

DIMENSIONS: in.[mm]


TOP VIEW



SIDE VIEW



FRONT VIEW



Spellman High Voltage has been designing, manufacturing and providing CT generators for OEM customers for over three decades. We have unrivaled experience being the first provider of a CT generator used in a commercially available continuous rotating CT scanner in 1985. Since then Spellman has enhanced performance and developed new CT generators year after year, setting the standard for CT generator technology.

Spellman High Voltage has manufactured over 30,000 CT generators. We have the knowledge, capability and experience to provide you with the CT generator technology you need.

Ask about our subsystem capabilities

- CT Generators from 32kW to 110kW
- 60-140kV output
- Rotational CT up to 240rpm
- Fast rise time
- Designed to drive industry standard CT tubes
- Digital interface allows for ease of integration
- OEM customization



32/42/50kW 16-64 slice single chassis "compact" CT generator



50kW/80kW 16-128 slice "performance" CT generator with grid/Z deflection



110kW 64-264 slice "premier" CT generator for state of the art CT systems

MODEL	32/42/50kW Compact CT Generator	50/80kW CT Generator	110kW CT Generator
Model Designation	CCT70PN32 CCT70PN42 CCT70PN50	CT70PN50 CT70PN80	CT140N110
Input Power		400Vac, 3Ø, +15%/-20%, 50/60Hz	
Auxiliary Input Power	220/230Vac, 1Ø +15%/-10%, 50/60Hz	220/230Vac, 1Ø +15%/-10%, 50/60Hz	Not required
kV Output Range	60kV - 140kV (bipolar, 30kV – 70kV)	60kV - 140kV (bipolar, 30kV – 70kV)	60kV to 140kV Anode grounded
kV Output Accuracy		±0.5% of setting	
mA Output Range	10mA – 300mA / 32kW maximum 10mA – 350mA / 42kW maximum 10mA – 360mA / 50kW maximum	10mA – 420mA / 50kW maximum 10mA – 667mA / 80kW maximum	6mA to 900mA, 110kW maximum
mA Regulation/Accuracy	2% or 2mA or which is larger for 20mA -350mA	2% or 1mA or which is larger for 20mA -420mA	2% or 1mA or which is larger for 20mA -900mA
Filament Output	2 outputs: 15Vac @ 0-6A up to 8A available	1 output: 15Vac @ 0-6A, up to 15A available 2 filament/no grid configuration available	2 outputs: 10Vac @ 0-8A,
Filament Accuracy	±5% of setting	±5% of setting	±2% from 25% to 75%, 5% above
Filament Repeatability		±0.2%	
Starter		HSS configured to match X-Ray tube used	
Interface		Custom serial interface	
Rotation	Up to 120 rpm	Up to 120 rpm	Up to 240 rpm
Configuration	Single Chassis	Two chassis	Four chassis
Grid Option	Dual grid/single filament, 0-4kV @ 0-4kHz (separate assembly)	Dual grid/single filament, 0-4kV @ 0-4kHz (built-in)	n/a
Magnetic Z Deflection Option	n/a	Ground based single channel beam steering	n/a

Please consult factory regarding product configuration availability and regulatory requirements for specific markets







- Constant Potential Output
- Excellent Stability and Regulation
- Power Factor Corrected AC Input Circuitry
- Digital Interface, Ethernet and RS-232
- End Grounded Exposed Anode
- Portable, Repeatable, Accurate
- 100% Duty Cycle
- Unparalleled Resolution Imaging
- Liquid or Air Cooled Models
- Penetration of up to 76mm of Fe (300kV unit)

Spellman's SPX Series are perfectly suited for today's demanding NDT inspection requirements. SPX units are rugged, yet easy to transport and economical to maintain. They can be line or portable generator powered automatically adapting to standard input voltages to permit all day inspection under extreme conditions virtually anywhere.

The end grounded X-Ray tubes have a focal spot size of 1.5mm sq. and the exposed anode allows for easy and flexible positioning of the tube head assembly. Tube ports use a low-absorption beryllium window that allows the radiographer to utilize the full spectrum of X-Ray energy. The high radiation output of the SPX systems allow for lower kV per exposure, shorter exposure times and increased film contrast for superior radiographic imaging.



The SPX microprocessor-driven control unit provides automatic warm-up and comprehensive self-diagnostic circuitry. Memory to store and recall exposure techniques is standard and the last set of exposure parameters is retained before powering down. The SPX is adjustable in 1kV and 0.1mA increments. Exposure duration can be set from 1 second to 99 min 59 seconds in 1 second increments. There are three models to choose from: 160kV, 200kV and 300kV.

TYPICAL APPLICATIONS

- Aerospace
- Manufacturing
- Defense
- Aviation
- Energy
- Security Systems
- NDT Applications

SPECIFICATIONS

Input Line Requirements:

Automatically adapts to input line voltage 100-130Vac, 50/60Hz, 20 Amperes maximum 200-250Vac, 50/60Hz, 10 Amperes maximum May also be portable-generator powered

X-Ray Output:

SPX160: 20 to 160kV, 0.5mA to 5.0mA (800 watts max.) SPX200: 10 to 200kV, 0.5mA to 10.0mA (900 watts max.) SPX300: 10 to 300kV, 0.5mA to 10.0mA (900 watts max.)

Constant potential, end-grounded anode, air or liquid cooled versions available

X-Ray Tube Window:

SPX160: Beryllium 0.8mm (directional) Nickel 0.6mm (panoramic)

SPX200: Beryllium 1.0mm SPX300: Beryllium 1.0mm

Radiation Coverage:

SPX160: 40° directional or 360° panoramic tube available SPX200: 40° directional or 360° panoramic tube available

SPX300: 40° x 60°

Radiation Output:

SPX160: 14R/min at 50cm filtered with 0.5 inches (12.7mm)

aluminum at 160kV, 5mA

SPX200: 21R/min at 50cm filtered with 0.5 inches (12.7mm)

aluminum at 200kV, 4.5mA

SPX300: 30R/min at 50cm filtered with 0.5 inches (12.7mm)

aluminum at 300kV, 3mA

Radiation Leakage:

Less than 2.0 Roentgens per hour at 1 meter from the X-Ray tube target.





Effective Focal Spot: SPX160:

Standard: 0.7mm x 1.0mm (0.03in x 0.04in) EN12543

0.5mm x 0.5mm (0.02in x 0.02in)

nominal IEC60336

Panoramic: This tube has a flat target (0 degree)

and therefore it is without dimension along the tube axis (other than panoramic tubes with conical targets). The true focal spot on the target can only be estimated by taking two focal spot film exposures in the main beam 90 degrees apart from each other. Due to this no focal spot is inferred.

SPX200:

Standard: 3mm x 3mm (0.12in x 0.12in) EN12543 Panoramic: 0.4mm x 4mm (0.016in x 0.16in) EN12543

SPX300:

Standard: 3mm x 3mm (0.12in x 0.12in) EN12543

Ambient Temp:

100% duty cycle @ 120°F (49°C)

Duty Cycle:

100% - liquid or air cooled

Operating Temp:

32°F to 120°F (0°C to 49°C)

Storage Temp:

-30°F to 160°F (-35°C to 71°C)

Anode Cooling:

Liquid coolant solution closed loop between X-Ray tube anode and cooling unit, or fan forced air cooling.

Liquid Cooling Unit Dimensions:

Please reference dimension drawings

Liquid Cooling Unit Weight:

54lbs. (15.4kg) approx.

Tube Head Dimensions:

Please reference dimension drawings

Tube Head Weight:

SPX160:

Liquid Cooled: 29lbs. (13.15kg) Air Cooled: 33lbs. (14.97kg) Panoramic: 29lbs. (13.15kg)

SPX200:

Liquid Cooled: 37lbs. (16.78kg) Air Cooled: 41lbs. (18.60kg) Panoramic: 37lbs. (16.78kg)

SPX300:

Liquid Cooled: 98lbs. (44.5kg) Air Cooled: 105lbs. (47.61kg)

X-Ray Control Unit:

Digital microcomputer based with local control, RS-232 and Ethernet

X-Ray Control Unit Dimensions:

Please reference dimension drawings

X-Ray Control Unit Weight:


26lbs. (11.8kg) approx.

Safety Devices:

- Tubehead Pressure Relief Valve
- Tubehead Thermal Cut-Out
- Tubehead Pressure Gauge
- Tubehead Low Pressure Cut-Out @ 25psi (1.72 Bar)
- Coolant Flow Sensor (liquid cooled only)
- Control Unit Safety Keyswitch
- Microcomputer-based Self Diagnostics
- Continuous Exposure Parameter Display

Standard Accessories:

- Operation manual
- Tubehead carrying case
- Tubehead Cable- 100' with strain relief
- Extra key (1) for Control Unit Safety Lock
- Power cable 25' with strain relief
- · Coolant hose twin, 50' with self-sealing terminations (liquid cooled only)
- Cooler power cable



This chart is for reference only (actual settings may vary due to SFD, material, and film type)

PAGE 3 OF 7

SPX160 MODEL SELECTION TABLE

MODEL NUMBE	R DESCRIPTION
	Air Cooled, 40° Directional Beam, Glass insert
SPX160LCDBG	Liquid Cooled, 40° Directional Beam, Glass insert
SPX160LCPANG	Liquid Cooled, PANoramic Beam, Glass insert

SPX200 MODEL SELECTION TABLE

	MODEL NUMI	BER DESCRIPTION
I	SPX200ACDBC	Air Cooled, 40° Directional Beam, metal Ceramic insert
I	SPX200LCDBG	Liquid Cooled, 40° Directional Beam, Glass insert
I	SPX200ACDBG	Air Cooled, 40° Directional Beam, Glass insert
	SPX200LCPANC	Liquid Cooled, PANoramic beam, metal Ceramic insert
	SPX200LCDBC	Liquid Cooled, 40° Directional Beam, metal Ceramic insert

SPX300 MODEL SELECTION TABLE

MODEL NUMBE	R DESCRIPTION	
SPX300LCDBC	Liquid Cooled, 40° Directional Beam, metal Ceramic insert	
SPX300ACDBC	Air Cooled, 40° Directional Beam, metal Ceramic insert	

SPX OPTIONS

MODEL NUMBER	DESCRIPTION	
3-000-0754	SPX160/200 tubehead stand	
3-000-0756	SPX300 tubehead stand	
3-000-0792	Laser pointer for liquid cooled tube	
K935	SPX160 Laser pointer for air cooled tube	
K936	SPX200/300 Laser pointer for air cooled tube	
K937	SPX200 Laser pointer for liquid cooled tube	
K938	SPX300 Laser pointer for liquid cooled tube	

SPX MAIN AC INPUT

Controller Side; Male, 3 pins MS type

PIN	SIGNAL	
А	LINE 1 120/220Vac	
В	LINE 2 Neutral 120/220Vac	
С	Ground	

SPX INTERLOCK CONNECTOR

Controller Side; Female, 8 pins MS type Tube Side; Male, 8 pins MS type

PIN	SIGNAL	
А	External Interlock	
В	External Interlock	
С	X-Ray ON External Light	
D	External Lights Common	
E	Pre-Warning External Light	
F	External Light Confirm Input	
G	24Vdc Outut, 1A max.	
Н	24Vdc Return (com.)	

SPX FAN CONNECTOR (A/C ONLY)

Controller Side; Female, 8 pins MS type Tube Side; Male, 4 pins MS type

PIN (Control)	PIN (Tube Head)	SIGNAL
D	А	Fan 120Vac Line1
С	В	Fan 220Vac Tap
G	С	Fan 120Vac Line2/Neutral
В	D	Ground
Е		N/C
F		N/C
А		Flow Interlock
Н		Flow Interlock

SPX COOLER CONNECTOR (W/C ONLY)

Controller Side; Female, 8 pins MS type Tube Side; Male, 8 pins MS type

PIN	SIGNAL	
А	Flow Interlock	
В	Ground	
С	120/220Vac Line1 for Motor	
D	120/220Vac Line2/Neutral for Motor	
Е	120Vac Motor Tap	
F	120/220Vac Motor Tap	
G	220Vac Motor Tap	
Н	Flow Interlock	

SPX160 TUBE HEAD CONNECTOR

Controller Side; Female, 10 pins MS type Tube Side; Male, 10 pins MS type

PIN	SIGNAL	
Α	Interlock Temperature/Pressure	
В	Ground	
С	Ground	
D	HV Transformer	
Е	mA Feedback	
F	Filament Transformer	
G	kV Feedback	
Н	kV Feedback Return (GND)	
	Filament Transformer	
J	HV Transformer	

SPX200/300 TUBE HEAD CONNECTOR

Controller Side; Female, 14 pins MS type Tube Side; Male, 14 pins MS type

PIN	SIGNAL	
А	Interlock Temperature/Pressure SPX200, N/C SPX300	
В	Ground	
С	Ground	
D	HV Transformer	
Е	mA Feedback	
F	Filament Transformer	
G	kV Feedback	
Н	kV Feedback Return (GND)	
	Filament Transformer	
J	HV Transformer	
K	N/C	
L	Interlock Temperature/Pressure SPX300, N/C SPX200	
M	N/C	
N	N/C	



OPTIONAL ACCESSORIES

GUI Control Software for the SPX

GUI is specifically designed for controlling SPX series systems. As an alternative to the front panel control, the GUI will allow the user to control all necessary functions of the system from a userfriendly windows based menu. Additionally the GUI can be used as a diagnostic tool when the system is controlled via the front panel.

- Automatic warm-up of the X-Ray tube
- Timed or Continuous Exposure modes
- Fault and status monitor





+1-631-630-3000

e-mail: sales@spellmanhv.com

Laser Pointer

Spellman's exclusive Laser Pointer allows pinpoint image area targeting. The Laser Pointer projects a highly visible reference laser beam from the tubehead to surfaces up to 75 feet away, showing precisely where the central X-Ray beam will be located, providing unmatched accuracy for greater efficiency and reduced set-up times.

Tubehead Stand

An optional X-Ray Tubehead Stand allows for quick set up and provides rigid support for optimal image quality with three-axis positioning of the tube head assembly. The stand incorporates telescoping legs, a hand wheel-driven variable height adjustment and lockable hand wheel controlling. the tubehead tilt and horizontal rotation. The tubehead cradle is cushioned for secure mounting and vibration damping. A bubble-type indicator is included for guick and easy leveling of the tubehead. Black anodized aluminum construction. 35lbs. (16kg) approx.

Air Cooled Tube Head Assembly

The air cooled tube head assembly uses a heat sink and high volume fan to dissipate heat from the anode and typically is used in applications that do not have limited access and are not in a volatile fuel vapor atmosphere. The air cooled tube head assembly does not require the cooler unit and the associated mixing and maintenance of liquid coolant. This unit requires less user maintenance and could be considered more environmentally friendly.

Panoramic Tube Head Assembly

The panoramic tube head assembly comes in a liquid cooled version only and produces radiation in a 360 degree cone making it ideal for aircraft FOD inspection, inspection of tanks or pipes or any application that requires circumferential radiographic inspection.










SPX160

DIMENSIONS: in.[mm]


CONTROL UNIT TOP VIEW



COOLER TOP VIEW




SPX160 TUBE HEAD SIDE VIEW




FRONT VIEW




FRONT VIEW



SIDE VIEW



SIDE VIEW






SPX200

DIMENSIONS: in.[mm]


CONTROL UNIT TOP VIEW




COOLER TOP VIEW




SPX200 TUBE HEAD SIDE VIEW




FRONT VIEW




FRONT VIEW



SIDE VIEW



SIDE VIEW



LIQUID COOLED 43.00 [1092.20]

> AIR COOLED 49.00 [1244.6]



CONTROL UNIT TOP VIEW




SPX300






SPX300 **TUBE HEAD** SIDE VIEW




FRONT VIEW




FRONT VIEW




SIDE VIEW



SIDE VIEW





12.00 [304.80]

PAGE 1 OF 2



Spellman's LPX Series are perfectly suited for today's demanding NDT inspection requirements. LPX units are rugged, easy to transport and the optional LPX1620 Tubehead Stand allows for quick set up and provides rigid support for optimal image quality. The tubehead stand incorporates telescoping legs, a hand wheel-driven variable height adjustment and lockable hand wheel controlling the tubehead tilt and horizontal rotation. The tubehead cradle is cushioned for secure mounting and vibration damping. A bubble-type indicator is included for quick and easy leveling of the tubehead.

SPECIFICATIONS

Horizontal Rotation:

360°

Tilt:

-45° to +90°

Dimensions:

Footprint of legs: 43" (109cm) min., 70.5" (179cm) max. Floor to center line of tubehead ring: 45.5" (115cm) min., 83.5" (212cm) max.

Weight:

35lbs. (16kg)

SET-UP

- 1. Extend tripod legs outward
- Loosen height lock knob and raise gearhead mount approx. 3 inches
- Place gearhead on tripod shaft. Align set screw hole in shaft with hole in gearhead mount. Using supplied hex key, tighten set screw to engage gear head mount.
- Mount tubehead in cradle. Open knurled latch and outer ring to remove cradle assembly. Release the two hook latches on the cradle to open it. Fit cradle over tubehead making sure any cooling manifolds are positioned between cushioning pads. Latch the hook latches securely.
- Mount cradle in the gear head outer ring. Close and latch the knurled knob locking mechanism.
- Use the height, tilt, and rotation controls to position the X-Ray tubehead as needed. Lock all adjustments before making X-Ray exposures.




- Quick Set Up
- Allows 3-Axis Positioning of Tubehead
- Provides Rigid Support for Optimal Image Quality





3-000-0756


Tubehead stand for LPX300













Other imaging systems may produce inconsistent results and require repeat exposures. Spellman's Laser Pointer, exclusive to Lorad's LPX Systems, locates the centerline of the X-Ray beam for unmatched accuracy and efficiency. The Laser Pointer shows precisely where the central X-Ray beam will contact the test area by projecting a highly visible reference beam from the X-Ray tube head to surfaces up to 75 feet away. The beam is activated by a push button and automatically shuts off after 30 seconds. The Laser Pointer is lightweight and powered by three (3) AAA batteries. The Laser Pointer can be used with Lorad's end-grounded exposed anode tube heads and also with air cooled tube heads with the addition of the air cooled adaptor.

SPECIFICATIONS

Wavelength:

670nm typical

Output power:

4.2mW +/-5%

Laser Class:

Class IIIa Conforming (CDRH 21CFR) Class 3R (IEC 60825 1)

Operating Current:

@ 5Vdc 45mA typical, 125mA max

Battery Lifetime:

20 hours typical (Alkaline AAA cells)

Operating Temp:

10°C to +40°C

Operating time w/o restart:

30 seconds

Dimensions:

1.75" H x 2.72" W x 2.72" D (4.44cm x 6.90cm x 6.90cm)

Exclusive to Lorad LPX Systems

- Quick Set Up
- Accurate up to 75 Feet Away
- Adaptors for Most LPX Tubeheads

Adaptors:

LPX160 A/C Part Number 9-200-0110 LPX160 L/C N/A LPX160 Panoramic N/A LPX200 A/C Part Number 9-200-0327 LPX200 L/C Part number 9-200-0370 LPX200 Panoramic N/A LPX300 L/C 9-200-0465



The LPX Laser Pointer is compatable with most LPX160, LPX200 and LPX300 tubehead assemblies



 Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics

- Compact & Lightweight
- Can be Mounted in Any Physical Orientation
- Analog or Digital Control Interface

Spellman's XRB011 Series of Monoblock® X-Ray sources are designed for OEM applications powering its internal X-Ray tube up to 80kV at 20W and 80kV at 50W. Features like 24Vdc input voltage, small package size, standard analog interface and RS-232/Ethernet digital interface simplify integrating the XRB011 into your X-Ray system. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability and performance.

TYPICAL APPLICATIONS

Medical X-Ray: Fluoroscopy and Radiography for Extremities, Specimen Radiography. Pulsed Fluoroscopy (contact Spellman sales) Industrial X-Ray: Component inspection and Non-Destructive Testing

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Micro focus tube

Focal Spot: 33µm Nominal, 50µm max. (IEC 336)

Beam Filter: Ultem 0.060" (1.5mm)

Oil 0.175" (4.4mm)

Beam Geometry: Symmetrical 40° cone

Input Voltage:

20W: 24Vdc ±1V @ 2.5A 50W: 24Vdc ±1V @ 4A

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 35kV to 80kV

X-Ray Tube Current:

20W: 0-250μA over specified tube voltage range 50W: 0-700μA over specified tube voltage range

X-Ray Tube Power:

20/50W maximum continuous

Voltage Regulation:

Line: $\pm 0.5\%$ for a $\pm 1V$ change of nominal input line voltage Load: $\pm 0.1\%$ for a load change of $25\mu A$ to maximum

rated current

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±1% of the programmed value

Voltage Risetime:

Ramp time shall be ≤250ms from 10% to 90% of maximum rated output voltage

Voltage Temperature Coefficient:

≤100ppm/°C

Over Temperature Fault:

Indicates that the internal oil temperature has exceeded 65° C. The high voltage output will be disabled. Toggling the X-Ray ON Command OFF and ON will reset the fault.

Over Voltage Fault:

An overvoltage (OV) fault is detected when the output voltage exceeds 82kV. The high voltage output will be disabled. Toggling the X-Ray ON Command OFF and ON will reset the fault.

Voltage Ripple:

1% peak to peak

Current Regulation:

Line: $\pm 0.5\%$ for a $\pm 1V$ change of nominal input line voltage Load: $\pm 0.5\%$ for a voltage change of 35kV to 80kV

Current Accuracy:

Current measured through the X-Ray tube is within ±2.5% of the programmed value

Over Current Fault:

An overcurrent (OC) fault is detected when the emission current exceeds 275µA (20W model) and 710µA (50W model). Toggling the X-Ray ON Command OFF and ON will reset the fault.

Arc Intervention:

One arc fault. The high voltage output will be disabled. Toggling the X-Ray ON command OFF and ON will reset the fault.

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control

Analog Interface:

Ground referenced 10kV/V, 25μ A/V (20W model) and 70μ A/V (50W model) for programming and monitoring analog interface signals. Open collector, active low digital signal interface. Internal jumper is needed to be configured for analog interface.



e-mail: sales@spellmanhv.com

PAGE 2 OF 4

Digital Interface:

RS-232: standard Ethernet: optional

Control Software:

A demo GUI is available for engineering evaluations

Interlock/Signals:

A hardware interlock functions in both analog and digital programming modes.

Operating Temperature:

0°C to +40°C


Storage Temperature:

-20°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

20W and 50W option: Customer provided, external cooling fan, 50cfm, minimum



Analog Interface and Input Line Connector:

25 pin D connector, male

Digital Interface Connector:

RS-232: 9 pin D connector, female

Ethernet: RJ45 connector

Grounding Point:

6-32 ground stud provided on chassis

Dimensions:

20W: 5.81"W x 5.0"H x 10.81"D

(147.57mm X 127mm X 274.57mm)

50W: 6.00"W x 5.0"H x 10.81"D

(152.4mm x 127mm x 274.57mm)

Weight:

20W: 18lbs (8.165kg) 50W: 20lbs (9.072kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Less than 1mR/hr at 1 meter

Regulatory Approvals:

Compliant to UL/CUL recognized file E242584. CE to EN 61010-1 for non-medical applications.

RS-232 DIGITAL INTERFACE— 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	NC	No Connection
2	TX Out	Transmit Data
3	RX In	Receive Data
4	NC	No Connection
5	SGND	Signal Ground
6	NC	No Connection
7	NC	No Connection
8	NC	No Connection
9	NC	No Connection

ETHERNET DIGITAL INTERFACE— RJ45 8 PIN CONNECTOR

PIN	SIGNAL	PARAMETERS
1	TX +	Transmit Data +
2	TX -t	Transmit Data -
3	RX +	Receive Data +
4	NC	No Connection
5	NC	No Connection
6	RX -	Receive Data -
7	NC	No Connection
8	NC	No Connection

ANALOG INTERFACE-J1 25 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	+24V	+24Vdc±1Vdc @ 4A
2	+24V	+24Vdc±1Vdc @ 4A
3	+24V	+24Vdc±1Vdc @ 4A
4	NC	No Connection
5	+24V RETURN	+24V RETURN
6	+24V RETURN	+24V RETURN
7	+24V RETURN	+24V RETURN
8	Signal Ground	Signal Ground
9	Interlock Input	Input, Active low, Interlock is low safe to enable high voltage. Connect to +24V Return
10	kV Monitor	Output, 0 to 8V = 0 to rated output voltage. Zout= 100Ω
11	μA Monitor	Output, 0 to $10V = 0$ to rated output current. Zout= 100Ω
12	X-Ray Ready status	Output, Active Low, Open Collector, 24Vdc @ 10mA max
13	X-Ray ON status	Output, Active Low, Open Collector, 24Vdc @ 10mA max
14	Filament Standby status	Output, Active Low, Open Collector, 24Vdc @ 10mA max
15	Over Voltage Fault	Output, Active Low, Open Collector, 24Vdc @ 10mA max
16	Over Current Fault	Output, Active Low, Open Collector, 24Vdc @ 10mA max
17	ARC Fault	Output, Active Low, Open Collector, 24Vdc @ 10mA max
18	Filament Current Limit Fault	Output, Active Low, Open Collector, 24Vdc @ 10mA max
19	Signal Ground	Signal Ground
20	Interlock Output	Output, Active Low, Open Collector, 24Vdc @ 10mA max
21	μA Program	Input, 0 to 10V = 0 to rated output current. $Zin=10k\Omega$
22	kV Program	Input, 0 to 8V = 0 to rated output voltage. $Zin=10k\Omega$
23	X-Ray ON Command	Input, Active low
		Low (short) = X-Ray ON
		High (open) = X-Ray OFF
		Internal pull up resistor to +15V
24	Signal Ground	Signal Ground
25	Over Temperature	Output, Active Low, Open Collector, 24Vdc @ 10mA max

20W Model ORDERING INFORMATION

Medical Applications:

XRB011-80PN20 80kV, 250uA, 20W, Analog Interface, RS-232

XRB011-80PN20E 80kV, 250uA, 20W, Analog Interface, RS-232, Ethernet

XRB011-80PN20A 80kV, 250uA, 20W, Analog Interface

Non-Medical Applications:


XRB011-80PN20/CE 80kV, 250uA, 20W, Analog Interface, RS-232, CE XRB011-80PN20E/CE 80kV, 250uA, 20W, Analog Interface, RS-232, Ethernet, CE

XRB011-80PN20A/CE 80kV, 250uA, 20W, Analog Interface, CE


XRB011 20W Model


DIMENSIONS: in.[mm]

FRONT VIEW



TOP VIEW





e-mail: sales@spellmanhv.com

50W Model **ORDERING INFORMATION**

Medical Applications:

XRB011-80PN50 80kV, 700uA, 50W, Analog Interface, RS-232

XRB011-80PN50E 80kV, 700uA, 50W, Analog Interface, RS-232, Ethernet

XRB011-80PN50A 80kV, 700uA, 50W, Analog Interface

Non-Medical Applications:

XRB011-80PN50/CE 80kV, 700uA, 50W, Analog Interface, RS-232, CE

XRB011-80PN50E/CE 80kV, 700uA, 50W, Analog Interface, RS-232, Ethernet, CE

XRB011-80PN50A/CE 80kV, 700uA, 50W, Analog Interface, CE

4.17 [105.91] 2.08 [52.83] 4.37 [110.99] 6-32 GROUNDING STUD RJ45 4.23 [107.44] 6.00 [152.40]


FRONT VIEW

5.81 [147.57]

XRB011 50W Model

DIMENSIONS: in.[mm]

SIDE VIEW TOP VIEW



130KV @ 65W MICROFOCUS MONOBLOCK®

PAGE 1 OF 5



Spellman's uXRB130P65 microfocus Monoblock® X-Rav sources are designed for high resolution imaging applications powering its internal microfocus X-Ray tube up to 130kV @ 65W. Features like 24Vdc input voltage, small package size and standard RS-232 digital interface simplify integrating the µXRB130P65 into your X-Ray system. The small, round focal spot size, optimized over the range of operating voltage, and high magnification, combined with stable high intensity output provides distortion free, superior quality 2D and 3D images.

TYPICAL APPLICATIONS

Industrial X-Ray:

Circuit board and electronic component inspection High resolution Non Destructive Testing of metal

and plastic parts

Micro CT for Industrial applications

Battery inspection

Medical X-Ray:

Micro CT for life sciences applications

OPTIONS


WB Wide Beam

ET Extended Tube (wide beam only)

Light Weight LW



The uXRB130P65 is ideal for applications such as printed circuit board inspection, battery inspection and industrial/medical micro CT



Photos provided by ThermoFisher Scientific

- Integrated X-Ray Tube and Control Electronics in One Compact Assembly
- Standard RS-232 Digital Interface Offers Access to Diagnostics and Operating Logs
- Standard Windows Test GUI
- 7 Micron Focal Spot for Narrow Beam
- 8 Micron Focal Spot for Wide Beam
- 10mm/14mm Spot to Window Spacing Provides High Geometric Magnification

SPECIFICATIONS

Narrow Beam Benefits (Standard):

The small round spot is optimized over the range of kV and power to provide distortion free images. Operated at 4 watts yields a 6 micron spot for high resolution imaging. The 14mm spot to window spacing offers high geometric magnification.

Narrow Beam X-Ray Characteristics (Standard):

Spot Ellipticity: ±20% @ 16 watts, 130kV

(either axis referred to average)

Beam Geometry: ≥ 53°, round beam, uniform beam

profile in any direction

Spot to Window

Spacing: 14mm ±0.5mm

Window Diameter

(uncollimated): ≈19mm

Window Material

and Thickness: Beryllium, 0.25mm

Target Material: Tungsten

Wide Beam Benefits (WB Option):

The 115 degree round beam is well suited for automated inspection where a large field of view is required for maximum throughput or off angled views. The 10mm spot to window spacing provides superior high geometric magnification.

Wide Beam X-Ray Characteristics (WB Option):

Spot Ellipticity: ±20% @ 16 watts, 130kV

(either axis referred to average)

Cone of

Illumination: 115°, round beam, uniform beam

profile in any direction

Spot to Window

10mm ±0.5mm Spacing:

Window Diameter

(uncollimated): ≈38mm

Window Material

and Thickness: Beryllium, 0.51mm

Target Material: Tungsten

X-Ray Leakage: Behind X-Ray tube is ≤0.5mR/hr at 2.55cm

Input Voltage:

+24-27Vdc

Input Current: <6 amps



130KV @ 65W MICROFOCUS MONOBLOCK®

PAGE 2 OF 5

Anode Supply:

Output Voltage:

20kV to 130kV (referenced to

Cathode Gun Supply)

Output Current:

up to 0.5mA, from 20kV to 130kV

Environmental:

Operating Temperature:

0°C to +32°C

Storage Temperature:

-20°C to +70°C

Humidity:

0 to 95%, non-condensing

Altitude:

Up to 5,000 feet (1524 meters)

Cooling:

Internal fan is incorporated. Adequate air circulation around unit must be provided.

Digital Interface:

RS-232

Mechanical:

See drawings

Weight: Standard: 30lbs. (13.60kg)

Standard/Extended Tube: 34lbs. (15.40kg) Light Weight (LW option): 23lbs. (10.43kg) Light Weight/Extended Tube: 27lbs. (12.24kg)

Regulatory Approvals:

Compliant to EEC EMC Directive.

Compliant to EEC Low Voltage Directive.

Grapical User Interface



Diagnostics Screen

J1 INPUT/OUTPUT— 16 PIN AMP #206036-1 CONNECTOR

PIN	SIGNAL	PARAMETERS
1	Chamber Interlock Out	To close Chamber Interlock connect pin 1 to pin 2, R<2Ω
2	Chamber Interlock In	To close Chamber Interlock connect pin 2 to pin 1, R<2Ω
3	X-Ray ON Lamp Out	120Vac @ 3A/250Vac @ 1.5A rated contacts. Close at X-Ray ON
4	X-Ray ON Lamp In	120Vac @ 3A/250Vac @ 1.5A rated contacts. Close at X-Ray ON
5	N/C	N/C
6	Prime Power Interlock Out	To close Power Interlock connect pin 6, 7 to pin 8, 10, R<2Ω
7	Prime Power Interlock Out	To close Power Interlock connect pin 6, 7 to pin , R<2Ω
8	Prime Power Interlock In	To close Power Interlock connect pin 8, 10 to pin 6, 7, R<2Ω
9	N/C	N/C
10	Prime Power Interlock In	To close Power Interlock connect pin 8, 10 to pin 6, 7, $R < 2\Omega$
11	+24Vdc Input (+)	+24Vdc Input (+)
12	+24Vdc Input (+)	+24Vdc Input (+)
13	+24Vdc Return (-)	+24Vdc Return (-)
14	+24Vdc Return (-)	+24Vdc Return (-)
15	X-Ray On Indicator Out	24Vdc @ 3A rated contacts. Close at X-Ray On
16	X-Ray On Indicator In	24Vdc @ 3A rated contacts. Close at X-Ray On

J2 RS-232 DIGITAL INTERFACE— 9 PIN AMP #788903-1 CONNECTOR

PIN	SIGNAL	NAME
1	DCD	Data Carrier Detect
2	RD	Received Data
3	TD	Transmitted Data
4	DTR	Data Terminal Ready
5	SGNO	Signal Ground
6	DSR	Data Set Ready
7	RTS	Request to send
8	CTS	Clear to Send
9	RI	Ring Indicator

SPOT TABLE


PARAME [*]	TER	NARROW BEAM	WIDE BEAM
Operating	Voltage Range	45-130kV	50-130kV
Maximum	Power	65W, 130kV	65W, 130kV
Maximum	Beam Current	0.500mA	0.500mA
Spot Size	4 Watt	≤ 7µ, 45-130kV	≤ 8µ, 50-130kV
	8 Watt	≤ 10µ, 45-130kV	≤ 14µ, 50-130kV
	16 Watt	≤ 22µ, 45-130kV	≤ 24µ, 50-130kV
	32 Watt	≤ 48µ, 70-130kV	≤ 48µ, 70-130kV
	40 Watt	≤ 60µ, 80-130kV	≤ 60µ, 80-130kV
	65 Watt	≤ 100µ, 130kV	≤ 100µ, 130kV


How to Order:	
Standard (Narrow Beam)	PART NO.: µXRB130P65NB
Wide Beam Option	PART NO.: µXRB130P65WB
Wide Beam Option and Extension Tube	PART NO.: µXRB130P65WBET


PAGE 3 OF 5

DIMENSIONS: in.[mm]

NARROW BEAM (Standard) SIDE VIEW









PAGE 4 OF 5

DIMENSIONS: in.[mm]

WIDE BEAM (WB Option) SIDE VIEW




3.543 ± .005 [89.9] 0.600 [15.24] 6.889 ± .005 [174.98]




PAGE 5 OF 5

DIMENSIONS: in.[mm]

WIDE BEAM (WB Option) and **EXTENSION TUBE (ET Option)** SIDE VIEW




BOTTOM VIEW



REAR VIEW







Spellman's XRB80N100 Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 80kV at 100W. Features like universal input, small package size and a standard analog and RS-232 digital interface simplify integrating this unit into your X-Ray system. The XRB80N100 is available either with fan shaped (standard) or (optional) cone shaped beam geometries. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Bone Densitometry, Thickness Measurement, Food Inspection, Fill Level Confirmation, Parcel Inspection

SPECIFICATIONS

X-Ray Characteristics:

Focal Spot: 0.5mm (IEC 336)

Beam Filter:

3.30mm ±0.15mm Ultem: Oil: 8mm ±0.1mm Glass: 1.8mm ±0.25mm

BE: 0.8mm

Beam Geometry:

Standard. The beam angular coverage Fan:

will be 75° with the beam plane

perpendicular to the X-Ray tube axis and

13° wide.

Cone: Optional. 25° cone beam

Input Voltage:

Power factor corrected input 0.98, 100-240Vac ±10% 50/60Hz, 2A, maximum

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable up to 80kV

X-Ray Tube Current:

150uA to 1.25mA over specified tube voltage range

X-Ray Tube Power:

100W maximum continuous

- Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics
- Compact & Lightweight
- Universal Input, Power Factor Corrected with Internal EMI Filter
- Can be Mounted in Any Physical Orientation
- Analog Control Interface and Standard RS-232 Digital Interface

Voltage Regulation:

±0.05% of maximum output voltage over a ±10% Line:

change of nominal input line voltage

±0.1% of maximum rated voltage for 150uA Load:

to 1.25mA load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

Voltage Risetime:

Standard: Ramp time shall be 500ms from 10% to

90% of maximum rated output voltage Optional: 5 seconds. Specify at time of order

Voltage Overshoot:

5% of maximum voltage, to return within 2.5% of maximum voltage in less than 100ms

Voltage Ripple:

1% peak to peak of maximum voltage for frequencies ≤1kHz

Emission Current Parameters Current Regulation:

Line: ±0.05% of rated output current over a

> ±10% change of nominal input line voltage ±0.1% of rated output current for a change from

50% to 100% of rated output voltage

Current Accuracy:

Load:

Current measured through the X-Ray tube is within

±2% of the programmed value

Current Risetime:

Standard: Ramp time shall be 500ms from 10% to 90%

of maximum rated current

Optional: 5 seconds. Specify at time of order

Arc Intervention:

3 arcs in 10 seconds with a 200ms quench = Shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control



139

PAGE 2 OF 4

Analog Interface:

Ground referenced 0 to 9Vdc for all programming and monitoring signals. Relay contacts and open collector signals for other signals. See analog interface connector pin out table.

Digital Interface:

Jumpers are needed to be configured and the digital interface cable installed to enable the RS-232 interface.

Control Software:

A demo GUI is available for engineering evaluations

Interlock/Signals:

A hardware interlock functions in both analog and digital programming modes. The hardware X-Ray Enable signal only functions in analog programming mode.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

Cooling:

Customer provided 150cfm external cooling fan as required to maintain oil temperature below 55°C. (External cooling is not required if fan option is selected)

Input Line Connector:

3 pin, Phoenix Contact 1829167, SHV part number 105725-219. Mating connector Phoenix Contact #1805990, SHV part number 105808-475 provided with unit.

Analog Interface Connector:

15 pin D connector, male

Digital Interface Connector:

9 pin D connector, female

Grounding Point:

8-32 ground stud provided on chassis

Dimensions:

See line drawings

Weight:

32lbs (14.5kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E235530.

AC LINE POWER CONNECTOR— J1 THREE POSITION PHOENIX CONTACT

	PIN	SIGNAL
	1	Earth Ground
l	2	Line
1	3	Neutral

Mating connector provided with unit

RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	TD	Transmit Data
3	RD	Receive Data
4	N/C	No Connection
5	SGND	Signal Ground
6	NC	No Connection
7	NC	No Connection
8	NC	No Connection
9	NC	No Connection

XRB ANALOG INTERFACE— J2 15 PIN MALE D CONNECTOR

Ī	PIN	SIGNAL	PARAMETERS
	1	Power Supply Fault Output	Open collector, 35V @ 10mA max. high = no fault
	2	mA Program Input	0 to 9.00Vdc = 0 to 100% rated output, Zin = $10M\Omega$
	3	kV Program Input	0 to 9.00Vdc = 0 to 100% rated output, Zin = $10M\Omega$
L	4	X-Ray On Lamp Relay Output	Common, dry contacts, 30Vdc @ 1A, max
L	5	X-Ray On Lamp Relay Output	Normally open, X-Ray ON = closed
L	6	mA Monitor Output	0 to 9Vdc = 0 to 100% rated output, Zout =10kΩ
L	7	X-Ray On Lamp Relay Output	Normally closed, X-Ray ON = open
L	8	kV Monitor Output	0 to 9.00Vdc = 0 to 100% rated output, Zout = $10k\Omega$
L	9	Signal Ground	Ground
L	10	Signal Ground	Ground
L	11	HV Interlock Return Input	Connect to Pin 12 to close HV interlock
ı	12	HV Interlock Output	+15Vdc @ open, 5mA when connected to pin 11
	13	X-Ray Enable Output	+15Vdc @ open, 5mA when connected to pin 15
	14	X-Ray Status Output	Open collector, 35V @ 10mA max high = X-Ray OFF
	15	X-Ray Enable Return Input	Connect to pin 13 to enable X-Ray generation

LED INDICATORS

	INDICATOR	SIGNAL NAME	CONDITION Illuminated When
	LED 1	OV	High kV occurs
	LED 2	UV	Low kV occurs
-[LED 3	UC	Low mA occurs
ı	LED 4	OC	High mA occurs
ſ	LED 5	ARC FLT	Arc fault occurs
-[LED 6	OT	Over temperature occurs
Ī	LED 7	X-RAY ON	X-Rays are enabled
	LED 8	PWR	Power is ON

80KV @ 100W MONOBLOCK®

PAGE 3 OF 4

OPTIONS

RT 5 second Risetime for both voltage and current

CB Cone Beam

Integrated Cooling Fan FΝ M Elapsed Time Meter

(measures X-Ray ON elapsed time)

How to Order:

Standard: PART NO.: XRB80N100

Risetime, Cone Beam, Fan and Elapsed Time Meter Options

PART NO.: XRB80N100/RT/CB/FN/M


DIMENSIONS: in.[mm]

Standard Unit


FRONT VIEW NOTE: Shown with Elapsed Time Meter option


⚠ WARNING **⚠** 7.00 [178] **(=) (9) ⚠** WARNING **⚠ ⚠ WARNING ⚠** 7.60 [193] 9.13 [232]

SIDE VIEW



BACK VIEW






PAGE 4 OF 4


DIMENSIONS: in.[mm]

Cooling Fan Option


TOP VIEW



SIDE VIEW



BACK VIEW





80KV @ 100W MONOBLOCK®

PAGE 1 OF 6



 Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics

- Compact & Lightweight
- Universal Input, Power Factor Corrected with Internal EMI Filter
- Can be Mounted in Any Physical Orientation
- Analog Monitoring Interface and Standard RS-232 Digital Program and Monitor Interface
- Data Logging and Firmware Controlled X-Ray Tube Seasoning (Smart Controller Option Only)

Spellman's XRB80PN100HR (high reliability) Monoblock® X-Ray source is designed for OEM applications powering its internal Bipolar X-Ray tube up to 80kV at 100W. Features like universal input, small package size and a standard RS-232 digital interface simplify integrating this Monoblock® into your X-Ray system. The XRB80PN100HR is available either with fan shaped (standard) or (optional) cone shaped beam geometries. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance. The XRB80PN100HR is designed for long field life and comes with a 3 year warranty.

TYPICAL APPLICATIONS

X-Ray Scanning, Thickness Measurement, Food Inspection, Fill Level Confirmation, Parcel Inspection

OPTIONS

CB Cone Beam

.5mm .5mm focal spot X-Ray tube NF 80° x 10° Narrow Fan beam

RA Right Angle cable SC **Smart Controller**

SPECIFICATIONS

X-Ray Characteristics:

0.8mm (IEC 336) standard Focal Spot:

0.5mm (IEC 336) optional

Beam Filter:

Ultem: 3.00mm ±0.15mm Oil: 7.5mm ±0.25mm Glass: 1.7mm ±0.2mm

Re: 0.8mm

Beam Geometry:

The standard beam angular coverage will be 80°

with the beam plane perpendicular to the X-Ray tube axis and 20° wide (with a 2° tolerance) An optional 80° x 10° (with a 2° tolerance)

is also available

Cone: Optional. 20° cone beam

(with a 2° tolerance)

Input Voltage:

Power factor corrected input 0.98, 100-240Vac ±10% 50/60Hz. 2A maximum

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable 40kV (±20kV) to 80kV (±40kV)

X-Ray Tube Current:

150uA to 2.00mA over specified tube voltage range (100W max.)

X-Ray Tube Power:

100W maximum continuous

Voltage Regulation:

±0.05% of maximum output voltage over a ±10% Line:

change of nominal input line voltage

Load: ±0.1% of maximum rated voltage for 150uA

to 2.00mA load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

Voltage Risetime:

Ramp time shall be <500ms from 10% to 90% of maximum rated output voltage

Voltage Ripple:

0.5% peak to peak of maximum voltage for frequencies ≤1kHz

Emission Current Parameters

Current Regulation:

Line: ±0.05% of rated output current over a

±10% change of nominal input line voltage

±0.1% of rated output current for a change Load:

from 50% to 100% of rated output voltage

Current Accuracy:

Current measured through the X-Ray tube is within ±2% of the programmed value

Current Risetime:

Ramp time shall be <500ms from 10% to 90% of maximum rated current

Arc Intervention:

4 arcs in 10 seconds with a 100ms quench/100ms

re-ramp = Shutdown



80KV @ 100W MONOBLOCK®

PAGE 2 OF 6

Filament Configuration:

Internal AC filament drive with closed loop filament emission control

Analog Monitoring Interface:

Ground referenced 0 to 9Vdc for all monitoring signals. Relay contacts and open collector signals for other signals. See analog interface connector pin out table.

Digital Programming and Monitoring Interface:

The RS-232 interface allows for programming of kV, mA output and X-Ray enable. Provides monitoring for kV, mA output and oil temperature. Tolerance 3%. (with an additional 5µA offset at ≤10% mA programming)

Control Software:

A demo GUI is available for engineering evaluations

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

Cooling:

X-Ray Tank: Customer provided 250 cfm external

cooling fan as required to maintain oil

temperature below 55°C.

Controller: Forced air via internal fan.

Input Line Connector:

3-pin Phoenix Contact 1829167. Mating connector provided with unit

Analog Interface Connector:

15 pin male D connector provided with unit

Digital Interface Connector:

9 pin female D connector provided with unit

Grounding Point:

M4 ground stud provided on chassis

Dimensions:

X-Ray Tank: 11.3 L x 9.625 W x 4.93 H

(287.02mm x 244.4mm x 125.2mm

Standard

Controller: 8.5 L x 6.70 W x 2.21 H

(215.9mm x 170.2mm x 56.1mm)

Smart

Controller: 8.5 L x 7.14 W x 2.40 H

(215.9mm x 181.4mm x 61.0mm)

Weight:

X-Ray Tank: 36lbs (16.32kg)

Standard

Controller: 3.7lbs (1.68kg)

Smart

Controller: 3.9lbs (1.77kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E235530

SMART XRB (only available with Smart Controller option)

The XRB80PN100HR with the Smart Controller (SC option) has two new digital features available: data logging and firmware controlled seasoning.

Data Logging:

Think of this as an "airplane black box". The data logging captures data on fault events and non-fault events. Fault events will turn off the high voltage:

FAULT EVENTS

Temperature Arc
High Current Low Voltage
High Voltage Watchdog
Power Fault Interlock

The XRB80PN100HR stores data 620ms before the event, the event itself and for 620ms after the event. Data is recorded every 20ms (62 samples total) showing:

Anode kV Cathode kV
Total kV Total mA
Filament Temperature

We also log non-fault events, these are changes in set points or state of the unit.

NON FAULT EVENTS

HV On HV Off
kV Set point mA Set point
Low Current Pre Heat Set point

Fault event data is actual graphical data. Non fault event data is just stored as event type, data and timestamp. We also have a preventative maintenance fault, which throws a non-shutdown alarm if the X-Ray tube has been factory installed over 4 years ago or if over 15,000 hours of HV ON is logged.

Firmware Controlled Seasoning:

Every unit comes with an initial seasoning table, or customers can set their own. The XRB80PN100HR knows when the unit has been on, when it has been off, hours on the X-Ray tube, etc. As a preventative maintenance feature upon turn on, we review the data and suggest that a particular seasoning protocol be run based upon the actual usage history of the unit. Proper seasoning compliance of the X-Ray tube will help get the longest lifetime.

How to Order:	
Standard	PART NO.: XRB80PN100HR
Cone Beam Option	PART NO.: XRB80PN100HR/CB
0.5mm Focal Spot Option	PART NO.: XRB80PN100HR/.5mm
Narrow Fan Beam Option	PART NO.: XRB80PN100HR/NF
Cable Option	PART NO.: XRB80PN100HR/RA
Smart Controller Option	PART NO.: XRB80PN100HR/SC

80KV @ 100W MONOBLOCK®

PAGE 3 OF 6

AC LINE POWER CONNECTOR— J1 THREE POSITION PHOENIX CONTACT

PIN	SIGNAL
1	Earth Ground
2	Line
3	Neutral

Mating connector provided with unit

RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	TD	Transmit Data
3	RD	Receive Data
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

ETHERNET DIGITAL INTERFACE*— J4 8 PIN RJ45 CONNECTOR

PIN	SIGNAL	PARAMETERS
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receive Data +
4	N/C	No Connection
5	N/C	No Connection
6	RX-	Receive Data -
7	N/C	No Connection
8	N/C	No Connection

^{*}Ethernet interface for Smart Controller option only

LED INDICATORS

INDICATOR	SIGNAL NAME	CONDITION Illuminated When
LED 1	OV	High kV occurs
LED 2	UV	Low kV occurs
LED 3	UC	Low mA occurs
LED 4	OC	High mA occurs
LED 5	ARC FLT	Arc fault occurs
LED 6	OT	Over temperature occurs
LED 7	X-RAY ON	X-Rays are enabled
LED 8	PWR	Power is ON


XRB80PN100HR ANALOG INTERFACE— J2 15 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	Power Supply Fault Output	Open collector, 35V @ 10mA max. high = no fault
2	N/C	No Connection
3	N/C	No Connection
4	X-Ray On Lamp Relay Output	Common, dry contacts, 30Vdc @ 1A, max
5	X-Ray On Lamp Relay Output	Normally open, X-Ray ON = closed
6	mA Monitor Output	0 to 9Vdc = 0 to 100% rated output, Zout = $10k\Omega$
7	X-Ray On Lamp Relay Output	Normally closed, X-Ray ON = open
8	kV Monitor Output	0 to 9.00Vdc = 0 to 100% rated output, Zout = $10k\Omega$
S	Signal Ground	Ground
10	Signal Ground	Ground
11	HV Interlock Return Input	Connect to Pin 12 to close HV interlock
12	HV Interlock Output	+15Vdc @ open, 5mA when connected to pin 11
13	X-Ray Enable Output	+15Vdc @ open, 5mA when connected to pin 15
14	X-Ray Status Output	Open collector, 35V @ 10mA max high = X-Ray OFF
15	X-Ray Enable Return Input	Connect to pin 13 to enable X-Ray generation (for local enable)

PAGE 4 OF 6

DIMENSIONS: in.[mm]


STANDARD CONTROL UNIT TOP VIEW



SIDE VIEW



BOTTOM VIEW








PAGE 5 OF 6

DIMENSIONS: in.[mm]


SMART CONTROL UNIT TOP VIEW



SIDE VIEW



BOTTOM VIEW



Corporate Headquarters






147


PAGE 6 OF 6


DIMENSIONS: in.[mm]

GENERATOR TANK TOP VIEW



FRONT VIEW











 Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics

- Compact & Lightweight
- Universal input, Power Factor Corrected with Internal EMI Filter
- Can be Mounted in Any Physical Orientation
- Analog Control Interface and Standard RS-232 Digital Interface

Spellman's XRB100N100 Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 100kV at 100W. Features like universal input, small package size and a standard analog and RS-232 digital interface simplify integrating this Monoblock® into your X-Ray system. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Food Inspection, Fill Level Confirmation and Security Applications

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Stationary anode, tungsten target

Focal Spot: 0.5mm (IEC 336)
Beam Filter: Lexan: 3.2mm

Oil: 10mm ±0.1mm Glass: 1.8mm max

Beam Geometry: Symmetrical fan

74° x 10° ±1°

Input Voltage:

Power factor corrected input 0.98, 100-240Vac ±10% 50/60Hz, 2A, maximum

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 40kV to 100kV

X-Ray Tube Current:

100uA to 1mA over specified tube voltage range

X-Ray Tube Power:

100W maximum continuous

Voltage Regulation:

Line: ±0.1% of maximum output voltage over a

±10% change of nominal input line voltage

Load: ±0.1% of maximum rated voltage for 100uA

to 1mA load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

Voltage Risetime:

Ramp time shall be 1 second from 10% to 90% of maximum rated output voltage

Voltage Overshoot:

5% of maximum voltage, to return within 2.5% of maximum voltage in less than 50ms

Voltage Ripple:

0.5% peak to peak of maximum voltage for frequencies $\leq 1 \text{kHz}$

Emission Current Parameters Current Regulation:

Line: ±0.5% of rated output current over a

±10% change of nominal input line voltage

Load: ±0.5% of rated output current for a change from

50% to 100% of rated output voltage

Current Accuracy:

Current measured through the X-Ray tube is within

±1% of the programmed value

Current Risetime:

Ramp time shall be 1 second from 10% to 90% of maximum rated current

Arc Intervention:

3 arcs in 10 seconds with a 200ms quench = Shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control



e-mail: sales@spellmanhv.com

100KV @ 100W MONOBLOCK®

PAGE 2 OF 3

Analog Interface:

Ground referenced 0 to 9Vdc for all programming and monitoring signals. Relay contacts and open collector signals for other signals. See analog interface connector pin out table.

Digital Interface:

Jumpers are needed to be configured and the digital interface cable installed to enable the RS-232 interface.

A demo GUI is available for engineering evaluations.

Interlock/Signals:

A hardware interlock functions in both analog and digital programming modes. The hardware X-Ray Enable signal only functions in analog programming mode.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

Cooling:

Forced air and natural convection augmented by customer provided external cooling fan to maintain oil temperature below 55°C.

Input Line Connector:

3 pin, Phoenix Contact 1829167, SHV part number 105725-219. Mating connector Phoenix Contact #1805990, SHV part number 105808-475 provided with unit.

Analog Interface Connector:

15 pin D connector, male

Digital Interface Connector:

9 pin D connector, female

Grounding Point:

M4 ground stud provided on chassis

Dimensions:

See page 3 of 3

Weight:

55lbs (25kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface.

AC LINE POWER CONNECTOR-THREE POSITION PHOENIX CONTACT

PIN	SIGNAL	
1	Earth Ground	
2	Line	
3	Neutral	

Mating connector provided with unit

RS-232 DIGITAL INTERFACE— J3 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	TD	Transmit Data
3	RD	Receive Data
4	N/C	No Connection
5	SGND	Signal Ground
6	NC	No Connection
7	NC	No Connection
8	NC	No Connection
9	NC	No Connection

XRB ANALOG INTERFACE— J2 15 PIN MALE D CONNECTOR

1	PIN	SIGNAL	PARAMETERS
Г	1	Power Supply Fault Output	Open collector, 35V @ 10mA max. high = no fault
	2	mA Program Input	0 to 9.00Vdc = 0 to 100% rated output, Zin = $10M\Omega$
	3	kV Program Input	0 to 9.00Vdc = 0 to 100% rated output, Zin = $10M\Omega$
	4	X-Ray On Lamp Relay Output	Common, dry contacts, 30Vdc @ 1A, max
L	5	X-Ray On Lamp Relay Output	Normally open, X-Ray ON = closed
L	6	mA Monitor Output	0 to 9Vdc = 0 to 100% rated output, Zout = $10k\Omega$
L	7	X-Ray On Lamp Relay Output	Normally closed, X-Ray ON = open
L	8	kV Monitor Output	0 to 9.00Vdc = 0 to 100% rated output, Zout = $10k\Omega$
L	9	Signal Ground	Ground
1	10	Signal Ground	Ground
	11	HV Interlock Return Input	Connect to Pin 12 to close HV interlock
	12	HV Interlock Output	+15Vdc @ open, 5mA when connected to pin 11
	13	X-Ray Enable Output	+15Vdc @ open, 5mA when connected to pin 15
	14	X-Ray Status Output	Open collector, 35V @ 10mA max high = X-Ray OFF
	15	X-Ray Enable Return Input	Connect to pin 13 to enable X-Ray generation

LED INDICATORS


INDICATOR	SIGNAL NAME	CONDITION Illuminated When
LED 1	OV	High kV occurs
LED 2	UV	Low kV occurs
LED 3	UC	Low mA occurs
LED 4	OC	High mA occurs
LED 5	ARC FLT	Arc fault occurs
LED 6	OT	Over temperature occurs
LED 7	X-RAY ON	X-Rays are enabled
LED 8	PWR	Power is ON

100KV @ 100W MONOBLOCK®


PAGE 3 OF 3

DIMENSIONS: in.[mm]


X-RAY GENERATOR **FRONT VIEW**




TOP VIEW




SIDE VIEW





+1-631-630-3000


CONTROL UNIT FRONT VIEW




TOP VIEW



SIDE VIEW



BOTTOM VIEW



PAGE 1 OF 8



Spellman's XRBHR (high reliability) Series of Monoblock® X-Ray sources are designed for OEM applications powering their internal Bipolar X-Ray tube at 80kV and 100kV at power levels of 100W, 210W, 350W and 500W. Features such as universal input, compact package size and a standard RS-232 digital interface simplify integration of any XRBHR model into your X-Ray system. Each XRBHR model is available with fan shaped (standard) or cone shaped (optional) beam geometries. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance. The XRBHR Series is designed for long field life and comes with a 3 year warranty.

TYPICAL APPLICATIONS

Food Inspection Systems, Fill Level Confirmation Systems, Security Scanning Systems, Industrial NDT Systems, Thickness/Plating Measurement Systems

OPTIONS

CB Cone Beam

.5mm .5mm focal spot X-Ray tube

ST-TE

RA-SE | See page 4 for Cable Options

RA-TE

SPECIFICATIONS

X-Ray Characteristics:

Beam Geometry:

Focal Spot: 0.8mm (IEC 336) standard

0.5mm (IEC 336) optional

Beam Filter:

1.50mm ±0.15mm Ultem: Oil: 9.0mm ±0.25mm Glass: 1.7mm ±0.2mm

Be: 0.8mm

Standard. The beam angular coverage Fan:

will be 90° with the beam plane

perpendicular to the X-Ray tube axis and

12° wide (with a 2° tolerance)

Optional. 40° cone beam (with a 2° tolerance) Cone:

Compact & Lightweight

- Universal Input, Power Factor Corrected
- Can be Mounted in Any Physical Orientation
- Analog Monitoring Interface, Standard RS-232 Digital Interface and Ethernet
- Data Logging and Firmware Controlled X-Ray Tube Seasoning

Input Voltage:

100-240Vac, ±10%, 50/60 Hertz, .98 power factor

Input Current:

100W @ 2A

210W @ 4A

350W @ 6A

500W @ 8A

X-Ray Tube Voltage:

See table. Minimum kV for emission current 35kV

X-Ray Tube Current:

See table. Minimum emission current 150uA

X-Ray Tube Power:

See table

Voltage Regulation:

Line: ±0.05% of maximum output voltage over a ±10%

change of nominal input line voltage

±0.1% of maximum rated voltage for 150uA Load:

to full rated load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

Voltage Risetime:

Standard ramp time shall be <500ms from 10% to 90% of maximum rated output voltage

Voltage Ripple:

0.5% peak to peak of maximum voltage for frequencies ≤1kHz

Emission Current Parameters

Current Regulation:

±0.05% of rated output current over a Line:

±10% change of nominal input line voltage

Load: ±0.1% of rated output current for a change from

50% to 100% of rated output voltage

Current Accuracy:

Current measured through the X-Ray tube is within ±2% of the programmed value

Current Risetime:

Standard ramp time shall be <500ms from 10% to 90% of maximum rated current

Arc Intervention:

4 arcs in 10 seconds with a 100ms quench/100ms re-ramp = Shutdown

Filament Configuration:

Internal floating AC filament drive with closed loop filament emission control circuitry



PAGE 2 OF 8

Analog Interface:

Ground referenced 0 to 9Vdc for all monitoring signals. Relay contacts and open collector signals for other signals. See analog interface connector pin out table.

Digital Interface:

The RS-232 interface allows for programming of kV, mA output and X-Ray enable. Provides monitoring for kV, mA output and oil temperature.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

Cooling:

X-Ray Tank:

100W: Convection/customer supplied

forced air so tank is <55°C

210W: Externally powered forced air cooling,

24Vdc @ 2A

350W: Externally powered forced air cooling

with oil pump and heat exchanger,

24Vdc @ 5A

500W: Externally powered forced air cooling

with oil pump and heat exchanger,

24Vdc @ 5A

Controller: Forced air via internal fan.

Grounding Point:

M5 ground female thread on tank

M5 ground stud on control chassis provided

Dimensions:

X-Ray Tank: see drawings

100W/210W Controller: see drawings 350W/500W Controller: see drawings

Weight:

X-Ray Tank:

100W @ 75 lbs. (34kg) 210W @ 75lbs. (34kg) 350W @ 81.5lbs. (37kg) 500W @ 81.5lbs. (37kgs)

100W/210W: 4 pounds (1.18kg) 350W/500W: 7 pounds (3.18kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E235530

MODEL SELECTION TABLE

MODEL	MAX. VOLTAGE	MAX. CURRENT	MAX. POWER
XRB80PN210HR	80kV	5.25mA	210 watts
XRB80PN350HR	80kV	8mA	350 watts
XRB80PN500HR	80kV	8mA	500 watts
XRB100PN100HR	100kV	2mA	100 watts
XRB100PN210HR	100kV	4.2mA	210 watts
XRB100PN350HR	100kV	7mA	350 watts
XRB100PN500HR	100kV	8mA	500 watts

LED INDICATORS

INDICATOR	SIGNAL	CONDITION Illuminated When	LED COLOR
1	OV Error 6	High kV occurs	Red
2	UV Error 5	Low kV occurs	Red
3	UC Error 4	Low mA occurs	Red
4	OC Error 3	High mA occurs	Red
5	ARC Error 2	Arc fault occurs	Red
6	OT Error 1	Over temperature occurs	Red
7	X-Ray On	X-Rays are being generated	Green
8	Power On	AC input power is present	Green

SMART XRB

The XRBHR has two new digital features: data logging and firmware controlled seasoning.

Data Logging:

Think of this as an "airplane black box". The data logging captures data on fault events and non-fault events. Fault events will turn off the high voltage:

FAULT EVENTS

Temperature High Current Low Voltage High Voltage Watchdog Power Fault Interlock

The XRBHR stores data 620ms before the event, the event itself and for 620ms after the event. Data is recorded every 20ms (62 samples total) showing:

Anode kV Cathode kV Total kV Total mA Filament Temperature

We also log non-fault events, these are changes in set points or state of the unit.

NON FAULT EVENTS

HV On HV Off kV Set point mA Set point

Low Current Filament Limit Set point

Pre Heat Set point Line Dip

Fault event data is actual graphical data. Non fault event data is just stored as event type, data and timestamp. We also have a preventative maintenance fault, which throws a non-shutdown fault if the X-Ray tube has been factory installed over 4 years ago or if over 15,000 hours of HV ON is logged.

Firmware Controlled Seasoning:

Every unit comes with an initial seasoning table, or customers can set their own. The XRBHR knows when the unit has been on, when it has been off, hours on the X-Ray tube, etc. As a preventative maintenance feature upon turn on, we review the data and suggest that a particular seasoning protocol be run based upon the actual usage history of the unit. Proper seasoning compliance of the X-Ray tube will help get the longest lifetime.



153

PAGE 3 OF 8

Power and Interface Connections

AC INPUT—3 PIN PHOENIX CONTACT 1858772

PIN	SIGNAL	PARAMETERS
1	AC Input (high)	100-240Vac (high)
2	Ground	Ground
3	AC Input (neutral)	100-240Vac (neutral)

DC INPUT FOR HEAT DISSIPATION UNIT-4 PIN AMP (210/350/500W) 206060-1

PIN	SIGNAL	DESCRIPTION	PARAMETERS
1	24Vdc	Fan/Pump Power	24Vdc @ 5 amps
2	24Vdc Return	r ann ump r ower	24Vuc @ 5 amps
3	N/C	No Connection	N/C
4	N/C	No Connection	N/C

It is critical to ensure that 24Vdc is supplied to pins 1 and 2

ANALOG INTERFACE— 10 PIN PHOENIX CONTACT 1792605


PIN	SIGNAL	PARAMETERS
1	X-Ray Interlock Enable	Apply +24Vdc to enable interlock. Open/removal of +24Vdc will cause X-Ray generation to stop.
2	X-Ray Interlock Enable Return	Ground reference for X-Ray Interlock.
3	Pin removed	N/C
4	kV Monitor	0-10Vdc = 0-100% rated output voltage. Zout = 10kΩ
5	Signal Ground	Signal Ground
6	mA Monitor	0-10Vdc = 0-100% rated output current. Zout =10kΩ
7	Fault Signal	Open collector, High (Open) = No Fault, 35Vdc @ 10mA maximum
8	HV ON Lamp Relay N/O	N/O dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load
9	HV ON Lamp Relay C	Common dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load
10	HV ON Lamp Relay N/C	N/C dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load

RS-232 DIGITAL INTERFACE— 9 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	N/C
2	Transmitted Data	Conforms to EIA RS-232-C
3	Received Data	Conforms to EIA RS-232-C
4	N/C	N/C
5	Signal Ground	Signal Ground
6	N/C	N/C
7	N/C	N/C
8	N/C	N/C
9	N/C	N/C

ETHERNET DIGITAL INTERFACE—RJ45 8 PIN FEMALE CONNECTOR

PIN	SIGNAL	PARAMETERS
1	TX +	Transmit Data +
2	TX -	Transmit Data -
3	RX +	Receive Data +
4	N/C	No Connection
5	N/C	No Connection
6	RX -	Receive Data -
7	N/C	No Connection
8	N/C	No Connection






DIMENSIONS: in.[mm]

350/500W CONTROL UNIT

FRONT VIEW



BOTTOM VIEW



REAR VIEW M5 x 10mm Dp 4PL 413 [10.5] .515 [13.1] 12.52 [318.0]

SIDE VIEW



SIDE VIEW








PAGE 6 OF 8

DIMENSIONS: in.[mm]

100W TANK TOP VIEW












PAGE 7 OF 8

DIMENSIONS: in.[mm]

210W TANK TOP VIEW








PAGE 8 OF 8


DIMENSIONS: in.[mm]

350/500W TANK

TOP VIEW




SIDE VIEW



BACK VIEW

FRONT VIEW





PAGE 1 OF 8



Spellman's XRBD Series of Monoblock® X-Ray sources are designed for OEM applications powering their internal bipolar X-Ray tube at 160kV at power levels of 100W, 210W, 350W and 500W. Features such as universal input, compact package size and a standard RS-232 digital interface simplify integration of any XRBD model into your X-Ray system. Each XRBD model is available with fan shaped (standard) or cone shaped (optional) beam geometries. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

Food Inspection Systems, Fill Level Confirmation Systems, Security Scanning Systems, Industrial NDT Systems, Thickness/Plating Measurement Systems

OPTIONS

CB Cone Beam

.5mm .5mm focal spot X-Ray tube

ST-TE

RA-SE See page 4 for Cable Options

RA-TE

SPECIFICATIONS

X-Ray Characteristics:

0.8mm (IEC 336) standard Focal Spot:

0.5mm (IEC 336) optional

Beam Filter:

Ultem: 1.50mm ±0.15mm 9.0mm ±0.25mm Oil: 1.7mm ±0.2mm Glass:

0.8mm Be:

Beam Geometry:

Standard. The beam angular coverage Fan:

will be 90° with the beam plane

perpendicular to the X-Ray tube axis and

12° wide (with a 2° tolerance)

Optional. 40° cone beam (with a 2° tolerance) Cone:

Compact & Lightweight

- Universal Input, Power Factor Corrected
- Can be Mounted in Any Physical Orientation
- Analog Monitoring Interface, Standard RS-232 Digital Interface and Ethernet
- Data Logging and Firmware Controlled X-Ray Tube Seasoning

Input Voltage:

100-240Vac, ±10%, 50/60 Hertz, .98 power factor

Input Current:

100W @ 2.0A

210W @ 4.0A

350W @ 6.0A

500W @ 8.0A

X-Ray Tube Voltage:

See table. Minimum kV for emission current 35kV

X-Ray Tube Current:

See table. Minimum emission current 150uA

X-Ray Tube Power:

See table

Voltage Regulation:

±0.05% of maximum output voltage over a ±10% Line:

change of nominal input line voltage

±0.1% of maximum rated voltage for 150uA Load:

to full rated load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

Voltage Risetime:

Standard ramp time shall be <500ms from 10% to 90% of maximum rated output voltage

Voltage Ripple:

0.5% peak to peak of maximum voltage for frequencies ≤1kHz

Emission Current Parameters Current Regulation:

Line: ±0.05% of rated output current over a

±10% change of nominal input line voltage

±0.1% of rated output current for a change from Load:

50% to 100% of rated output voltage

Current Accuracy:

Current measured through the X-Ray tube is within ±2% of the programmed value

Current Risetime:

Standard ramp time shall be <500ms from 10% to 90% of maximum rated current

Arc Intervention:

4 arcs in 10 seconds with a 100ms quench/100ms re-ramp = Shutdown

Filament Configuration:

Internal floating AC filament drive with closed loop filament emission control circuitry



PAGE 2 OF 8

Analog Interface:

Ground referenced 0 to 9Vdc for all monitoring signals. Relay contacts and open collector signals for other signals. See analog interface connector pin out table.

Digital Interface:

The RS-232 interface allows for programming of kV, mA output and X-Ray enable. Provides monitoring for kV, mA output and oil temperature.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

Cooling:

X-Ray Tank:

100W: Convection/customer supplied

forced air so tank is <55°C

210W: Externally powered forced air cooling,

24Vdc @ 2A

350/500W: Externally powered forced air cooling

with oil pump and heat exchanger,

24Vdc @ 5A

Controller: Forced air via internal fan

Grounding Point:

M5 ground female thread on tank

M5 ground stud on control chassis provided

Dimensions:

see drawings

Weight:

X-Ray Tank:

100/210W @ 78lbs. (35.4kg) 350/500W @ 84.5lbs. (38.3kg)

Controller:

100W/210W: 4 pounds (1.18kg) 350W/500W: 7 pounds (3.18kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E235530.

MODEL SELECTION TABLE

MODEL	MAX. VOLTAGE	MAX. CURRENT	MAX. POWER
XRBD160PN100	160kV	1mA	100 watts
XRBD160PN210	160kV	2.1mA	210 watts
XRBD160PN350	160kV	3.5mA	350 watts
XRBD160PN500	160kV	4mA	500 watts

LED INDICATORS

INDICATOR	SIGNAL	CONDITION Illuminated When	LED COLOR
1	OV Error 6	High kV occurs	Red
2	UV Error 5	Low kV occurs	Red
3	UC Error 4	Low mA occurs	Red
4	OC Error 3	High mA occurs	Red
5	ARC Error 2	Arc fault occurs	Red
6	OT Error 1	Over temperature occurs	Red
7	X-Ray On	X-Rays are being generated	Green
8	Power On	AC input power is present	Green

SMART XRB

The XRBD has two new digital features: data logging and firmware controlled seasoning.

Data Logging

Think of this as an "airplane black box". The data logging captures data on fault events and non-fault events. Fault events will turn off the high voltage:

FAULT EVENTS

Temperature Arc
High Current Low Voltage
High Voltage Watchdog
Power Fault Interlock

The XRBD stores data 620ms before the event, the event itself and for 620ms after the event. Data is recorded every 20ms (62 samples total) showing:

Anode kV Cathode kV
Total kV Total mA
Filament Temperature

We also log non-fault events, these are changes in set points or state of the unit.

NON FAULT EVENTS

HV On HV Off kV Set point mA Set point

Low Current Filament Limit Set point

Pre Heat Set point Line Dip

Fault event data is actual graphical data. Non fault event data is just stored as event type, data and timestamp. We also have a preventative maintenance fault, which throws a non-shutdown fault if the X-Ray tube has been factory installed over 4 years ago or if over 15,000 hours of HV ON is logged.

Firmware Controlled Seasoning:

Every unit comes with an initial seasoning table, or customers can set their own. The XRBD knows when the unit has been on, when it has been off, hours on the X-Ray tube, etc. As a preventative maintenance feature upon turn on, we review the data and suggest that a particular seasoning protocol be run based upon the actual usage history of the unit. Proper seasoning compliance of the X-Ray tube will help get the longest lifetime.



PAGE 3 OF 8

Power and Interface Connections

AC INPUT—3 PIN PHOENIX CONTACT 1858772

PIN	SIGNAL	PARAMETERS
1	AC Input (high)	100-240Vac (high)
2	Ground	Ground
3	AC Input (neutral)	100-240Vac (neutral)

DC INPUT FOR HEAT DISSIPATION UNIT-4 PIN AMP (210/350/500W) 206060-1

PIN	SIGNAL	DESCRIPTION	PARAMETERS
1	24Vdc	Fan/Pump Power	24Vdc @ 5 amps
2	24Vdc Return	ranyrump rowei	24vuc @ 3 amps
3	N/C	No Connection	N/C
4	N/C	No Connection	N/C

It is critical to ensure that 24Vdc is supplied to pins 1 and 2

ANALOG INTERFACE— 10 PIN PHOENIX CONTACT 1792605

PIN	SIGNAL	PARAMETERS
1	X-Ray Interlock Enable	Apply +24Vdc to enable interlock. Open/removal of +24Vdc will cause X-Ray generation to stop.
2	X-Ray Interlock Enable Return	Ground reference for X-Ray Interlock.
3	Pin removed	N/C
4	kV Monitor	0-10Vdc = 0-100% rated output voltage. Zout = 10 kΩ
5	Signal Ground	Signal Ground
6	mA Monitor	0-10Vdc = 0-100% rated output current. Zout =10kΩ
7	Fault Signal	Open collector, High (Open) = No Fault, 35Vdc @ 10mA maximum
8	HV ON Lamp Relay N/O	N/O dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load
9	HV ON Lamp Relay C	Common dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load
10	HV ON Lamp Relay N/C	N/C dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load


RS-232 DIGITAL INTERFACE— 9 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	N/C
2	Transmitted Data	Conforms to EIA RS-232-C
3	Received Data	Conforms to EIA RS-232-C
4	N/C	N/C
5	Signal Ground	Signal Ground
6	N/C	N/C
7	N/C	N/C
8	N/C	N/C
9	N/C	N/C

ETHERNET DIGITAL INTERFACE—RJ45 8 PIN FEMALE CONNECTOR

PIN	SIGNAL	PARAMETERS
1	TX +	Transmit Data +
2	TX -	Transmit Data -
3	RX +	Receive Data +
4	N/C	No Connection
5	N/C	No Connection
6	RX -	Receive Data -
7	N/C	No Connection
8	N/C	No Connection

PAGE 4 OF 8



Hauppauge, New York USA

e-mail: sales@spellmanhv.com

FAX: +1-631-435-1620

+1-631-630-3000


163

PAGE 5 OF 8

DIMENSIONS: in.[mm]


350/500W CONTROL UNIT

FRONT VIEW



BOTTOM VIEW





SIDE VIEW



SIDE VIEW








PAGE 6 OF 8

DIMENSIONS: in.[mm]

100W TANK TOP VIEW








Corporate Headquarters





PAGE 7 OF 8

DIMENSIONS: in.[mm]

210W TANK TOP VIEW







e-mail: sales@spellmanhv.com


+1-631-630-3000

PAGE 8 OF 8


DIMENSIONS: in.[mm]


350/500W TANK

TOP VIEW



SIDE VIEW





Corporate Headquarters

Hauppauge, New York USA



www.spellmanhv.com



Spellman's XRB180PN200 is an integrated X-Ray source operating up to 180kV and 200W, providing OEM users a compact plug-and-play Monoblock for critical inspection and screening applications. The unit incorporates a 25° angle stationary anode X-Ray tube offering a fan beam of 80°x 4°. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, with industry leading dose stability and image quality. This compact model comes with standard analog and RS-232 digital control. Spellman can provide customized versions of this platform for specific OEM system requirements.

TYPICAL APPLICATIONS

Aviation Security Screening: Checked Baggage/EDS, Checkpoint. Vehicle Inspection, General NDT, Food Inspection

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Stationary Anode, tungsten target
Focal Spot: 0.8 x 0.8mm nominal (IEC60336)
Beam Filter: Consists of oil and the curved Ultem
0.079" +/-0.01". Inherent filtration in

the X-Ray Tube is 1mm Be, 1.5mm

+/-10% glass.

Beam Geometry: Fan of 80° X 4°, ±1%

Anode Angle: 25°

Input Voltage:

Power factor corrected input to 0.98. 100Vac to 240Vac, ±10%, 50/60 Hertz. 5A, maximum

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 90kV to 180kV.

Voltage Accuracy:

The high voltage measured at the X-ray tube will be within ±1% of the selected value.

Voltage Ripple:

Ripple will be $\leq 0.2\%$ of maximum rated voltage for frequencies $\leq 1 \text{kHz}$.

Voltage Regulation:

 $< \pm 0.1\%$ for $\pm 10\%$ of nominal input line change $< \pm 0.1\%$ for 0.5mA to 1.11mA load change

- 180kV and 200W
- X-Ray Tube Current: 0.5mA to 1.1mA
- Focal Spot 0.8 x 0.8mm nominal (IEC60336)
- Fan Beam of 80° X 4°, maximum
- Power factor corrected input to 0.98
- 100Vac to 240Vac, ±10%

Voltage Overshoot:

kV overshoot will return within 5% of full voltage in less than 10ms.

Risetime:

The voltage and current risetime is controlled by a ramping circuit. Ramp time is less than 0.5 second from 10% to 90% of output voltage and current.

X-Ray Tube Current:

0.5mA to 1.1mA @ 180kV, 200 Watts maximum

Current Accuracy:

<±1% of the selected value.

Current Regulation:

<0.5% at 90-180kV, 0.5mA to 1.1mA

Arc Intervention:

Unit will detect a single arc but HV will not shut down. If multiple arcs occur (4 in 10 seconds) then the unit will shut down.

Filament Configuration:

Internal high frequency AC filament drive operated in current mode with closed loop filament emission control.

Analog Interface:

Ground referenced 0 to 10Vdc for all monitoring signals. Relay contacts and open collector outputs for other signals.

Digital Interface:

The RS-232 interface allows for programming of the voltage, current, and X-Ray Enable. Provides monitoring for voltage, current and oil temperature. Tolerance is 3% (with additional 5uA offset at ≤10%mA programming).

Control Software:

A demo GUI is available for engineering evaluation.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing.

Cooling:

Via natural convection/external cooling fans of 100CFM minimum or maintaining tank/oil temperature below 55°C.



e-mail: sales@spellmanhv.com

180KV @ 200W MONOBLOCK®

PAGE 2 OF 3

Input Line Connector:

3 pin Phoenix Contact, p/n 1829167. Mating connector provided with unit.

Analog Interface Connector:

10 pin Phoenix Contact, p/n 1755503. Mating connector provided with unit.

Digital Interface Connector:

9 pin female D connector. Mating connector provided with unit.

Grounding Point:

M4 grounding stud provided on chassis.

Dimensions:

See outline drawing.

Weight:

132 pounds (60kg).

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than .5mR/hr at 5cm from any surface of the Monoblock® when measured at 180kV @ 1.1mA.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive.

AC INPUT POWER PIN PHOENIX CONTACT P/N 1829167

PIN	SIGNAL	PARAMETERS
1	Line	100-240Vac,±10%, 50/60 Hertz @ 6 amps
2	GND	Ground
3	Neutral	100-240Vac,±10%, 50/60 Hertz @ 6 amps

ANALOG INTERFACE— 10 PIN PHOENIX CONTACT P/N 1755503

	PIN	SIGNAL	PARAMETERS
	1	X-Ray On	+24Vdc = Enable X-Ray, Low or open = Disable X-Ray
۱	2	X-Ray On Return	X-Ray on Return
ı	3	N/C	No Connection
١	4	kV Monitor	0 to 10Vdc = 0 to 200kV, Zout = $10k\Omega$
١	5	SGND	Signal Ground
	6	mA Monitor	0 to 10Vdc = 0 to 1.5mA, Zout = $10k\Omega$
	7	Fault	Open Collector, High (Open) = No Fault, 35Vdc @ 10mA, maximum
	8	HV On Lamp N/O	Relay dry contact, normally open, 30Vdc @ <1A, nominal 50mA DC load
	9	HV On Lamp Common	Relay dry contact, common, 30Vdc @ <1A, nominal 50mA DC load
	10	HV On Lamp N/C	Relay dry contact, normally closed, 30Vdc @ <1A, nominal 50mA DC load

RS-232 DIGITAL INTERFACE— 9 PIN MALE D CONNECTOR

	PIN	SIGNAL	PARAMETERS
	1	N/C	No Connection
ı	2	Transmit Data	Conforms to EAI RS-232-C
ı	3	Receive Data	Conforms to EAI RS-232-C
ı	4	N/C	No Connection
Î	5	SGND	Signal Ground
ı	6	N/C	No Connection
ı	7	N/C	No Connection
ı	8	N/C	No Connection
ĺ	9	N/C	No Connection


FRONT PANEL LED INDICATORS

INDICATOR	SIGNAL NAME	CONDITION Illuminated When	LED COLOR
LED 1	OT	OverTemperature occurs	Red
LED 2	ARC	Arc fault occurs	Red
LED 3	UV	Low kV occurs	Red
LED 4	OV	High kV occurs	Red
LED 5	UC	Low mA occurs	Red
LED 6	OC	High mA occurs	Red
LED 7	X-RAY ON	X-Rays are enabled	Green
LED 8	PWR ON	Power is ON	Green


169

PAGE 3 OF 3

DIMENSIONS: in.[mm]




BACK VIEW



+1-631-630-3000

FRONT VIEW



Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

FAX: +1-631-435-1620



Spellman's XRBe80PN300 beryllium window Monoblock® X-Ray sources are designed for OEM applications powering the internal Bipolar X-Ray tube at 80kV at a power level of 300W. Features such as universal input, compact package size and a standard RS-232 digital interface simplify integration of the XRBe80PN300 into your X-Ray system. It is available with a cone shaped beam geometry. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

Food Inspection Systems, Fill Level Confirmation Systems, Security Scanning Systems, Industrial NDT Systems, Thickness/Plating Measurement Systems

OPTIONS

0.8mm 0.8mm focal spot X-Ray tube

ST-TE

RA-SE Cable Options (see page 3)

RA-TE

SPECIFICATIONS

X-Ray Characteristics:

Focal Spot: 0.8mm (IEC 336) standard

Beam Filter: Be 0.8mm

Beam Geometry:

Cone: Standard. The beam angular coverage

will be 40° with the beam plane perpendicular to the X-Ray tube axis

Input Voltage:

100-240Vac, ±10%, 50/60 Hertz, .98 power factor

Input Current:

300W @ 6A

- Compact & Lightweight
- Universal Input, Power Factor Corrected
- Can be Mounted in Any Physical Orientation
- Analog Monitoring Interface, Standard RS-232 Digital Interface and Ethernet
- Data Logging and Firmware Controlled X-Ray Tube Seasoning

X-Ray Tube Voltage:

See table. Minimum kV for emission current 40kV

X-Ray Tube Current:

See table. Minimum emission current 300uA

X-Ray Tube Power:

300W

Voltage Regulation:

Line: ±0.05% of maximum output voltage over a ±10%

change of nominal input line voltage

Load: ±0.1% of maximum rated voltage for 150uA

to full rated load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

Voltage Risetime:

Standard ramp time shall be <500ms from 10% to 90% of maximum rated output voltage

Voltage Ripple:

0.5% peak to peak of maximum voltage for frequencies ≤1kHz

Emission Current Parameters Current Regulation:

Line: ±0.05% of rated output current over a

±10% change of nominal input line voltage

Load: ±0.1% of rated output current for a change

from 50% to 100% of rated output voltage

Current Accuracy:

Current measured through the X-Ray tube is within ±2% of the programmed value

Current Risetime:

Standard ramp time shall be <500ms from 10% to 90% of maximum rated current

Arc Intervention:

4 arcs in 10 seconds with a 100ms quench/100ms re-ramp = Shutdown

Filament Configuration:

Internal floating AC filament drive with closed loop filament emission control circuitry



PAGE 2 OF 5

Analog Interface:

Ground referenced 0 to 9Vdc for all monitoring signals. Relay contacts and open collector signals for other signals. See analog interface connector pinout table.

Digital Interface:

The RS-232 interface allows for programming of kV, mA output and X-Ray enable. Provides monitoring for kV, mA output and oil temperature.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

Cooling:

X-Ray Tank: Externally powered forced air cooling

with oil pump and heat exchanger,

24Vdc @ 5A

Controller: Forced air via internal fan.

Grounding Point:

M5 ground female thread on tank

M5 ground stud on control chassis provided

Dimensions:

X-Ray Tank: see drawings Controller: see drawings

Weight:

X-Ray Tank: 81.5lbs. (37kg) Controller: 7lbs. (3.18kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface.

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E235530

AC INPUT-3 PIN PHOENIX CONTACT 1858772

PIN	SIGNAL	PARAMETERS
1	AC Input (high)	100-240Vac (high)
2	Ground	Ground
3	AC Input (neutral)	100-240Vac (neutral)

DC INPUT FOR HEAT DISSIPATION UNIT-4 PIN AMP (210/350/500W) 206060-1

PIN	SIGNAL	DESCRIPTION	PARAMETERS
1	24Vdc	Fan/Pump Power	24Vdc @ 5 amps
2	24Vdc Return	r ann ump r ower	24Vuc @ 3 amps
3	N/C	No Connection	N/C
4	N/C	No Connection	N/C

It is critical to ensure that 24Vdc is supplied to pins 1 and 2

LED INDICATORS

INDICATOR	SIGNAL	CONDITION Illuminated When L	ED COLOR
1	OV Error 6	High kV occurs	Red
2	UV Error 5	Low kV occurs	Red
3	UC Error 4	Low mA occurs	Red
4	OC Error 3	High mA occurs	Red
5	ARC Error 2	Arc fault occurs	Red
6	OT Error 1	Over temperature occurs	Red
7	X-Ray On	X-Rays are being generated	Green
8	Power On	AC input power is present	Green

ANALOG INTERFACE— 10 PIN PHOENIX CONTACT 1792605

	PIN	SIGNAL	PARAMETERS
	1	X-Ray Interlock Enable	Apply +24Vdc to enable interlock. Open/removal of +24Vdc will cause X-Ray generation to stop.
	2	X-Ray Interlock Enable Return	Ground reference for X-Ray Interlock.
	3	Pin removed	N/C
	4	kV Monitor	0-10Vdc = 0-100% rated output voltage. Zout = 10 kΩ
1	5	Signal Ground	Signal Ground
ĺ	6	mA Monitor	0-10Vdc = 0-100% rated output current. Zout =10kΩ
	7	Fault Signal	Open collector, High (Open) = No Fault, 35Vdc @ 10mA maximum
Ī	8	HV ON Lamp Relay N/O	N/O dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load
	9	HV ON Lamp Relay C	Common dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load
	10	HV ON Lamp Relay N/C	N/C dry contacts. 50 volts maximum. Rated for 1 amp or less, 50mA nominal load

RS-232 DIGITAL INTERFACE— 9 PIN MALE D CONNECTOR


ŀ	PIN	SIGNAL	PARAMETERS
	1	N/C	N/C
Г	2	Transmitted Data	Conforms to EIA RS-232-C
	3	Received Data	Conforms to EIA RS-232-C
Г	4	N/C	N/C
Г	5	Signal Ground	Signal Ground
	6	N/C	N/C
L	7	N/C	N/C
I	8	N/C	N/C
L	9	N/C	N/C

ETHERNET DIGITAL INTERFACE— RJ45 8 PIN FEMALE CONNECTOR

PIN	SIGNAL	PARAMETERS
1	TX +	Transmit Data +
2	TX -	Transmit Data -
3	RX +	Receive Data +
4	N/C	No Connection
5	N/C	No Connection
6	RX -	Receive Data -
7	N/C	No Connection
8	N/C	No Connection
	•	

e-mail: sales@spellmanhv.com

CABLE CONFIGURATIONS



SMART XRB

The XRBe80PN300 has two new digital features: data logging and firmware controlled seasoning.

Data Logging:

Think of this as an "airplane black box". The data logging captures data on fault events and non-fault events. Fault events will turn off the high voltage:

FAULT EVENTS

Temperature Arc

High Current Low Voltage High Voltage Watchdog Power Fault Interlock

The XRBe80PN300 stores data 620ms before the event, the event itself and for 620ms after the event. Data is recorded every 20ms (62 samples total) showing:

Anode kV Cathode kV Total kV Total mA Filament Temperature

We also log non-fault events, these are changes in set points or state of the unit.

NON FAULT EVENTS

HV Off HV On kV Set point mA Set point

Low Current Filament Limit Set point

Pre Heat Set point Line Dip

Fault event data is actual graphical data. Non fault event data is just stored as event type, data and timestamp. We also have a preventative maintenance fault, which throws a non-shutdown fault if the X-Ray tube has been factory installed over 4 years ago or if over 15,000 hours of HV ON is logged.

Firmware Controlled Seasoning:

Every unit comes with an initial seasoning table, or customers can set their own. The XRBe80PN300 knows when the unit has been on, when it has been off, hours on the X-Ray tube, etc. As a preventative maintenance feature upon turn on, we review the data and suggest that a particular seasoning protocol be run based upon the actual usage history of the unit. Proper seasoning compliance of the X-Ray tube will help get the longest lifetime.




Corporate Headquarters

PAGE 4 OF 5

DIMENSIONS: in.[mm]

CONTROL UNIT


FRONT VIEW



BOTTOM VIEW



REAR VIEW



SIDE VIEW

SIDE VIEW









PAGE 5 OF 5

DIMENSIONS: in.[mm]


TOP VIEW



SIDE VIEW



FRONT VIEW



Corporate Headquarters

Hauppauge, New York USA

Copyright © 2023 Spellman High Voltage Electronics Corp.

8NKV @ 32NW MONORI OCK®

PAGE 1 OF 3



Spellman's XRB80PN320 Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 80kV at 320W. Features like small package size and RS-232 digital interface simplify integrating this Monoblock® into your X-Ray system. Standard models are available with fan shaped beam geometry. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Food Inspection, Fill Level Confirmation and Security Applications

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Glass tube, Tungsten target, Be filter

Focal Spot: 0.8mm x 0.8mm (IEC 336)
Beam Filter: 5052 AI, 0.040" (±0.01")

Beam Geometry: Asymmetrical fan 80° x 10° ±2°

Input Voltage:

200-240Vac ±10%, 50/60Hz, 6.5A max

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 40kV to 80kV

X-Ray Tube Current:

0.5mA to 4mA over specified tube voltage range

X-Ray Tube Power:

320W maximum continuous

Voltage Regulation:

Line: ±0.05% for a ±10% input line change Load: ±0.05% for a 0.5mA to 4mA load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

- Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics
- Compact & Lightweight
- Can be Mounted in Any Physical Orientation
- Standard RS-232 Digital Interface

Voltage Risetime:

Ramp time shall be <500ms from 10% to 90% of rated output

Voltage Overshoot:

Within 5% of rated voltage in <10ms

Voltage Ripple:

≤1% p-p of rated voltage @ 1kHz

Current Regulation:

Line: ±0.5% @ 50-100% V nominal over specified Line range Load: ±0.5% @ 50-100% V nominal over specified Load range

Current Accuracy:

Current measured through the X-Ray tube is within ±2% of the programmed value

Current Risetime:

<500ms from 10% to 90% of rated output

Arc Intervention:

4 arcs in 10 seconds = shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control

Analog Interface:

0 to 10Vdc ground referenced monitoring signals

Digital Interface:

RS-232

Control Software:

A demo GUI for engineering evaluations will be provided for the RS-232 digital interface upon request.

Interlock Signals:

A hardware interlock functions in digital programming modes.

Operating Temperature:

 0° C to $+40^{\circ}$ C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 90% relative humidity, non-condensing

Cooling:

Heat exchanger w/fan and oil pump



80KV @ 320W MONOBLOCK®

PAGE 2 OF 3

Input Line Connector:

Terminal block, Schurter, Inc. part no. 6100-33

Digital Interface Connector:

9 pin D, female

Analog Monitoring Connector:

10 pin Phoenix Contact 1755503

Grounding Point:

8-32 ground stud provided on chassis

Dimensions:

See line drawing

Weight:

120lbs (54.4kg) maximum

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface

Regulatory Approvals:

Designed to be compliant to EEC EMC Directive and EEC Low Voltage Directive with an external filter.

AC INPUT POWER TERMINAL BLOCK

PIN	SIGNAL	PARAMETERS
1	Line	Line
2	Line	Line
3	Line	Line
4	Neutral	Neutral
5	Neutral	Neutral
6	Neutral	Neutral


RS-232 DIGITAL INTERFACE JB16 9 PIN FEMALE D CONNECTOR


	PIN	SIGNAL	PARAMETERS
	1	N/C	No Connection
Ì	2	TX	RS-232 Transmit
	3	RX	RS-232 Receive
	4	N/C	No Connection
	5	SGND	Signal Ground
ĺ	6	N/C	No Connection
Ì	7	N/C	No Connection
	8	N/C	No Connection
ĺ	9	N/C	No Connection

ANALOG MONITORING— JB11 10 PIN PHOENIX CONTACT


PIN	SIGNAL	PARAMETERS
1	X-Ray Enable	+24Vdc = Enable X-Ray 0Vdc/Open = Disable X-Rays
2	RTN	Signal Return
3	N/C	No Connection
4	kV Monitor	0 to 10Vdc = 0 to 100kV, Zout = $10k\Omega$
5	SGND	Signal Return
6	mA Monitor	0 to 10Vdc = 0 to 5mA, Zout = $10k\Omega$
7	Fault	Open Collector, High (Open) = No Fault, 35Vdc @10mA max.
8	HV On Lamp, Relay N/O	Relay Normally Open, 50Vdc @ 1A maximum
9	HV On Lamp, Relay Common	Relay Common, 50Vdc @ 1A maximum
10	HV On Lamp, Relay N/C	Relay Normally Closed, 50Vdc @ 1A maximum

DIMENSIONS: in.[mm]





BACK VIEW



e-mail: sales@spellmanhv.com

PAGE 3 OF 3



Spellman's XRB200PN400/CT Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 200kV at 400W. Features like universal input, small package size, standard analog monitoring and RS-232 digital interface simplify integrating this unit into your X-Ray system. Standard models are available with fan shaped beam geometry. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Food Inspection, Fill Level Confirmation, Security Applications

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Glass tube, Tungsten target, Be filter

Focal Spot: 0.8mm x 0.5mm (IEC336)

Beam Filter: Glass 1.8mm, Oil 10mm, Al 1mm

Beam Geometry: Symmetrical fan 85° x 10° ±1°

Input Voltage:

100Vac-240Vac ±10%, 50/60Hz, 6A maximum

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 100kV to 200kV

X-Ray Tube Current:

0.5mA to 2mA over specified tube voltage range

X-Ray Tube Power:

400W maximum continuous (350W average without external forced air)

Voltage Regulation:

Line: ±0.1% for a ±10% input line change Load: ±0.1% for a 0.5mA to 2mA load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±1% of the programmed value

Voltage Risetime:

<1 second from 10% to 90% of rated output

- Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics
- Compact & Lightweight
- Universal Input, Power Factor Corrected
- Can be Mounted in Any Physical Orientation
- Analog Monitoring and Standard RS-232 Digital Interface

Voltage Overshoot:

5% in less than 100ms

Voltage Ripple:

≤0.2% pp of rated maximum voltage

Current Regulation:

Line: ±0.1% @ 100-200kV, 0.25mA to 2mA Load: ±0.5% @ 100-200kV, 0.25mA to 2mA

Current Accuracy:

Current measured through the X-Ray tube is within $\pm 1\%$ of the programmed value

Current Risetime:

<1 second from 10% to 90% of rated output

Arc Intervention:

4 arcs in 10 seconds = shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control

Digital Interface:

RS-232 interface.

Control Software:

A demo GUI for engineering evaluations will be provided for the RS-232 digital interface upon request.

Interlock Signals:

A hardware interlock function is provided

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

5% to 95% relative humidity, non-condensing

Cooling

Heat exchanger w/fan and oil pump, powered from 24Vdc, 2A power supply (customer provided). External forced air cooling if needed to keep oil temperature below 55°C



e-mail: sales@spellmanhv.com

200KV @ 400W MONOBLOCK®

PAGE 2 OF 3

Input Line Connector:

3 pin Phoenix Contact 1829167

Analog Interface Connector:

10 pin Phoenix Contact 1755503

Digital Interface Connector:

9 pin D connector, female

Grounding Point:

M5 ground stud provided on chassis

Dimensions:

See drawing

Weight:

148.0lbs (67.0kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 5uSv/hr at 5cm outside the external surface

AC INPUT POWER 3 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	Line	Line
2	GND	Ground
3	Neutral	Neutral

DC POWER FOR HEAT DISSIPATION UNIT 4 PIN AMP 206061-1 CONNECTOR

	PIN	SIGNAL	PARAMETERS
	1	+24	+24Vdc
	2	RTN	Return
	3	+24	+24Vdc
1	4	RTN	Return

ANALOG INTERFACE— 10 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	X-Ray	+24Vdc = enable X-Ray
2	X-Ray Return	X-Ray Return
3	N/C	N/C
4	kV Monitor Output	0 to 9Vdc = 0 to 100% Rated Voltage
5	SGND	Signal Ground
6	mA Monitor Output	0 to 9Vdc = 0 to 100% Rated Current
7	Fault	Open Collector, Open = No Fault
8	Relay N/O	HV On, 50V @ 1A maximum
9	Relay Common	HV On, 50V @ 1A maximum
10	Relay N/C	HV On, 50V @ 1A maximum


RS-232 DIGITAL INTERFACE— 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	Transmit Data	Conforms to E/A RS-232-C
3	Receive Data	Conforms to E/A RS-232-C
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

e-mail: sales@spellmanhv.com

PAGE 3 OF 3


DIMENSIONS: in.[mm]





BACK VIEW

TOP VIEW SIDE VIEW



Hauppauge, New York USA



Spellman's XRB160PN480/1 Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 160kV at 480W. Features like power factor correction, small package size, standard analog monitoring and RS-232 digital interface simplify integrating this Monoblock® into your X-Ray system. Standard models are available with fan shaped beam geometry. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Food Inspection, Fill Level Confirmation and Security Applications

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Glass tube, Tungsten target, Be filter

Focal Spot: 0.8mm x 0.8mm (IEC336)

Beam Filter: Curved 1mm Al

Beam Geometry: Asymmetrical fan 80° x 10° ±2°

Input Voltage:

220Vac, ±10%, 50/60Hz, 6.5A max

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 80kV to 160kV

X-Ray Tube Current:

0.25mA to 3mA over specified tube voltage range

X-Ray Tube Power:

480W maximum continuous

Voltage Regulation:

Line: ±0.1% for a ±10% input line change of nominal

input line voltage

Load: ±0.1% for a 0.25mA to 3mA load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% plus 1.785kV of the programmed value

- Integrated HV Supply. Filament Supply. X-Ray Tube, Beam Port and Control Electronics
- Compact & Lightweight
- Power Factor Corrected with Internal EMI Filter
- Can be Mounted in Any Physical Orientation
- Analog Monitoring and Standard RS-232 Digital Interface

Voltage Risetime:

Ramp time shall be ≤2 seconds from 10% to 90% of rated output

Voltage Overshoot:

±1% switching between 90kV to 160kV @ 0.25mA

Voltage Ripple:

≤0.1% of rated voltage from 10Hz to 1kHz

Current Regulation:

Line: ±0.5% @ 80-160kV, 0.25mA to 3mA

±0.5%, 0.25mA to 3mA Load:

Current Accuracy:

Current measured through the X-Ray tube is within 2% of the programmed value

Current Risetime:

≤2 seconds from 10% to 90% of rated output

Arc Intervention:

4 arcs in 10 seconds = shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control

Analog Interface:

0 to 10Vdc ground referenced signals

Digital Interface:

RS-232 interface

Control Software:

A demo GUI for engineering evaluations will be provided for the RS-232 digital interface upon request.

Interlock Signals:

A hardware interlock function is provided

Operating Temperature:

0°C to +40°C

Storage Temperature:

-20°C to +70°C

Humidity:

Corporate Headquarters

5% to 95% relative humidity, non-condensing



PAGE 2 OF 3

Cooling:

Heat exchanger w/fan and oil pump, powered from AC

Input Line Connector:

6 position terminal block

Analog Interface Connector:

7 pin Molex 26-60-5070

Digital Interface Connector:

9 pin D connector, female

Grounding Point:

8-32 ground stud provided on chassis

Dimensions:

20" x 22.5" x 10.75" (508mm x 572mm x 273mm)

Weight:

125lbs (56.7kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface

AC INPUT POWER J1 6 POSITION TERMINAL BLOCK

PIN	SIGNAL	PARAMETERS
1	Line	Line
2	Removed	N/C
3	Neutral	Neutral
4	Removed	N/C
5	Spare	N/C
6	Spare	N/C

ANALOG INTERFACE CONNECTOR—7 PIN MOLEX, 0.156 CENTER

	PIN	SIGNAL	PARAMETERS
1	1	X-Ray	+12Vdc @16mA = enable X-Ray
ı	2	X-Ray Return	X-Ray Return
1	3	N/C	N/C
1	4	kV Monitor Output	0 to 1.6Vdc = 0 to 160kV
1	5	SGND	Signal Ground
ı	6	mA Monitor Output	0 to 3Vdc = 0 to 3mA
1	7	Fault	Open Collector, Open = No Fault

RS-232 DIGITAL INTERFACE— 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	TX	Transmit Data
3	RX	Receive Data
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	X-Ray Enable	+12Vdc @ 16mA = Enable
9	N/C	No Connection

PAGE 3 OF 3

DIMENSIONS: in.[mm]

TOP VIEW SIDE VIEW _ 21.50 [546.1] _ .50 [12.7] — – 10.75 [273.05] – Įφ 19.00 [482.6] 20.00 [508] F.S. 9.50 [241.3] .75 [19.05] REF 20 4.00 [101.6] --- .75 [19.05] REF 3.13 [79.50] .50 [12.7] 8.06 [204.72] 10.75 [273.50] 22.50 [571.5] —

PAGE 1 OF 3



Spellman's XRB160PN480/2 Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 160kV at 480W. Features like universal input, small package size and a standard analog and RS-232 digital interface simplify integrating this Monoblock® into your X-Ray system. Standard models are available with fan shaped beam geometry. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Food Inspection, Fill Level Confirmation and Security Applications

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Glass tube, Tungsten target, Be filter

Focal Spot: 0.8mm x 0.8mm (IEC336)
Beam Filter: 1mm curved window

Beam Geometry: Asymmetrical fan 80° x 10° ±2°

Input Voltage:

100-240Vac ±10%, 50/60Hz, 6.5A max; 12Vdc @ 5A

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 80kV to 160kV

X-Ray Tube Current:

0.25mA to 3mA over specified tube voltage range

X-Ray Tube Power:

480W maximum

Voltage Regulation:

Line: $\pm 0.1\%$ for a $\pm 10\%$ input line change of nominal

input line voltage

Load: ±0.1% for a 0.3mA to 3mA load change

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±1% of the programmed value

Voltage Risetime:

Ramp time shall be <1 second from 10% to 90% of rated output

- Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics
- Compact & Lightweight
- Universal Input, Power Factor Corrected
- Can be Mounted in Any Physical Orientation
- Analog Control Interface and Standard RS-232 Digital Interface

Voltage Overshoot:

Within 5% of rated voltage in <10ms

Voltage Ripple:

0.1% pp of rated voltage @ ≤1kHz

Current Regulation:

Line: $\pm 0.1\%$ for a $\pm 10\%$ input line change of

nominal input line voltage

Load: ±0.5% @ 80-160kV, 0.3mA to 3mA

Current Accuracy:

Current measured through the X-Ray tube is within ±1% of the programmed value

Current Risetime:

<1 second from 10% to 90% of rated output

Arc Intervention:

4 arcs in 10 seconds with a 200ms quench = Shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control

Analog Interface:

0 to 10Vdc ground referenced signals

Digital Interface:

RS-232 interface.

Control Software:

A demo GUI for engineering evaluations will be provided for the RS-232 digital interface upon request.

Interlock Signals:

A hardware interlock functions in both analog and digital programming modes.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

95% relative humidity, non-condensing

Cooling:

Heat exchanger w/fan and oil pump, powered from DC input



PAGE 2 OF 3

Input Line Connector:

3 pin, Phoenix Contact 1829167

Analog Interface Connector:

10 pin, Phoenix Contact 1755503

Digital Interface Connector:

9 pin D connector, female

Heat Exchanger Power Connector:

4 pin AMP part no. 206061-1

Grounding Point:

8-32 ground stud provided on chassis

Dimensions:

See outline drawing

Weight:

125lbs (56.7kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface

AC INPUT POWER 3 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	Line	Line
2	GND	Ground
3	Neutral	Neutral

DC POWER FOR HEAT DISSIPATION UNIT 4 PIN AMP 206061-1 CONNECTOR

PIN	SIGNAL	PARAMETERS
1	+12	+12Vdc
2	RTN	Return
3	+12	+12Vdc
4	RTN	Return

ANALOG INTERFACE— JB15 10 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	X-Ray Signal	+24Vdc =Enable X-Ray, 0Vdc/open = Disable X-Ray, Zin=2.2k Ω
2	X-Ray Signal Return	Signal Return
3	N/C	N/C
4	kV Monitor	$0-10Vdc = 0$ to $178kV$, $Zout = 10k\Omega$
5	Signal Ground	Signal Ground
6	mA Monitor	$0-10Vdc = 0$ to $3.4mA$, $Zout = 10k\Omega$
7	Fault Signal	Open collector, High (Open) = No Fault, 35Vdc @10mA maximum
8	HV ON Lamp Relay n/o	Relay Normally Open, 50Vdc @ 1A maximum
9	HV ON Lamp Relay common	Relay Common, 50Vdc @ 1A maximum
10	HV ON Lamp Relay n/c	Relay Normally Closed ,50Vdc @ 1A maximum

LED INDICATORS


INDICATOR	SIGNAL NAME	CONDITION Illuminated When
LED 1	ОТ	Over temperature occurs
LED 2	ARC FLT	Arc fault occurs
LED 3	UV	Low kV occurs
LED 4	OV	High kV occurs
LED 5	UC	Low mA occurs
LED 6	OC	High mA occurs
LED 7	X-RAY ON	X-Rays are enabled
LED 8	PWR	Power is ON

RS-232 DIGITAL INTERFACE— 9 PIN FEMALE D CONNECTOR


PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	Transmit Data	Conforms to E/A RS-232-C
3	Receive Data	Conforms to E/A RS-232-C
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

PAGE 3 OF 3

DIMENSIONS: in.[mm]



FRONT VIEW



SIDE VIEW

TOP VIEW 15.85 ±0.01 [402.7 ±0.3] 3.44 [87.3] 3.00 [76.2] 15.19 [385.82] 7.43 [188.72] **7.56** [190.02] 0 6.00 [152.5] 23.69 ±0.05 [601.6 ±1.3] AIR INTAKE

AIR EXHAUST

7.63 [193.8] —— 3.00 [76.1] 4.63 [117.7] 9.36 [237.7] F.S. AIR INTAKE □ AIR EXHAUST 6.89 ±0.03 [175 ±0.8]



Spellman's XRB160PN480/CT Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 160kV at 480W. Features like small package size and RS-232 digital interface simplify integrating this Monoblock® into your X-Ray system. Standard models are available with fan shaped beam geometry. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Food Inspection, Fill Level Confirmation and Security Applications

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Glass tube, Tungsten target, Be filter
Focal Spot: 0.8mm x 0.8mm (IEC336)
Beam Filter: 1.7mm of glass, 1mm of Al, and

10mm of oil

Beam Geometry: Symmetrical fan 105° ±3° x 4° ±1°

Input Voltage:

Monoblock®: 100-240Vac ±10%, 50/60Hz,

6.5A max

Heat Dissipation Unit: 24Vdc, 3A

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 20kV to 160kV

X-Ray Tube Current:

0.3mA to 6mA over specified tube voltage range

X-Ray Tube Power:

320W continuous, 480W peak

Voltage Regulation:

Line: $\pm 0.1\%$ for a $\pm 10\%$ input line change of nominal

input line voltage

Load: ±0.1% for a 0.3mA to 6mA load change

• Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics

- Compact & Lightweight
- Can be Mounted in Any Physical Orientation
- Standard RS-232 Digital Interface

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±1% of the programmed value

Voltage Risetime:

Ramp time shall be <1 second from 1% to 90% of rated output

Voltage Overshoot:

Within 5% of rated voltage

Voltage Ripple:

0.1% pp of rated voltage @ ≤1kHz

Current Regulation:

Line: $\pm 0.5\%$ Load: $\pm 0.5\%$

Current Accuracy:

Current measured through the X-Ray tube is within ±1% of the programmed value

Current Risetime:

<1 second from 1% to 90% of rated output

Arc Intervention:

4 arcs in 10 seconds = Shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control

Digital Interface:

RS-232

Control Software:

A demo GUI for engineering evaluations will be provided for the RS-232 digital interface upon request.

Interlock Signals:

A hardware interlock functions in digital programming modes.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

5% to 90% relative humidity, non-condensing

Cooling:

Heat exchanger w/fan and oil pump, powered from customer provided 24Vdc @ 3A



PAGE 2 OF 3

Input Line Connector:

3 pin Phoenix Contact part no. 1829167

Digital Interface Connector:

9 pin D, female

Analog Signal Connector:

10 pin Phoenix Contact part no. 1755503

Cooler Power Connector:

4 pin AMP part no. 206061-1

Grounding Point:

8-32 ground stud provided on chassis

Dimensions:

24.00" x 16.00" x 6.50" (609.60mm x 406.40mm x 165.10mm)

Weight:

125lbs (49.5kg) ±10lbs (±4.5kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than 0.5mR/hr at 5cm outside the external surface

Special Features:

Stationary or rotating CT application up to 90rpm at a max. radius of 24.75" (629mm)

AC INPUT POWER 3 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	Line	Line
2	GND	Ground
3	Neutral	Neutral

ANALOG INTERFACE— 10 PIN PHOENIX CONTACT

	PIN	SIGNAL	PARAMETERS
Ī	1	X-Ray	+24Vdc = enable X-Ray
Ī	2	X-Ray Return	X-Ray Return
ſ	3	N/C	No Connection
I	4	kV Monitor Output	0 to 9Vdc = 0 to 100% Rated Voltage
I	5	SGND	Signal Ground
I	6	mA Monitor Output	0 to 9Vdc = 0 to 100% Rated Current
Ī	7	Fault	Open Collector, Open = No Fault
I	8	Relay N/C	HV On, 50V @ 1A maximum
	9	Relay Common	HV On, 50V @ 1A maximum
	10	Relay N/O	HV On, 50V @ 1A maximum


RS-232 DIGITAL INTERFACE— 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	Transmit Data	Conforms to E/A RS-232-C
3	Receive Data	Conforms to E/A RS-232-C
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection



PAGE 3 OF 3

DIMENSIONS: in.[mm]



PAGE 1 OF 3



Spellman's XRB200PN500 is an integrated X-Ray source operating up to 200kV and 500W, providing OEM users a compact plug-and-play Monoblock® for critical inspection and screening applications. The unit incorporates a 15° angle stationary anode X-Ray tube offering a symmetrical fan beam of 85° X 4°. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, with industry leading dose stability and image quality. This compact model comes with standard analog and RS-232 digital control. Spellman can provide customized versions of this platform for specific OEM system requirements.

TYPICAL APPLICATIONS

Aviation Security Screening: Checked Baggage/EDS Vehicle Inspection, Cargo Inspection, General NDT

SPECIFICATIONS

X-Ray Characteristics:

Stationary Anode, tungsten target Tube Type: Focal Spot: 0.8 x 0.5mm nominal (IEC60336) Beam Filter: Glass 2.1mm, maximum. Oil 18mm. Beam Geometry: Symmetrical fan of 85° X 4°, ±1%

Anode Angle:

Input Voltage:

Power factor corrected input to 0.98. 100Vac to 240Vac, ±10%, 50/60 Hertz. 6 Amps, maximum

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 100kV to 200kV

Voltage Accuracy:

The high voltage measured at the X-ray tube will be within ±1% of the selected value.

Voltage Ripple:

Ripple will be 1% of maximum rated voltage for frequencies ≤1kHz.

Voltage Regulation:

< ±0.1% for ±10% of nominal input line change < ±0.1% for 0.5mA to 2.5mA load change

Voltage Overshoot:

kV overshoot will return within 5% of full voltage in less than 100ms.

Risetime:

The voltage and current risetime is controlled by a ramping circuit. Ramp time is less than 1.0 second from 10% to 90% of output voltage and current.

200kV and 500W

- X-Ray Tube Current: 0.5mA to 2.5mA @ 200kV
- Focal Spot 0.8 x 0.5mm Nominal (IEC60336)
- Symmetrical Fan Beam of 85° X 4°, ±1%
- Power Factor Corrected Input to 0.98
- 100Vac to 240Vac, ±10%
- Logging and Firmware Controlled X-Ray Tube Seasoning

X-Ray Tube Current:

0.5mA to 2.5mA @ 200kV <±1% of the selected value. 500 watts maximum

Current Regulation:

<0.5% at 100 - 200 kV, 0.5mA to 2.5mA

Arc Intervention:

Unit will detect a single arc but HV will not shut down. If multiple arcs occur (4 in 10 seconds) then the unit will shut down.

Filament Configuration:

Isolated high frequency AC filament drive operated in current mode with closed loop thermionic filament emission control.

Digital Interface:

The RS-232 and Ethernet interfaces allow for programming of the voltage, current and X-Ray Enable. Provides monitoring for voltage, current and oil temperature. Tolerance is 3%.

Control Software:

A demo GUI is available for engineering evaluation.

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing.

Heat exchanger with fan and oil pump. Customer provided +24Vdc @ 3A is required. In certain situations, external cooling fans of 250CFM may be required to maintain tank/oil temperature below 55°C.

Input Line Connector:

3 pin Phoenix Contact, p/n 1829167. Mating connector provided with unit.

Analog Interface Connector:

10 pin Phoenix Contact, p/n 1755503. Mating connector provided with unit.

RS-232 Connector:

9 pin female D connector. Mating connector provided with unit.

Ethernet Connector:

8 pin RJ45 connector.

Heat Dissipation Unit Connector:

4 pin AMP connector, TE Connectivity (206061-1) Mating connector provided with unit.



200KV @ 500W MONOBLOCK®

PAGE 2 OF 3

Grounding Point:

M4 grounding stud provided on chassis.

Dimensions:

See outline drawing.

Weight:

181 pounds (80kg).

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Not to be greater than .5mR/hr at 5cm from any surface of the Monoblock® when measured at 200kV @ 2.5mA.

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. Designed to meet EEC EMC Directive with customer provided external line filter, Corcom p/n 6EU1F or equivalent.

AC INPUT POWER 3 PIN PHOENIX CONTACT P/N 1829167

PIN	SIGNAL	PARAMETERS
1	Line	100-240Vac,±10%, 50/60 Hertz @ 6 amps
2	GND	Ground
3	Neutral	100-240Vac,±10%, 50/60 Hertz @ 6 amps

DC POWER FOR HEAT DISSIPATION UNIT 4 PIN AMP 206061-1 CONNECTOR

PIN	SIGNAL	PARAMETERS
1	+24Vdc	+24Vdc @ 3A*
2	24Vdc Return	Return
3	+24Vdc	+24Vdc @ 3A*
4	24Vdc Return	Return

^{*}Both +24V supplies are required for pump and fans

RS-232 DIGITAL INTERFACE— 9 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	Transmit Data	Conforms to EAI RS-232-C
3	Receive Data	Conforms to EAI RS-232-C
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

ETHERNET INTERFACE— 8 PIN FEMALE RJ45 CONNECTOR

PIN	SIGNAL	PARAMETERS
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receive Data +
4	N/C	No Connection
5	N/C	No Connection
6	RX-	Receive Data -
7	N/C	No Connection
8	N/C	No Connection

ANALOG INTERFACE— 10 PIN PHOENIX CONTACT P/N 1755503

PIN	SIGNAL	PARAMETERS
1	X-Ray On	+24Vdc = Enable X-Ray, Low or open = Disable X-Ray
2	X-Ray On Return	X-Ray on Return
3	N/C	No Connection
4	kV Monitor	0 to 10Vdc = 0 to 200kV, Zout = $10k\Omega$
5	SGND	Signal Ground
6	mA Monitor	0 to 10Vdc = 0 to 2.5mA, Zout = $10k\Omega$
7	Fault	Open Collector, High (Open) = No Fault, 35Vdc @ 10mA, maximum
8	HV On Lamp N/O	Relay dry contact, normally open, 30Vdc @ <1A, nominal 50mA DC load
9	HV On Lamp Common	Relay dry contact, common, 30Vdc @ <1A, nominal 50mA DC load
10	HV On Lamp N/C	Relay dry contact, normally closed, 30Vdc @ <1A, nominal 50mA DC load

FRONT PANEL LED INDICATORS

INDICATOR	SIGNAL NAME	CONDITION Illuminated When	LED COLOR
LED 1	ОТ	OverTemperature occurs	Red
LED 2	ARC	Arc fault occurs	Red
LED 3	UV	Low kV occurs	Red
LED 4	OV	High kV occurs	Red
LED 5	UC	Low mA occurs	Red
LED 6	OC	High mA occurs	Red
LED 7	X-RAY ON	X-Rays are enabled	Green
LED 8	PWR ON	Power is ON	Green

SMART XRB

The XRB200PN500 features data logging and firmware controlled seasoning. Data Logging:

Think of this as an "airplane black box". The data logging captures data on fault events and non-fault events. Fault events will turn off the high voltage.

FAULT EVENTS

Temperature, Arc, High Current, High Voltage, Low Voltage, Watchdog, Power Fault, Interlock

The XRB200PN500 stores data 620ms before the event, the event itself and for 620ms after the event. Data is recorded every 20ms (62 samples total) showing: Anode kV, Cathode kV, Total kV, Total mA, Filament, Temperature

We also log non-fault events, these are changes in set points or state of the unit. **NON FAULT EVENTS**

HV On, HV Off, kV Set point, mA Set point, Low Current, Filament Limit Set point, Pre Heat Set point, Line Dip


Fault event data is actual graphical data. Non fault event data is just stored as event type, data and timestamp. We also have a preventative maintenance fault, which throws a non-shutdown fault if the X-Ray tube has been factory installed over 4 years ago or if over 15,000 hours of HV ON is logged.

Firmware Controlled Seasoning:

Every unit comes with an initial seasoning table, or customers can set their own. The XRB200PN500 knows when the unit has been on, when it has been off, hours on the X-Ray tube, etc. As a preventative maintenance feature upon turn on, we review the data and suggest that a particular seasoning protocol be run based upon the actual usage history of the unit. Proper seasoning compliance of the X-Ray tube will help get the longest lifetime.

PAGE 3 OF 3

DIMENSIONS: in.[mm]





Corporate Headquarters

Hauppauge, New York USA



Spellman's XRB150PN600 Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 150kV at 600W. Features like power factor correction, small package size and a standard analog and RS-232 digital interface simplify integrating this unit into your X-Ray system. Standard models are available with cone shaped beam geometry. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Bone Densitometry, Food Inspection, Security

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Glass tube, Tungsten target, Be filter

Focal Spot: 0.5mm x 0.5mm (IEC 336)

Beam Filter: 0.06" Ultem
Beam Geometry: Cone, 18° ±1°

Input Voltage:

200-240Vac ±10%, 50/60Hz, 6.5A maximum

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 70kV to 150kV

X-Ray Tube Current:

1.0mA to 4.0mA over specified tube voltage range

X-Ray Tube Power:

160W continuous, 600W peak

Duty Cycle: 30 seconds on, 300 seconds off

@ 600W peak

Voltage Regulation:

Line: $\pm 0.1\%$ for a $\pm 10\%$ input line change of

180 to 264Vac

Load: ±0.1% for a 1.0mA to 4.0mA load change.

600W maximum

Voltage Accuracy:

Voltage measured across the X-Ray tube is within ±2% of the programmed value

Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics

- Compact & Lightweight
- Power Factor Corrected
- Can be Mounted in Any Physical Orientation
- Analog Monitoring and Standard RS-232 Digital Interface

Voltage Risetime:

±1% in less than 300ms

Voltage Overshoot:

±10% during 300ms risetime

Voltage Ripple:

1% rms of rated voltage @ 10Hz to 1MHz

Current Regulation:

Line: ±0.1% from 180-264Vac

Load: ±0.5% @ 70kV-150kV, 1.0mA to 4.0mA

Current Accuracy:

Current measured through the X-Ray tube is within ±2% of the programmed value

Current Risetime:

±1% in less than 300ms

Arc Intervention:

4 arcs in 10 seconds with a 200ms guench = Shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop

filament emission control

Analog Interface:

0 to 5Vdc ground referenced signals

Digital Interface:

RS-232 interface.

Control Software:

A demo GUI for engineering evaluations will be provided for the RS-232 digital interface upon request.

Interlock/Signals:

A hardware interlock function is provided

Operating Temperature:

0°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

10% to 95% relative humidity, non-condensing

Cooling:

External fan required. 250cfm minimum to maintain

an oil temperature of 55° C

PAGE 2 OF 3

Input Line Connector:

3 pin Phoenix Contact P/N 1829167

Analog Interface Connector:

10 pin Phoenix Contact P/N 1755503

Digital Interface Connector:

9 pin D connector, female

Grounding Point:

8-32 ground stud provided on chassis

Dimensions:

13.46" x 13.38" x 6.24" (341.89mm x 339.85mm x 158.50mm)

Weight:

66lbs (30kg)

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Less than 100mR/hr at 1m distance, measured at 140kV, 3mA

AC INPUT POWER JB1 3 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	Line	Line
2	GND	Chassis Ground
3	Neutral	Neutral

RS-232 DIGITAL INTERFACE— JB16 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	Spare	N/C
2	Transmit	RS-232
3	Receive	RS-232
4	Spare	N/C
5	Signal Ground	Ground
6	Spare	N/C
7	Spare	N/C
8	Spare	N/C
9	Spare	N/C

ANALOG INTERFACE— JB15 10 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	X-Ray Signal	+12Vdc =Enable X-Ray, 0Vdc/open = Disable X-Ray, Zin=1k Ω
2	X-Ray Signal Return	Signal Return
3	N/C	N/C
4	kV Monitor	0 to 5Vdc = 0 to 175kV, Zout= $10k\Omega$
5	Signal Ground	Signal Ground
6	mA Monitor	0 to 5Vdc = 0 to 4.5mA, Zout= $10k\Omega$
7	Fault Signal	Open collector, High (Open) = No Fault, 35Vdc @10mA maximum
8	HV ON Lamp Relay n/o	Relay Normally Open, 50Vdc @ 1A maximum
9	HV ON Lamp Relay common	Relay Common, 50Vdc @ 1A maximum
10	HV ON Lamp Relay n/c	Relay Normally Closed, 50Vdc @ 1A maximum

LED INDICATORS


INDICATOR	SIGNAL NAME	CONDITION Illuminated When
LED 1	OT	Over temperature occurs
LED 2	ARC FLT	Arc fault occurs
LED 3	UV	Low kV occurs
LED 4	OV	High kV occurs
LED 5	UC	Low mA occurs
LED 6	OC	High mA occurs
LED 7	X-RAY ON	X-Rays are enabled
LED 8	PWR	Power is ON




150KV @ 600W MONOBLOCK®

PAGE 3 OF 3


DIMENSIONS: in.[mm]



FRONT VIEW CONTROL ASSEMBLY



SIDE VIEW TANK




SIDE VIEW CONTROL ASSEMBLY

AIR EXHAUST



TOP VIEW TANK



SIDE VIEW CONTROL ASSEMBLY

AIR INTAKE



FAX: +1-631-435-1620

+1-631-630-3000

160KV @ 688W MONOBLOCK

PAGE 1 OF 3



Spellman's XRB160PN688/CT Monoblock® X-Ray source is designed for OEM applications powering its internal X-Ray tube up to 160kV at 688W. Features like small package size and RS-232 digital interface simplify integrating this unit into your X-Ray system. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability performance.

TYPICAL APPLICATIONS

X-Ray Scanning: Food Inspection, Fill Level Confirmation and Security Applications

SPECIFICATIONS

X-Ray Characteristics:

Tube Type: Glass tube, Tungsten target, Be filter Focal Spot: 2.5mm x 2.5mm (IEC 60336) Beam Filter: 1.5mm glass, 9-26mm oil, 0.4mm Al Beam Geometry: Asymmetrical fan 93° x 15° ±2°

Input Voltage:

230Vac, ±15%, 50/60Hz, 5A max

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 50kV to 160kV

X-Ray Tube Current:

0.25mA to 4.3mA over specified tube voltage range

X-Ray Tube Power:

688W maximum continuous

Voltage Regulation:

Line: ±0.1% ±10% Load: ±0.1% 0.25 to 4.3mA

Voltage Accuracy:

Voltage measured across the X-Ray tube is within 1% of the programmed value

Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics

- Compact & Lightweight
- Power Factor Corrected
- Can be Mounted in Any Physical Orientation
- Standard RS-232 Digital Interface

Voltage Risetime:

Ramp time shall be 500ms nominal, 1 second maximum from 10% to 90% of rated output

Voltage Overshoot:

Within 5% of rated voltage

Voltage Ripple:

1% p-p of rated voltage

Current Regulation:

 $\pm 0.5\% \pm 10\%$ Line:

Load: ±0.5% 0.25 to 4.3mA

Current Accuracy:

Current measured through the X-Ray tube is within 5% of the programmed value

Current Risetime:

500ms nominal, 1 second maximum

Arc Intervention:

4 arcs in 10 seconds = shutdown

Filament Configuration:

Internal high frequency AC filament drive with closed loop filament emission control

Digital Interface:

RS-232 interface.

Control Software:

A demo GUI for engineering evaluations will be provided for the RS-232 digital interface upon request.

Interlock Signals:

A hardware interlock function is provided

Operating Temperature:

5°C to +40°C

Storage Temperature:

-25°C to +65°C

Humidity:

10% to 90% relative humidity, non-condensing

Cooling:

Heat exchanger w/fan and oil pump, powered from AC



160KV @ 688W MONOBLOCK®

PAGE 2 OF 3

Input Line Connector:

5 pin Molex 26-60-4050

Heat Exchanger Power Connector:

4 pin AMP part no. 206061-1

Digital Interface Connector:

9 pin D connector, female

Grounding Point:

M5 ground stud provided on chassis

Dimensions:

See drawing

Weight:

 $140lbs \pm 10lbs (64kg \pm 4.5kg)$

Orientation:

Can be mounted in any orientation.

X-Ray Leakage:

Less than 300uR/hr at a distance of 10cm from all surfaces

Special Features:

Stationary or rotating CT application up to 100rpm at a maximum radius 20.25" (514mm)

AC INPUT POWER J1 5 PIN MOLEX 26-60-4050 CONNECTOR

-	PIN	SIGNAL	PARAMETERS
	1	Line	230Vac Input
-	2	Line	230Vac Input
	3	N/C	No Connection
-	4	Neutral	230Vac Neutral
ļ	5	Neutral	230Vac Neutral

AC POWER FOR HEAT DISSIPATION UNIT 4 PIN AMP 206061-1 CONNECTOR

	PIN	SIGNAL	PARAMETERS
	1	Line	230Vac Input
- 1	2	N/C	No Connection
Ì	3	Neutral	230Vac Neutral
	4	GND	Chassis Ground

RS-232 DIGITAL INTERFACE— J5 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	TX	Transmit Data
3	RX	Receive Data
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection





160KV @ 688W MONOBLOCK®


PAGE 3 OF 3

DIMENSIONS: in.[mm]

TOP VIEW







Corporate Headquarters



Copyright © 2010 Spellman High Voltage Electronics Corp.

Hauppauge, New York USA



Spellman's new Panoramic Dental Monoblock® consists of an integrated X-Ray tube, dual-output high voltage power supply, and filament supply with control circuitry. The PDM90PN900 is designed for extra oral dental X-Ray applications including CT and Panoramic X-Ray. Features like small package size, standard analog and RS-232 digital interface simplify integrating this Monoblock® into your X-Ray system. Proprietary emission control circuitry provides excellent regulation of X-Ray tube current, along with outstanding stability and performance.

TYPICAL APPLICATIONS

Dental X-Ray: Panoramic and CT Imaging

SPECIFICATIONS

X-Ray Tube Characteristics:

Target Angle: 5 degrees
Focal Spot: 0.5mm nominal
Beam Filtration: 3.0mm of Al equivalent
Beam Geometry: see page 3

X-Ray Tube Voltage:

Nominal X-Ray tube voltage is adjustable between 50kV to 90kV

Voltage Regulation:

Line: ±0.5% for a ±1V change of nominal input line voltage Load:±0.1% for a load change of 25μA to maximum rated current

X-Ray Tube Current:

1mA to 10mA over specified tube voltage range

Current Regulation:

Line: ±0.5% for a ±1V change of nominal input line voltage Load:±0.5% for a voltage change of 35kV to 80kV

- Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics
- Compact & Lightweight
- Analog or Digital Control Interface

X-Ray Tube Power:

900W peak power

Duty Cycle:

CT (Pulsed): ≤45 seconds scan time cycle at up to 40 pulses per second available

Panoramic

(Continuous): Maximum scan time = 30s, with 60s

off-time. Five consecutive scans

Input Voltage:

100-240Vac ±10% 50/60 Hz, 10 amps RMS maximum

Interface:

The RS-232 serial communications interface will be used to program and monitor output voltage and current, control various functions and report status and faults.

Digital Interface Connector:

RS-232: 9 pin D connector, male

Operating Temperature:

0°C to +40°C

Storage Temperature:

-20°C to +70°C

Humidity:

5% to 95% relative humidity, non-condensing

Cooling:

Tank: Convection

Controller: Forced air via provided fan

Dimensions:

X-Ray Tank: 9.7"W x 7.7"H x 4.7"D

(247mm x 195mm x 119mm)

Inverter/Controller: 7.10"W x 9.80"H x 3.60"D

(180mm x 250mm x 92mm)

Weight:

X-Ray Tank: 17lbs (7.7kg) Inverter/Controller: 6.5lbs (3kg)

X-Ray Leakage:

Less than 100mR/hour (or <1mGy/hr) @ 1meter from the Monoblock® surface.

Regulatory Approvals:

Compliant to EMC 60601-1-2 (external EMC filter and shielding required). UL/CUL recognized file E242584.



PAGE 2 OF 3

AC INPUT POWER 3 PIN PHOENIX CONTACT

PIN	SIGNAL	PARAMETERS
1	Line	Line
2	GND	Ground
3	Neutral	Neutral

ANALOG INTERFACE— **J2 10 PIN PHOENIX CONTACT**

PIN	SIGNAL	PARAMETERS
1	X-Ray Ready/Sync	+5 V Logic
2	X-Ray Enable	+5 V Logic
3	+ X-ray Signal (Exgate)	+5VDC = Enable X-Ray, Low (or Open) = Disable X-Ray
4	Signal Ground	Signal Ground
5	VMTR Signal (KV monitor)	Voltage: 0 to +5.00 V max, Scale Factor: 0 - 5.00 Vdc = 0 to 100 kV
6	Signal Ground	Signal Ground
7	IMTR Signal (mA monitor)	Voltage: 0 to +5.00 V max, Scale Factor: 0 - 5.00 Vdc = 0 - 12.1mA
8	Fault Signal	Output signal: Open Collector, High (Open) = No Fault
9	HV ON Lamp, Relay N/O	Relay Normally Open, Dry contacts rated 1A or less will handle a nominal 50mA DC load.
10	HV ON Lamp, Common	Common

RS-232 DIGITAL INTERFACE— J5 9 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	N/C	No Connection
2	TX	Transmit Data
3	RX In	Receive Data
4	N/C	No Connection
5	SGND	Signal Ground
6	N/C	No Connection
7	N/C	No Connection
8	N/C	No Connection
9	N/C	No Connection

LED INDICATORS

Corporate Headquarters

Hauppauge, New York USA


INDICATOR	SIGNAL NAME	CONDITION Illuminated When
LED 1	OV	High kV occurs
LED 2	UV	Low kV occurs
LED 3	UC	Low mA occurs
LED 4	OC	High mA occurs
LED 5	ARC FLT	Arc fault occurs
LED 6	OT	Over temperature occurs
LED 7	PW (Pulse mode)	Pulse mode selected
LED 8	CW (CW mode)	CW mode selected
LED 9	CW (CW mode)	X-Ray is ON




PDM Generator Tank

DIMENSIONS: in.[mm]

TOP VIEW 9.59 [243.6] 9.32 [236.6] F.S. 4.13 [105] 4.49 [114.1] 0.88 [22.4] 0.09 [2.4]






+1-631-630-3000


PDM Inverter/Controller

DIMENSIONS: in.[mm]


TOP VIEW



FRONT VIEW



SIDE VIEW





Corporate Headquarters



Spellman's MMB125PN3.5 Medical Monoblock® with <1ms rise time is ideal for extremeties, specialized applications and vascular imaging. Benefit from Spellman's 70 plus years of high voltage innovation with this MMB125PN3.5 Monoblock® X-Ray source specifically designed for the C-Arm OEM. Our advanced technology and design expertise in conjunction with our depth of manufacturing capabilities position Spellman as the wise choice for your Monoblock® requirements.

Spellman's Ultra-Fast MMB Series utilizes our unique technologies that increases the quality of the X-Ray beam and significantly reduces patient dose. Pulsed Fluoroscopy enhances imaging of dense and complex anatomy to further support dose management. With a rise time of <1ms, Spellman's MMB Series is among the fastest in the industry.

TYPICAL APPLICATIONS

C-Arm OFM

SPECIFICATIONS

X-Ray Characteristics:

Focal Spot: 0.5mm for small focus

1.6mm for large focus

Target Angle: 16° Target Material: Tungsten Beam Filter: 0.8mm Al

Beam Geometry: Refer to line drawing

X-Ray Leakage: Less than <1mGy/hour @ 1meter

from tank surface.

Maximum

Filament Current: 4.3A

Filament Inverter

Switching Frequency: 20kHz Anode Heat Content: 35.5kJ

Maximum Anode

Heat Dissipation: 600W

Distance Between Focal Spot to X-Ray

Output Window: 45mm

Focal Spot Position: Refer to outline drawing, additionally

it is marked on tank cover.

- Integrated HV Supply, Filament Supply, X-Ray Tube, Beam Port and Control Electronics
- Compact & Lightweight
- <1ms Rise Time is Ideal for Extremities
- Specifically designed for the C-Arm OEM

Input Power:

Input Voltage: 190-264Vac, single phase, 50/60 Hz

Continuous Current: ≤9A @ 600W, 220V Peak Current: ≤34A @ 3500W, 220V

X-Ray Tube Voltage:

Operational Range: 40 to 125kV

kV Rise Time: <1ms (from 10% to 90%) ≤0.05 per IEC60601-2-54 Reproducibility:

kV Ripple: ≤1%

kV Accuracy

Fluoroscopy: ±5% kV Overshoot: ≤5%

X-Ray Tube Current:

Fluoro: 0.2mA to 6 mA (small focal spot) Pulsed Fluoro: 0.5mA to 10 mA (small focal spot) Radiography: 10mA to 40mA (large focal spot)

mA Accuracy:

Maximum Operating Conditions:

Continuous

Low Level Fluoro: 6 mA for 5 minutes

Continuous

High Level Fluoro: 10 mA for 2 minutes

Pulsed Fluoro: 0.5fps, 1fps, 2fps, 4fps, 8fps, 15fps,

25fps, 30fps for 2 minutes

the lower value of 40ms Pulse on time: or 50% duty cycle

Single shot large focal spot,

Radiographic:

0.1 seconds @ 3500 watts

Maximum Anode

600W Heat Dissipation:

Average Power: 600W for 5 minutes Tank Heat Content: No less than 675kHU

Max. Cooling Rate:

X-Ray Tube Current Protection:

Over Current (High mA): Trip point is set at 15% over maximum rated current, or at 15% over programmed output current value for longer than 50ms.

Under Current (High mA): Trip point is set at 15% under programmed output current value for longer than 50ms.

Over Current (Low mA): Trip point is set at 20% over maximum rated current, or at 20% over programmed output current value for longer than 50ms.

Under Current (Low mA): Trip point is set at 20% under programmed output current value for longer than 50ms.



203

PAGE 2 OF 3

X-Ray Tube Voltage Protection:

Over Voltage (High kV): Trip point is when the kV output exceeds 137.5kV for more than 10ms or it set is at 10% over programmed output voltage value for longer than 30ms.

Under Voltage (Low kV): Trip point is set at 10% under the programmed output voltage value for longer than 30ms.

X-Ray Tube Arc Protection:

Arc Intervention: Unit will detect an Arc but HV will not be shut down, but if multiple arcs occur (4 arcs in 10 seconds) the unit will shut down.

Over Temperature Protection:

Over Temperature: Over temperature of tank cover trip point shall be within 60°C ±5°C. Over temperature of tank oil trip point shall be set 65°C.

Operating Temperature: 0 to +40 °C.

Storage Temperature: -20 to +70 °C

Altitude: 0 to 8000 feet (0 to 2438 meters)

Humidity: 5 to 95%, non-condensing

Dimensions:

X-Ray Tank: 12.2" x 6.2" x 5.7" (310mm x 158mm x 145mm)

Refer to outline drawing.

Controller: 14.9" x 10.6" x 3.2" (380mm x 270mm x 83mm)

Refer to outline drawing.

Weight:

X-Ray Tank: 27.5 pounds (13kg) Controller: 9.9 pounds (4.5kg)

Regulatory Approvals:

Designed to be compliant to:

IEC 60601-1:2005+A

Medical electrical equipment Part 1: General requirements for basic safety and essential performance.

IEC 60601-1-2

2007 Medical electrical equipment Part 1-2: General requirements for basic safety and essential performance- Collateral standard: Electromagnetic compatibility—Requirements and tests.

IEC 60601-1-3

2008 Medical electrical equipment Part 1-3: General requirements for basic safety and essential performance-Collateral standard: Radiation protection in diagnostic X-Ray equipment.

IEC 60601-2-54

2009 Medical electrical equipment Part 2: Particular requirements for the basic safety and essential performance of X-Ray equipment for radiography and radioscopy.

EMC

Designed to meet IEC requirements for medical components. (Note: External EMI filter may be required)

RoHS

Controller and Tank Assembly are RoHS compliant.

AC LINE POWER CONNECTOR— TE: 1-350943-0

PIN	SIGNAL	PARAMETERS
1	Ground	Earth Ground
2	AC Input 1	190 - 264Vac, single phase, 50/60Hz, 34A max.
3	AC Input 2	190 - 264Vac, single phase, 50/60Hz, 34A max.

Note: Ground stud is provided on chassis

DIGITAL INTERFACE—9 PIN FEMALE D CONNECTOR TE: 5747844-5


PI	IN	SIGNAL	PARAMETERS
	1	NC	No Connection
	2	RS-232 TX Out	RS-232 Transmit
	3	RS-232 RX In	RS-232 Receive
	4	NC	No Connection
	5	RS-232 Ground	Ground from RS-232 transceiver IC
Г	6	NC	No Connection
Г	7	NC	No Connection
	8	NC	No Connection
	9	NC	No Connection


ANALOG INTERFACE—15 PIN FEMALE D CONNECTOR TE: 5747845-5

PIN	SIGNAL	PARAMETERS
1	GND	Signal Ground
2	+5Vdc Out	+5Vdc, 100mA max.
3	Prep	User signal (Contact Closure) to alert the generator that exposure sequence will begin. Once this signal is active, exposure parameters are locked in and cannot be changed. Contact connection to pin 14. Closed = PREP, the filament is placed in preheat mode
4	Ready	The generator is ready for X-Ray exposure. Open Collector. Low/Active = Ready
5	Exposure	User signal (Contact Closure) to generator to generate X-Rays. Filament is boosted, and high voltage is generated after the boost time. Contact connection to pin 14. Closed = Exposure
6	X-Ray ON 75% Status	Transistor output to indicate X-Ray ON status synchronized with 75% of kV set point
7	X-Ray ON Status	Transistor output to indicate X-Ray ON status synchronized with kV start up
8	X-Ray Shutdown	User signal to generator to rapidly turn HV OFF and ON during serial exposure sequence. Low/Active=HV OFF
9	HVG Fault Status	Generator signal indicating generator fault. Open collector transistor output. Low/Active = Fault
10	kV Monitor	Signal from generator. 0-10V = 0-140kV
11	mA Monitor	Signal from generator. Large focus: 0-10V = 0-50mA Small focus: 0-5V=0-10mA
12	Filament Current Monitor	Signal from generator. 0-10V = 0-6A
13	Monitor GND	Ground for reference of monitor signals
14	+24Vdc Out	For connection to PREP and EXPOSURE control relay coils
15	Shield Ground	For connection of interface cable shield to generator chassis ground

PAGE 3 OF 3


DIMENSIONS: in.[mm]





CONTROL UNIT FRONT VIEW









PAGE 1 OF 2



Spellman's MI1.5PN24 is a well-regulated, high performance DC-DC converter featuring a floating 1.5kV @ 6.5mA output, it has an operational range 300V-1500V. The output is isolated; this allows connection to loads of +Ve, -Ve or switchable polarity and for pulse currents to be contained within prescribed paths, reducing noise and interference signatures. The MI1.5PN24 low output ripple specification makes it ideal for use with pulsers in Mass Spectrometry applications. This module is packaged in a shielded metal enclosure and the high voltage output is provided via two captive cables. The MI1.5PN24 has a large, high quality capacitance and rugged output network, this allows high energy pulsed loads to powered continuously without significant voltage drop or damage to the unit circuitry. The unit has remote 0-10Vdc = 0-100% rated voltage programming and voltage monitor. A TTL compliant Enable signal provides simple control of the high voltage output.

TYPICAL APPLICATIONS

Mass spec pulsers Pulsed load requirements

SPECIFICATIONS

Input Voltage:

+24Vdc, ±10%. Protected against reverse connection

Input Current:

725mA maximum at 1500V @ 6.5mA

Output Voltage:

300V to 1.5kV, continuously variable over entire output range

Polarity:

Positive or negative, isolated to 1.5kV

Load Current:

6.5mA, maximum

Power

9.75 watts, maximum

Regulation:

Line: <0.5% for line change of $\pm 10\%$ Load: <0.1% for zero to full load

Stability:

Better than 300ppm/hour after 1 hour warm up. 100ppm/hour after 2 hour warm up at constant operating conditions. Typically, 50ppm/hour after 1 hour and 15ppm/hour after 2 hours.

Temperature Coefficient:

<100ppm/°C, typically 25ppm/°C

Floating, Programmable 1.5kV Output

- Well Regulated, Low Ripple
- Low Z Output Network for Pulsed Load Applications
- Compact Design

Ripple

<75mV peak to peak at full load when either end is grounded.

Output Current Limit:

The module will have an output current limit of 9mA. The module is capable of withstanding an indefinite short circuit or overload on its output and will recover automatically once the short circuit is removed.

Supply Voltage Dynamic Rejection:

< than 20mV for an input step of 1 volt (within the range of +24Vdc, +10%/-2%)

Settling Time:

500 milliseconds maximum under all conditions.

Output Capacitance:

>400nF - Connected directly between POSITIVE to NEGATIVE output nodes

Environmental:

Temperature Range:

Operating: +15°C to +50°C Storage: -40°C to 70°C

Humidity: 5% to 95% RH @ 40°C non-condensing

Cooling:

Convection cooled

Interface Connector:

20 pin IDC male connector

High Voltage Output Connectors:

Two Varex CA166 (Connectronics SCID compatible) right angle connectors, 10 inches (254mm) long. The +Ve cable will have a RED band and "POS" printed on the cable. The -Ve cable will have a BLUE band and "NEG" printed on the cable. High voltage outputs are floating.

Star Ground Network:

+24Vdc Return is central; case, analog input ground and digital ground are returned through a 100 Ω resistor in parallel with a 0.001uF capacitor to the +24Vdc Return.

Dimensions:

4.53"L x 3.74"W x 1.54"D (115mm X 95mm X 39.2mm)

Weight:

0.66lbs. (0.3kg)

Regulatory Approvals:

The unit is CE marked. The unit has been designed to meet the requirements of EN61010, UL1950 and CSA 22.2 No. 950.

EMC:

As the unit is a component it will not be tested as a stand alone unit to meet the EMC directive. The user will need to follow sensible EMC precautions in using the unit.



INTERFACE CONNECTOR — 20 PIN IDC MALE CONNECTOR


PIN	SIGNAL	SIGNAL PARAMETERS
1	Voltage Control Return	Analog Ground
2	Voltage Control*	0Vdc to +10Vdc = 0 to 1.5kV (differential Input) Zin = 100 kΩ. Protected against inputs of <11 volts and reverse voltages.
3	Voltage Control Return	Analog Ground
4	N/C	No Connection
5	Voltage Control Return	Analog Ground
6	N/C	No Connection
7	Voltage Control Return	Analog Ground
8	N/C	No Connection
9	Voltage Control Return	Analog Ground
10	Voltage Monitor	+2Vdc to +10Vdc = 300 volts to 1.5kV, ±1%, Zout = 1 k Ω
11	N/C	No Connection
12	Enable	TTL: Low = HV ON. Referenced to +24Vdc Return.
13	N/C	No Connection
14	N/C	No Connection
15	N/C	No Connection
16	N/C	No Connection
17	+24Vdc Return	Power Return (Power Ground)
18	+24Vdc Power	+24Vdc @ 725mA
19	+24Vdc Return	Power Return (Power Ground)
20	+24Vdc Power	+24Vdc @ 725mA

^{*}At voltage programming voltages less than 2 volts, parameters in this specification may not be met.


How to Order:

Standard: PART NO.: Mi1.5PN24

DIMENSIONS: in.[mm]



FRONT VIEW





Corporate Headquarters

Hauppauge, New York USA





Spellman's ML430 power supply module has been designed specifically to drive high voltage amplifiers. This compact, low cost, SMT based high performance module is printed circuit board mountable. Its dual output is ideal for amplifier driver requirements together with electrostatic lenses, deflectors and biasing supplies.

This voltage regulated, current limited, fixed, dual output unit provides up to 25mA of load current. The ML430 is fully protected against arc and short circuit conditions. The grounded metal case provides both shielding and heat sinking functions. An Enable feature is provided, allowing simple remote operation of the supply.

TYPICAL APPLICATIONS

High Voltage Amplifiers Electrostatic Lenses

SPECIFICATIONS

Input Voltage:

+24 Vdc, ±1.2Vdc

Input Current:

≤1.2 amp

Output Voltage:

Output 1-Positive:

+430 volts fixed. Accuracy ±7%

Output 2-Negative:

-430 volts fixed. Accuracy ±7%

Accuracy specified over full temperature,

input voltage and load ranges

Output Current:

12mA maximum - Output 1-Positive 25mA maximum - Output 2-Negative

- High Voltage Lens Power Supply
- Dual Positive and Negative Outputs
- Low Cost, Air Insulated Design
- SMT Design—Small Size and Low Weight
- UL Approved to UL61010-1
- Arc and Short Circuit Protected
- Remote Enable Control Provided

Line Regulation: (typical)

±0.1% – Positive output ±1.0% – Negative output

Load/Cross Regulation: (typical)

±0.1% - Positive output ±3.5% - Negative output

Output Current Limit:

An auto-recovering short circuit fold back limit is employed. Fully arc protected, capable of 10 arcs in 5 seconds.

Ripple:

≤0.5% p-p of full rated output voltage

Stability:

≤0.25% per hour, constant operating conditions after 1 hour warm up

Temperature Coefficient:

≤200ppm per degree C

Environmental:

Temperature Range: Operating: 0°C to 50°C Storage: -35°C to 85°C

Humidity

10% to 90% RH, non-condensing

Cooling:

Unit must be mounted in free air, in any position with the exception of inverted (pins up). Forced air cooling is recommended

Dimensions:

0.984" H X 2.362" W X 2.362" D (25mm x 60mm x 60mm)

Weight:

3.31 oz. (94g)

Regulatory Approvals:


Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E227588 & E354595. RoHS compliant.






DIMENSIONS: in.[mm]


TOP VIEW



FRONT VIEW



SIDE VIEW



How to Order:
PART NO.:ML430P/N16/24



Corporate Headquarters


Hauppauge, New York USA



www.spellmanhv.com







This guad output supply is ideal for guadrupole drivers

and electrostatic lenses.

This voltage regulated, current limited, fixed quad output unit provides up to 15mA of load current from each output. The ML1350 is fully protected against arc and short circuit conditions. The grounded metal case provides both shielding and heat sinking functions. An Enable feature is provided, allowing simple remote operation of the supply.

TYPICAL APPLICATIONS

Quadrupole HVPS Electrostatic Lenses

SPECIFICATIONS

Input Voltage:

+24 Vdc, ±1.2Vdc

Input Current:

≤3.0 amps

Output Voltage:

Output 1-Positive:

+245 volts, fixed, accuracy <±10%

Output 2-Negative:

-245 volts, fixed, accuracy <±10%

Output 3-Positive:

+1350 volts, fixed, accuracy <±7%

Output 4-Negative:

-1350 volts, fixed, accuracy <±7%

Output Current:

15mA maximum for each output

Line Regulation: (typical)

±1 volt all outputs

Load Regulation: (typical)

±3% all outputs

Quad Output High Voltage Power Supply

- Low Cost, Air Insulated Design
- SMT Design—Small Size and Low Weight
- Arc and Short Circuit Protected
- Remote Enable Control Provided
- UL Approved to UL61010-1

Output Current Limit:

An auto-recovering short circuit fold back limit is employed. Fully arc protected, capable of 10 arcs in 5 seconds.

Ripple:

≤0.1% p-p of full rated output voltage

Stability:

≤0.25% per hour, constant operating conditions after 1 hour warm up.

Under Voltage Shutdown:

The power supply will shut down when an input under voltage condition is detected. When the input voltage is restored above 11.8 volts, operating the enable pin will reset this fault.

Temperature Coefficient:

≤200ppm per degree C

Environmental:

Temperature Range:
Operating: 0°C to 50°C
Storage: -35°C to 85°C
Humidity:

10% to 90% RH, non-condensing

Cooling:

Unit must be mounted in free air, in any position with the exception of inverted (pins up). Forced air cooling is recommended.

Dimensions:

0.984" H X 4.331" W X 3.150" D (25mm x 110mm x 80mm) Width does not include mounting tab

Weight:

7.27 oz. (206g)

Regulatory Approvals:


Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E227588 & E354595. RoHS compliant.




PAGE 2 OF 2

DIMENSIONS: in.[mm]


TOP VIEW




FRONT VIEW



SIDE VIEW







+1-631-630-3000



Hauppauge, New York USA

Corporate Headquarters







Spellman's MX2.5 is a well-regulated high performance DC-DC converter featuring a "hot switchable" polarity reversal capability. The MX's low ripple specification makes it ideal for Mass Spectrometry applications; especially security detection systems, Dynodes, sample ionization as well as capillary electrophoresis and electrostatic printing applications.

The MX2.5 is rated at 2.5kV @ 60uA and is packaged in a shielded metal enclosure. This unit features a logic signal input to control output polarity reversal. A HV inhibit feature, along with voltage and current monitors are provided. Easily customized to meet OEM requirements, the MX2.5 can be provided with improved ripple performance and higher voltage and current capabilities.

TYPICAL APPLICATIONS

Mass Spectrometry Capillary Electrophoresis **Electrostatic Printing**

SPECIFICATIONS

Input Voltage:

+24Vdc, ±0.5 volt

Input Current:

<200mA continuous

Output Voltage:

 ± 100 Vdc to ± 2.5 kV

Output Current:

0 to 60uA max.

Remotely reversible via logic signal, 300mS to settle to ±1%, 1 Hz maximum switch rate

+1-631-630-3000

Voltage Regulation:

Load: 0.05% of maximum output voltage for a no load to full load change Line: 0.05% of maximum output voltage for a

1 volt input line change

- Hot Switchable Polarity Reversible Via a Logic Signal
- Well Regulated, Low Ripple
- Polarity Reversal Within 300mS
- **Voltage and Current Monitor Outputs**
- Remote HV Inhibit
- Small PCB Mount Module
- Arc and Short Circuit Protected

Voltage Programming:

0 to 10 volt corresponds to 0 to 100% of rated output voltage

Voltage/Current Monitor:

0 to 10 volt corresponds to 0 to 100% of rated output voltage/current

Programming and Monitor Accuracy:

±1% Voltage Programming/Monitor ±2% Current Monitor

Ripple:

≤0.02% Volts p-p

Stability:

0.02% per hour after 1 hour warmup

Temperature Coefficient:

≤50ppm per degree C

Environmental:

Temperature Range: Operating: 0°C to 40°C Storage: -40°C to 85°C Humidity:

10% to 90%, non-condensing

Cooling:

Convection cooled

Dimensions:

1.18" H X 2.36" W X 4.72" D (30mm X 60mm X 120mm)

Approximately 8.82 oz. (250g)

Interface/Power Connector:

PCB mount pins

HV Output Connector:

PCB mount pins

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.



FAX: +1-631-435-1620

PAGE 2 OF 2


MX2.5 INPUT/OUTPUT CONNECTIONS

PIN	SIGNAL	SIGNAL PARAMETERS
1	+24V	Power Input
2	Ov	Signal and Power Ground
3	Vprog	0-10V Programming Voltage
4	Polarity Change	Polarity Change Input
5	Shutdown	Output Inhibit, Disables HV Output Down to <60V Within 300ms
6	Vmon	0-10V Output Voltage Monitor
7	Output	HT Output
8	Imon	0-10V Output Current Monitor


How to Order:	
Standard: PART NO.:MX2.5PN24	

DIMENSIONS: mm

SIDE VIEW



BOTTOM VIEW ON PINS





Spellman's MX8 *Plus* is a well-regulated high performance fast reversible supply featuring a 25ms "hot switchable" polarity reversing capability.

The MX8 *Plus*'s low ripple specification is typical of the topologies that make Spellman High Voltage your ideal choice for mass spectrometry applications; especially security detection systems, dynodes, sample ionisation as well as capillary electrophoresis and electrostatic printing applications. The MX8 has been designed especially for EI and APCI applications.

The MX8 *Plus* can be easily tailored to an OEM's requirement, such as improved ripple performance, or different voltage and/or current capabilities.

TYPICAL APPLICATIONS

Mass Spectrometry
Capillary Electrophoresis
Electrostatic Printing

SPECIFICATIONS

Input Voltage:

+24Vdc, ±10%

Input Current:

<0.5A nominal continuous <1.2A peak during reversing

Output Voltage:

0V to ±8kV

(Linearity not guaranteed below 200V. Maximum offset ±20V when programmed to zero or disabled using remote enable.)

Output Current:

0 to 100µA max

Output Polarity:

Remotely reversible via TTL logic signal

Polarity Reversal Time:

<25ms from change of polarity command to 90% of output into 100pF load capacitance.

(Unit incorporates circuitry to minimize the effects of low programmed current on reversing time. Polarity reversal time applies when current is programmed to $3\mu A$ or above.)

- ±8kV 25mS Polarity Reversing Speed
- Optimized for EI and APCI Applications
- Precision Analog Voltage and Current Controls and Monitors
- High Stability
- Low Ripple and Noise
- High Voltage Inhibit Control
- UL Recognized, CE Marked and RoHS Compliant

Voltage and Current Regulation:

Line: <0.1% for ±10% input voltage change Load: <0.1% for 0 to full load

Ripple:

<0.1% p-p @ 100µA

Temperature Coefficient:

<100ppm per degree C

Environmental:

Temperature Range:
Operating: 5°C to 45°C
Storage: -35°C to 85°C

Humidity:

10% to 85%, non-condensing

Stability:

<0.05% per hour after 1 hour warm up

Protection:

Arc and short circuit protected

Output Voltage Limit:

Output voltage does not exceed ±8kV ±250V under any input or output conditions

Dimensions:

1.48" H X 3.23" W X 9.45" D (37.6mm X 82mm X 240mm)

Weight:

2.4 pounds (1.1kg)

Input Connector:

14 way Molex receptacle p/n 39-01-2140. Cable length 508mm, mating connector not provided

Output Connector:

Alden F303RX, mating connector not provided

Regulatory Approvals:

UL/CUL recognized, File E354595. Compliant to EEC Low Voltage Directive. UK Conformity Assessed. RoHS Compliant.



PAGE 2 OF 2

MX8 PLUS - POWER AND CONTROL 14 PIN MOLEX MINI-FIT JR RECEPTACLE

PIN	SIGNAL
1	+24Vdc Input
2	Ground return for +24Vdc Input
3	Enable/Inhibit input. TTL high is enabled, TTL low is disabled (see Note 1)
4	Output voltage monitor. 0 to +8V for 0V to $\pm 8kV$ output. Accuracy $\pm 1\%$
5	Voltage control input. 0 to +8V for 0V to ±8kV output. Accuracy ±1%
6	Current monitor output. 0 - 10V for 0A to 100µA. Accuracy ±2%
7	Current control input. 0 to +10V for 0A to 100µA. Accuracy ±1%
8	Polarity control input. TTL high is positive, TTL low is negative (see Note 1)
9	Analog ground
10	Current/Voltage control indicator. TTL compatible output (3.3V max). TTL high when in current mode. TTL low when in voltage mode.
11	N/C
12	N/C
13	N/C
14	N/C

Note 1: TTL input. The threshold is set to 1.65V for use with 3.3V or 5V input levels although the input will tolerate up to 15V being applied.

How to Order:


Standard: PART NO.: MXP8PN24

DIMENSIONS: in.[mm]

SIDE VIEW



TOP VIEW



FRONT VIEW







PAGE 1 OF 2



Remote HV Inhibit

Spellman's MX10 is a well-regulated high performance DC-DC converter featuring a "hot switchable" polarity reversal capability. The MX10's low ripple specification makes it ideal for Mass Spectrometry applications; especially security detection systems, Dynodes, sample ionization as well as capillary electrophoresis and electrostatic printing applications.

The MX10 is rated at 10kV @ 100uA and is packaged in a shielded metal enclosure. This unit features a logic signal input to control output polarity reversal. A HV inhibit feature, along with voltage and current monitors are provided. Easily customized to meet OEM requirements, the MX10 can be provided with current control, improved ripple performance and higher voltage and current capabilities.

TYPICAL APPLICATIONS

Mass Spectrometry Capillary Electrophoresis **Electrostatic Printing**

OPTIONS

VCC: Voltage and Current Control

SPECIFICATIONS

Input Voltage:

+24Vdc, ±1 volt

Input Current:

<400mA continuous <1.2A during reversing

Output Voltage:

±200Vdc to ±10kV

Output Current:

0 to 100uA max.

Polarity:

Remotely reversible via logic signal, 250mS to settle to ±2%, 1 Hz maximum switch rate

Voltage Regulation:

Load: 0.1% of maximum output voltage for a no load to full load change Line: 0.1% of maximum output voltage for a

1 volt input line change

Hot Switchable Polarity Reversible Via a Logic Signal

- Well Regulated, Low Ripple
- Polarity Reversal Within 250mS (Option to Improve to 100mS)
- Voltage and Current Monitor Outputs
- Flying High Voltage Output Cable
- Voltage or Current Control Options

Current Regulation: (VCC Option)

Load: 0.1% of maximum rated current for a 0 to 100% voltage change

Line: 0.1% of maximum rated current for a

1 volt input line change

Voltage/Current Programming:

0 to 10 volt corresponds to 0 to 100% of rated output voltage

Voltage/Current Monitor:

0 to 10 volt corresponds to 0 to 100% of rated output voltage

Programming and Monitor Accuracy:

±2%

Ripple:

≤0.005% Volts p-p

Stability:

0.1% per hour after 1 hour warmup

Temperature Coefficient:

≤100ppm per degree C

Environmental:

Temperature Range: Operating: 0°C to 40°C Storage: -40°C to 85°C Humidity: 10% to 90%, non-condensing.

Cooling:

Convection cooled

Dimensions:

1.63" H X 6.61" W X 4.53" D (41.5mm X 168mm X 115mm)

Approximately 3 pounds (1.4kg)

Interface/Power Connector:

9 pin male D connector

HV Output Connector:

39.4" (1m) Flying Lead of URM76 LSF cable

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E227588. RoHS Compliant.



MX10 TERMINAL BLOCK 9 PIN

PIN	SIGNAL	SIGNAL PARAMETERS
1	Voltage Monitor	0-10V=0-100% of Rated Output
2	External Inhibit Input	Open or >10V = "OFF"; <4V = "ON"
3	Current Programming Input	0-10Vdc = 0-100% of Rated Output (on VCC option)
4	Signal Ground	Signal Ground
5	Current Monitor	0-10Vdc = 0-100% of Rated Output
6	Polarity Control Input	Open or >10V = "NEGATIVE"; <4V = "POSITIVE"
7	Voltage Programming Input	0-10Vdc = 0-100% of Rated Output
8	+24V Input	+24V Input
9	Power Ground	Power Ground

How to Order:

Standard: PART NO.:MX10PN24


VCC Option: PART NO.:MX10PN24/VCC

DIMENSIONS: in.[mm]

SIDE VIEW



TOP VIEW













Spellman's MX20 is a well-regulated high performance DC-DC converter featuring a "hot switchable" polarity reversal capability. The MX20's low ripple specification makes it ideal for Mass Spectrometry applications; especially security detection systems, Dynodes, sample ionization as well as capillary electrophoresis and electrostatic printing applications.

The MX20 is rated at 20kV @ 100uA and is packaged in a shielded metal enclosure. This unit features a logic signal input to control output polarity reversal. A HV inhibit feature, along with voltage and current monitors are provided. Easily customized to meet OEM requirements, the MX20 can be provided with current control, improved ripple performance and higher voltage and current capabilities.

TYPICAL APPLICATIONS

Mass Spectrometry
Capillary Electrophoresis
Electrostatic Printing

OPTIONS

VCC: Variable Current Control

SPECIFICATIONS

Input Voltage:

+24Vdc, ±1.2 volts

Input Current:

<500mA continuous <1.2A during reversing

Output Voltage:

 $\pm 500 Vdc$ to $\pm 20 kV$

Output Current:

0 to 100uA max.

Polarity:

Remotely reversible via logic signal, 500mS to settle to $\pm 2\%$, 1 Hz maximum switch rate

Voltage Regulation:

Load: 0.02% of maximum output voltage for a no load to full load change
Line: 0.01% of maximum output voltage for a

1 volt input line change

- Hot Switchable Polarity Reversible Via a Logic Signal
- Well Regulated, Low Ripple
- Polarity Reversal Within 500m\$
- Voltage and Current Monitor Outputs
- Remote HV Inhibit
- Flying High Voltage Output Cable
- Current Control Option

Current Regulation: (VCC Option)

Load: 0.1% of maximum rated current for a 0 to 100% voltage change
Line: 0.01% of maximum rated current for a

1 volt input line change

Voltage/Current Programming:

0 to 10 volts corresponds to 0 to 100% of rated output voltage/current

Voltage/Current Monitor:

0 to 10 volts corresponds to 0 to 100% of rated output voltage/current

Programming and Monitor Accuracy:

±2% Voltage Programming/Monitor ±5% Current Programming/Monitor

Ripple:

≤0.0025% Volts p-p

Stability:

0.1% per hour after 1 hour warmup

Temperature Coefficient:

≤100ppm per degree C

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -40°C to 85°C
Humidity:
10% to 90%, non-condensing

Cooling:

Convection cooled

Dimensions:

2.05" H X 6.61" W X 6.50" D (52mm X 168mm X 165mm)

Weight:

Approximately 5.51 pounds (2.5kg)

Interface/Power Connector:

9 pin male D connector

HV Output Connector:

39.4" (1m) Flying Lead of URM76 LSF cable

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.



MX20 TERMINAL BLOCK 9 PIN

PIN	SIGNAL	SIGNAL PARAMETERS
1	Voltage Monitor	0-10V=0-100% of Rated Output
2	External Inhibit Input	Open or >10V = "OFF"; <4V = "ON"
3	Current Programming Input	0-10Vdc = 0-100% of Rated Output (on VCC option)
4	Signal Ground	Signal Ground
5	Current Monitor	0-10Vdc = 0-100% of Rated Output
6	Polarity Control Input	Open or >10V = "NEGATIVE"; <4V = "POSITIVE"
7	Voltage Programming Input	0-10Vdc = 0-100% of Rated Output
8	+24V Input	+24V Input
9	Power Ground	Power Ground

2.05 [52]

DIMENSIONS: in.[mm]


SIDE VIEW

How to Order:

Standard: PART NO.:MX20PN24

VCC Option: PART NO.:MX20PN24/VCC













Spellman's MXE series is a family of high voltage, high performance, ultra-compact, hot-switchable polarity reversing modules with output voltages ranging from 2.5kV to 10kV.

The MXE series is controlled via analog interface, provided via a standard 15-pin D-type connector. The units feature a differential voltage program input for low noise control and TTL compatible Enable and Polarity control signal inputs.

Spellman's advanced low noise, high stability technology provides the high quality and performance needed for precision applications.

TYPICAL APPLICATIONS

Mass Spectrometry Automatic Test Equipment Capillary Electrophoresis Dual Ion Surface Analysis

Electrostatic Printing Electrostatic Lenses Electrospinning **Precision Laboratory**

SPECIFICATIONS

Input Voltage:

+24Vdc, ±1.2Vdc

Input Current:

0.5A maximum

Output Voltage:

3 models available: ±2.5kV, ±5kV and ±10kV The minimum programmable voltage is ±20V The output is not designed to sink current

Output Polarity:

Hot-switchable polarity reversing

Output Current:

200µA maximum

Voltage Regulation:

Line: For a 5% line change 20ppm

Load: 0-100% load 20ppm

- Hot-switchable polarity reversing modules from 2.5kV to 10kV, at 200µA
- Differential Analog Voltage Control
- Voltage and Current Monitors
- High Stability, Low Temperature Coefficient
- Ultra Low Ripple and Noise, Specified Down to 1/f Band

Accuracies:

Voltage Programming: ±1% or ±10V* Voltage Monitor: ±2% or ±20mV* Current Monitor: ±5% or ±50mV* *whichever is greater

Current Limit:

110% of rated output current.

Polarity Reversal Time:

10s to within 2ppm at max output voltage amplitude and 100pF load

Output Decay Time:

5s to <50V at no-load condition

Ripple:

30mV between 0.01Hz and 20MHz

Stability:

15ppm/8h after one hour warm up period

Temperature Coefficient:

15ppm per degree C

Protection:

Arc and short circuit protected.

The power supply will fully recover once the short is removed with no subsequent damage to load, supply,input control, or input supply

Environmental:

Temperature Range:

Operating: 10°C to 45°C Storage: -20°C to 85°C

Humidity:

5% to 90% RH, non-condensing

Coolina:

Convection cooled

Dimensions:

1.9" H X 5.7" W X 6.8" D (48mm x 144mm x 172mm)

Weight:

3.74 lbs (1.7kg)

Interface Connector:

15 pin male D connector

Output Connector:

Captive 39.4" (1 meter) long un-terminated shielded HRG58 HV cable (URM76 compatible)

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. UK Conformity Assessed. RoHS Compliant.





MXE SELECTION TABLE

Model	Output Voltage	Output Current
MXE2.5PN24	±2.5kV	200μΑ
MXE5PN24	±5kV	200μΑ
MXE10PN24	±10kV	200μΑ


MXE EXTERNAL INTERFACE-15 PIN MALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	24Vdc Return	Input voltage return
2	+24Vdc Input	Input voltage +24dc @ 0.5A max
3	Voltage Monitor Output	0 to 10Vdc = 0 to 100% rated output, Zout=330Ω
4	Polarity Set Input	TTL level or open/short contact signal. Low or short = Positive, high or open = Negative
5	N/C	Pin used internally - do not connect
6	Voltage Program Return	0 to 10Vdc differential between pin 7 and pin 6 =
7	Voltage Program Input	0 to 100% of rated output, Zin=100kΩ
8	Current Monitor Output	0 to 10Vdc = 0 to 200 μ A, Zout=330 Ω
9	N/C	Pin used internally - do not connect
10	N/C	Pin used internally - do not connect
11	Signal Ground	Signal ground for control and monitoring
12	Enable Input	TTL level or open/short contact signal. Low or short = enabled, high or open = disabled
13	Control Pin	Connect to pin 14
14	Control Pin	Connect to pin 13
15	N/C	Pin used internally - do not connect





REAR VIEW



SIDE VIEW





Hauppauge, New York USA

Corporate Headquarters



- ±10kV 25mS Polarity Reversing Speed
- Integrated Electron Multiplier Supply
- Precision Analog Voltage Control
- High Stability
- Low Ripple and Noise
- High Voltage Inhibit Control
- RoHS Compliant

Spellman's RoHS compliant MX10 *Plus* is a well-regulated high performance fast reversible dynode supply featuring a 25ms "hot switchable" polarity reversing capability with an integrated -2.3kV electron multiplier supply.

The MX10 *Plus*'s low ripple specification is typical of the topologies that make Spellman High Voltage your ideal choice for mass spectrometry applications; especially security detection systems, dynodes, sample ionisation as well as capillary electrophoresis and electrostatic printing applications. The MX10 *Plus* has been designed especially for dynode detector applications.

The MX10 *Plus* can be easily tailored to an OEM's requirement, such as improved ripple performance, or different voltage and/or current capabilities.

TYPICAL APPLICATIONS

Dynode Supply Electron Multiplier Supply

SPECIFICATIONS

Input Voltage:

+15Vdc, ±.75Vdc

Input Current:

≤500mA nominal continuous <2A during reversing

Temperature Coefficient:

≤100ppm per degree C

Environmental:

Temperature Range:
Operating: 5°C to 45°C
Storage: -35°C to 85°C
Humidity:
10% to 85%, non-condensing

Stability:

(constant operating conditions) ≤300ppm per hour after 1 hour warm up

Protection:

Arc and Short circuit protected

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant.

DYNODE SPECIFICATIONS

Output Voltage:

 $\pm 10kV$

Output Current:

10μΑ

Output Polarity:

Remotely reversible via TTL logic signal

Switching Speed:

25ms to settle 90% into 50pF load

Voltage Regulation:

Line: ≤0.02% for a 1.5V input voltage change

Ripple:

≤10 Volts p-p

ELECTRON MULTIPLIER SPECIFICATIONS

Output Voltage:

Fixed: -2.3kV

Output Polarity:

Negative

Output Current:

≤230µA

Voltage Regulation:

Line: ≤0.02% for a 1.5V input voltage change Load: <5V for for no load to 22M Ohms load change

Ripple:

≤200mV p-p @ 2.3kV into 22M Ohm load

Output Rise Time:

10ms

Output Fall Time:

10ms

Dimensions:

2.00" H X 5.30" W X 8.00" D (50.8mm X 134.6mm X 203mm)

Weight:

Approximately 3.3 pounds (1.5kg)

Interface/Power Connector:

20 pin flat ribbon connector

Output Connector:

±10kV: modified Alden #A200 connector -2.3kV: MHV Kings bulkhead KV-79-15 or similar




MX10 PLUS TERMINAL BLOCK 20 PIN

PIN	SIGNAL
1	+15Vdc Input
2	+15Vdc Input
3	N/C
4	N/C
5	Ground
6	Ground
7	Output Voltage Control
8	Signal Reference Ground
9	10kV On
10	10kV On
11	Output Polarity Control
12	EM Protect
13	-2.3kV Output Monitor
14	EM On
15	Ground
16	Ground
17	±10kV Output Monitor
18	N/C
19	+15Vdc Input
20	+15Vdc Input


How to Order:Standard: PART NO.:MXP10PN15

DIMENSIONS: in.[mm]

SIDE VIEW



TOP VIEW



FRONT VIEW











Spellman's MXR Series are well-regulated high performance DC-DC converters. The MXR's low ripple specification makes it ideal for Mass Spectrometry and electron microscopes. The MXR20 is rated at 20kV @ 300uA and MXR30 is rated at 30kV @ 300uA. Both are packaged in a shielded metal enclosure and are available either in analog or RS-232 digital control options. These units feature a logic signal input to control output polarity reversal. Voltage, polarity and current monitors are provided. The digital version also features an opto isolated interlock input (HV Enable/Inhibit). Easily customized to meet OEM requirements, the MXR Series can be provided with current control, improved ripple performance and higher voltage and current capabilities.

TYPICAL APPLICATIONS

Mass Spectrometry
Electron Microscopes
Capillary Electrophoresis
Electrostatic Printing

OPTIONS

MXR can be ordered as an analog or a digital controlled unit. See How To Order information below.

Custom captive cable options available upon request.

SPECIFICATIONS

Input Voltage:

24Vdc (±5%)

Input Current:

≤1.25 A nominal continuous ≤4.5 A peak during reversing

Output Voltage:

0V to ±20kV (MXR20) 0V to ±30kV (MXR30)

Output Current:

<300µA

Voltage Regulation:

Load: <50ppm of maximum output voltage for a no load to full load change

Line: <20ppm of maximum output voltage for a 5% input line change

+1-631-630-3000

Programming and Monitor Accuracy:

±2% Voltage Programming/Monitor

Hot Switchable Reversible Polarity, Settles to <3ppm Within 2s

- Voltage and Current Monitor Outputs
- Arc and Short Circuit Protected
- Well Regulated, Low Ripple, High Stability
- UL Recognized, CE Marked and RoHS Compliant
- OEM Customization Available

Ripple:

20kV: 100mVp-p 30kV: 150mVp-p

Stability:

1hr = 10ppm max. after 1 hr warm-up 8hrs = 20ppm max. after 1 hr warm-up

Temperature Coefficient:

10ppm/°C

Reversing Time:

2s for +20kV to -20kV or +30kV to -30kV settling to <3ppm. Faster switching times available on request.

Environmental:

Temperature Range:
Operating: 10°C to 50°C
Storage: -35°C to 85°C
Humidity:
0% to 85%, non-condensing

Cooling:

Convection cooled

Dimensions:

2.05" H X 8.47" W X 9.45" D (52mm X 215mm X 240mm)

Weight:

8.80 pounds (4.0kg)

Input Connectors:

Analog units:

Power and Control: 12 way Samtec FWS 12-04-T-S-RA

Digital units:

Power: 2 way Molex Mini-fit Jr 39-30-1022 Control: 10 way 'IDC Ribbon cable' connector 3M N3793-5302RB

Output Connector:

Standard output is GES HB30 receptacle (GES p/n: 7331051). Mating plug is GES HS30 (p/n: 7331050, not included). Mating cable assembly can be ordered separately, see How To Order information below.

Regulatory Approvals:

UL recognized component (RC). File number E354595. Compliant to IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. UKCA marked to BS EN 61010-1. RoHS compliant. As the unit is designed for incorporation within the user's system it is not tested against any specific EMC standards. Compliance with any relevant EMC standards on a system level are the responsibility of the equipment designer.

ANALOG UNITS—POWER AND CONTROL 12 PIN SAMTEC FWS CONNECTOR

PIN	SIGNAL
1	Current monitor output 0-10V = 0V to 500μA Zout=10kΩ, Accuracy ±5%
2	+24Vdc Input
3	Voltage monitor output 0-10V = 0V to Max V Zout=10kΩ, Accuracy ±2%
4	N/C
5	N/C
6	N/C
7	Voltage program input 0-10V = 0V to Max V Zin>1M Ω , Accuracy ±2%
8	Polarity set input, TTL levels: LO = +VE, HI/Open = -VE
9	Signal ground
10	Ground return for +24Vdc
11	N/C
12	Polarity status output LO (<200mV, source 1.5k Ω) = +VE, HI (+24V, source 2.2k Ω) = -VE

DIGITAL UNITS-POWER 2 PIN MOLEX MINI-FIT JR

PIN	SIGNAL
1	+24Vdc Input
2	Ground return for +24Vdc

DIGITAL UNITS— CONTROL 10 PIN IDC RIBBON CONNECTOR

PIN	SIGNAL
1	Transmit data (output) with respect to pin 2
2	Serial signal ground return (if required)
3	Receive data (input) with respect to pin 2
4	N/C
5	N/C
6	N/C
7	Interlock opto-isolator input (0mA = Voltage Inhibit) see*
8	Interlock opto-isolator signal return
9	Polarity set opto-isolator input (0mA = -VE) see*
10	Polarity set signal opto-isolator signal return

^{*}Note: 3.3V@6mA or 5V@10mA

How to Order:

Analog (standard): PART NO.: MXR20PN24

PART NO.: MXR30PN24

PART NO.: MXR20PN24/DCC2 Digital (option):

PART NO.: MXR30PN24/DCC2


Mating cable,

PART NO.: HVC30/1S/1279 length 2m:



DIMENSIONS: in.[mm] SIDE VIEW






FRONT VIEW (Digital) 8.47 [215.0] (1)



FRONT VIEW (Analog)





225

Corporate Headquarters



• Floating, Programmable 3kV Output

- Output Isolated to 15kV
- Well Regulated, Low Ripple
- Output Voltage Monitor
- Compact Shielded Metal Enclosure
- Arc and Short Circuit Protected

Spellman's MCP Module is a well-regulated, high performance DC-DC converter featuring a floating 3kV output, isolated to 15kV. The MCP low output ripple specification makes it ideal for use with detectors in Mass Spectrometry applications like: Electron Multipliers (EM's), Microchannel Plates Detectors (MCP's) and Channel Electron Multipliers.

This +3kV @ 330uA module is packaged in a shielded metal enclosure. The unit has remote voltage programming and a voltage monitor, and features low injected ripple when used with biasing supplies. The MCP module is easily customized to meet OEM requirements with improved ripple performance, improved stability and configurable output lead terminations as required.

TYPICAL APPLICATIONS

Mass Spectrometry Detectors Microchannel Plates Electron Multipliers Channel Electron Multipliers

SPECIFICATIONS

Input Voltage:

+24Vdc, ±0.5 volts

Input Current:

600mA maximum

Output Voltage:

+100V to +3kV, continuously variable over the entire output range

Output Current:

330uA maximum

Polarity:

Positive

Isolation Voltage:

Up to 15kV total to ground (resistance to ground 600M on each output)

Line Regulation:

≤0.01% for input voltage change of 1V

Load Regulation:

≤0.1% for a no load to full load change

Voltage Programming:

0 to 10 volt corresponds to 0 to 100% of rated output voltage

Voltage Monitor:

0 to 5 volts corresponds to 0 to 100% of rated output voltage

Accuracy:

±1% from 10% to 100% of output. Below 10% accuracy spec is not guaranteed

Ripple:

≤0.1% Volts p-p, 0.1Hz to 1MHz

Stability:

≤1000 ppm/hour at constant operating conditions after a 1 hour warm up

Temperature Coefficient:

≤300ppm per degree C

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -40°C to 85°C
Humidity:
10% to 90%, non-condensing

Cooling:

Convection cooled

Dimensions:

1.49" H X 4.09" W X 6.73" D (38mm X 104mm X 171mm)

Weight:

2.2 pounds (1kg)

Interface/Power Connector:

9 pin male D connector

High Voltage Output Cable:

HV positive: 29.5" (750mm) fly wire, URM76 coaxial HV cable HV negative: 29.5" (750mm) fly wire, URM76 coaxial HV cable

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS compliant.






DIMENSIONS: in.[mm]


FRONT VIEW

MCP INTERFACE/POWER CONNECTOR

JB1	SIGNAL	SIGNAL PARAMETERS
1	Signal Ground	Signal Ground
2	Voltage Programming Input	0-10Vdc = 0-100% of Rated Output
3	+24V Input	+24V Input
4	+24V Input	+24V Input
5	Voltage Monitor	0-5Vdc=0-100% of Rated Output
6	Power Ground	Power Ground
7	Power Ground	Power Ground
8	Power Ground	Power Ground
9	Power Ground	Power Ground



TOP VIEW













The TOF3000 offers critical specifications like ultra low ripple and noise, excellent temperature coefficient; a stable, repeatable and accurate output, along with remote output polarity reversing capability. These superior specifications result in improved mass spectrometer resolution. Unique high voltage packaging and surface mount fabrication techniques, coupled with Spellman's proprietary encapsulation technology provide this unit in an attractive sized OEM package.

Featuring a 0-30kV @ 400µA output with remote polarity reversing capability and dimensions of 3"H x 5"W x 12 5/8"L, the TOF3000 is a small, cost-effective high voltage power supply with technology that sets the standard for the future of Mass Spectrometry applications.

TYPICAL APPLICATIONS

Mass Spectrometry

SPECIFICATIONS

Input Voltage:

+24 Vdc, +5%, -2%

Input Current:

2 amps maximum

Output Voltage:

0 to 30kV

Output Current:

0 to 400 microamperes

Polarity:

Positive or Negative with respect to ground, reversible via TTL signal

Voltage Regulation:

Line: 0.001% for input change of 1 volt Load: 0.001% for 100µA to full load change

Current Regulation:

Line: 0.05% for +5% to -2% input change Load: 0.1% for 0 to maximum output voltage

- Remote Output Polarity Reversibility Via TTL Signal Control
- Ultra Low Ripple and Noise
- Small Footprint OEM Modular Packaging
- Encapsulated for Reliable, Long Term Corona Free Operation
- CE and RoHS Compliant

Ripple:

≤70mV peak to peak

Stability:

0.01% per hour, 0.02% per 8 hours after 1.0 hour warm up period

Temperature Coefficient:

25ppm per degree C

Environmental:

Temperature Range: Operating: 0°C to 50°C Storage: -20°C to 65°C Humidity:

10% to 90% RH, non-condensing

Control Interface

Voltage Program Input:

0 to +10Vdc corresponds to 0 to ±30kV, Zin ≥ 1 megohm

Program Accuracy:

±0.15% at 15KV, with overall accuracy of ±0.25% of maximum output

TTL Polarity Reversal:

High = positive polarity Low = negative polarity

Voltage Monitor:

0 to 10Vdc corresponds to 0 to 30KV, Zout = 4.7Kohm

Current Monitor:

0 to 10Vdc corresponds to 0 to 400uA, Zout = 4.7Kohm

Cooling:

Convection cooled

Dimensions:

3"H X 5"W X 12.625"D (76.2mm x 127mm x 321.7mm)

Weight:

9.5 pounds (4.31kg)

Interface Connector:

15 pin male D connector

Output Connector:

Alden B102, which accepts Alden B200 cable plug

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized, File 148969. RoHS Compliant




JB1 INTERFACE CONNECTOR


PIN	SIGNAL	SIGNAL PARAMETERS
1	Spare	N/C
2	Voltage Program	0 to 10V=0 to 100% Rated Output
3	Spare	N/C
4	Spare	N/C
5	Voltage Monitor	0 to 10V=0 to 100% Rated Output
6	TTL Polarity Control Signal	Hi=Positive Polarity, Low=Negative Polarity
7	Signal Ground	Signal Ground
8	Power Ground	Power Ground
9	Spare	N/C
10	Spare	N/C
11	Spare	N/C
12	TTL HV Enable	Hi=Inhibit, Low=Enable
13	Current Monitor	0 to 10V=0 to 100% Rated Output
14	Spare	N/C
15	+24Vdc	+24Vdc





DIMENSIONS: in.[mm]



BACK VIEW











Spellman's MCP4 is a well-regulated, high performance DC-DC converter featuring a floating 4kV @ 600uA output, isolated to 15kV. The MCP4 low output ripple specification and high stability make it ideal for use with detectors in Mass Spectrometry applications such as: Electron Multipliers (EM's), Microchannel Plates Detectors (MCP's) and Channel Electron Multipliers. This module is packaged in a shielded metal enclosure and the high voltage output is provided via two captive one meter long shielded coaxial cables. The unit has remote 0-10Vdc = 0-100% rated voltage programming and voltage monitor. A TTL compliant Enable signal provides simple control of the high voltage output. This unit has specifically designed to minimize crosstalk with the high voltage source which it is floated upon. The MCP4 can be customized to meet OEM requirements.

TYPICAL APPLICATIONS

Mass Spectrometry Detectors Microchannel Plates Electron Multipliers Channel Electron Multipliers

SPECIFICATIONS

Input Voltage:

+24Vdc, ±5%

Input Current:

700 mA maximum

Output Voltage:

0 to 4kV, continuously variable over the entire output range

Output Current:

600uA maximum

Current Limit:

1900uA maximum

Polarity:

+VE Positive with respect to the high voltage source (-VE) which it is floated upon

Isolation Voltage:

Up to 15kV total to ground.

Note: When the unit output is set to zero and no load is connected: If the reference supply is positive (up to +15kV), +VE will always be less than 100V with respect to -VE. If the reference supply is negative (up to -15kV), a $47M\Omega$ pre-load resistor fitted within the MCP4 limits +VE (with respect to -VE) to \leq 1400V

- Floating, Programmable 4kV Output
- Output Isolated to 15kV
- Well Regulated, Low Ripple
- Output Voltage Monitor
- Compact Shielded Metal Enclosure
- Arc and Short Circuit Protected

Line Regulation:

50ppm for a ±5% line change

Load Regulation:

300ppm for a 10% to 100% load change

Voltage Programming:

0 to 10 volt corresponds to 0 to 100% of rated output voltage

Voltage Monitor:

0 to 10 volts corresponds to 0 to 100% of rated output voltage. Accuracy ±1%. Iout=300µA maximum

Ripple:

100mVpp

Injected Ripple:

30mVpp, on an appropriate, properly connected ground referenced high voltage generator

Temperature Coefficient:

20ppm per degree C

Drift:

50ppm, maximum excursion in any 8 hours period at 40°C

Environmental:

Temperature Range:
Operating: 0°C to 50°C
Storage: -30°C to 85°C
Humidity:

5% to 90%, non-condensing.

Cooling:

Convection cooled

Dimensions:

1.81" H X 5.74" W X 9.53" D (46mm X 139mm X 242mm)

Weight:

3.85 pounds (1.75kg)

Interface/Power Connector:

9 pin male D connector

High Voltage Output:

Both HV cables (+VE and -VE): HRG58 coaxial 45.3"(1150mm)

Regulatory Approvals:

Designed to meet IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. UKCA marked to BS EN 61010-1. RoHS compliant.


EMC

As the unit is designed for incorporation within the users system it is not tested against any specific EMC standards. The user will need to take sensible EMC precautions when designing the unit in and verify the overall system EMC performance against any relevant standards.



INTERFACE/POWER CONNECTOR—9 PIN MALE D


PIN	SIGNAL	SIGNAL PARAMETERS
1	Voltage Programing Input	0 to 10 volt. Accuracy=2% Zin=20kΩ
2	Voltage Programing Return	Differential return for Voltage programming
3	Enable	Enable = High (>2V) Vmax = 11V, Imax = 19mA
4	Enable Return	Differential return for Enable
5	Power Ground	Power Ground
6	Signal Ground	Signal Ground
7	Voltage Monitor	0 to 10 volt corresponds to 0 to 100% of rated output. Accuracy ±1%. lout=300μA maximum
8	N/C	N/C
9	+24V Input	+24Vdc Input



How to Order:

Standard: PART NO.:MCP4P













Spellman's FIB Series is an integrated multiple output high voltage power supply specifically designed for focused ion beam applications. It incorporates a high stability accelerator voltage with the floating outputs to drive traditional Ga Ion and Plasma Sources.

An additional Lens Chassis is available, providing the high performance fixed or reversible polarity high voltage lenses required to focus the Ion Beam. Focused Ion Beam is typically used in the semiconductor industry, materials science and in the biological field for imaging, etching and deposition of materials.

The Main Chassis provides an Acceleration voltage up to 35kV, with floating Filament, Extractor and Suppressor outputs, all designed to the exacting performance requirements for FIB applications. The Lens Chassis offers Lens voltages up to 30kV, with fixed or reversible polarity.

All outputs are offered with ultra-low ripple, excellent regulation, stability, temperature coefficient, drift and accuracy specifications.

Customer control of this integrated FIB power supply system is accomplished via a fiber optic or Ethernet interface. All high voltage safety interlocks are of a failsafe hardware based design.

TYPICAL APPLICATIONS

Focused Ion Beam (FIB) Ion Gun Controller

SPECIFICATIONS

Input Voltage:

+24Vdc, ±5% @ 5.5 amps maximum. Inrush is <6 amps for 1 second.

Environmental:

Operating Temperature:

+10°C to +45°C ambient for normal operation. The unit will operate from 0°C but will require an extended warm up period.

Storage Temperature:

-20°C to +60°C

Humidity:

0 to 80% RH, non-condensing

2000 meters ASL at full power. For altitudes above 2000 meters the maximum ambient operating temperature is linearly derated by 1.1°C per 300 meter interval.

- Integrated Accelerator and Ion Source Chassis
- High Performance Ground Reference Lens Chassis
- Very Low Ripple and Ultra Stable Outputs
- Robust Arc and Short Circuit Protection
- Designed to Minimize Micro-discharge Events
- Optically Isolated Digital Interface
- CE Marked & Designed to Meet SEMI S2

FIB Input Power Connector:

2 pin Mate-n-Lok (TE 1-350942-0)

FIB Communication:

Fiber Optics dual channel Avago HFBR- 2524z/1524z. RS-232. Ethernet RJ-45 socket which supports 100BaseTX.

When Ethernet port is connected, RS-232 will not work. A Spellman Fiber Optic to RS-232 converter can be ordered. as well as a complete Fiber Optic to USB communication kit.

FIB Vacuum Interlock Connector:

Dual channel Avago HFBR- 2524z (receiver) /1524z (transmitter)

FIB to Lens Modules Interconnection:

The modules are supplied with interconnecting cables for the power and communications. The same kit is used to connect the FIB to the lens module, and, if required, between a lens module and the next.

FIB HV Output Connector:

The main high voltage output is fitted with a custom 4 pole receptacle. A Spellman HV cable assembly, available in different lengths, can be ordered with the unit.

Lenses HV Output Connectors:

The lenses are fitted with Lemo ERA3Y430CTL receptacles. A Spellman 5 meters mating HV cable assembly can be ordered with the units. (See the product manual for additional cables and connectors information)

FIB and LGM Operation:

When the modules are switched on / enabled, all output voltages are automatically set to 0V.

Safety Interlocks:

The vacuum interlock is an optical interlock. When it opens, the power supply is deactivated via relay contacts and will not reactivate until it is enabled through the computer control, even though the interlock may close. The FIB communication remains operational.

The interlock plate is situated around the FIB HV Output connector, and if removed will also disable all outputs.

The individual modules of the HVPS can be enabled and disabled through computer control, provided the appropriate hardware interlocks are enabled.

Weight:

Main chassis: 67.46 lbs. (30.6 kg) Lens chassis: 27.56 lbs. (12.5 kg)

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. UK Conformity Assessed RoHS Compliant.





OUTPUTS SPECIFICATIONS

MODULE		FIB		_	LGM
OUTPUT	Accelerator	Filament	Suppressor	Extractor	Lens
Output Voltage	0 to 35kV, referenced to ground	0 to 5V referenced to Accelerator, current controlled	-2kV to +2kV referenced to Accelerator	0 to -15kV referenced to Accelerator	30kV max, referenced to ground, positive, negative or bipolar. (see Lens Module options table)
Output current - max	30μΑ	5A	30μΑ	400μΑ	30μA or 50μA (see config. table)
Output current limit	30μΑ	current controlled	30μΑ	programmable 8 bit, 0 to 400µA	30μA or 50μA (see config. table)
Output Absolute Accuracy	100V	5mA	20V	100V	100V
Load Regulation	±0.01% of max for 0 to 30µA change	±0.1% of max for 0 to 5V change	±0.01% of max for 0 to 30µA change	±0.01% of max for 0 to 400µA change	±0.005% of max for 0 to max rated current change
Line Regulation	100mV for a 5% line change	5mA for a 5% line change	100mV for a 5% line change	100mV for a 5% line change	100mV for a 5% line change
Ripple p-p from 0.1Hz to 1MHz	200mV at max output	10mA	150mV	100mV at 30µA and below	200mV for 30kV bipolar outputs. 150mV for all other output ratings
Temperature Coefficient	25 ppm/°C	200 ppm/°C	25 ppm/°C	25 ppm/°C	25 ppm/°C
Stability (after 2h warm up)	1.5V / 10h	5mA/10min	0.5V / 10h	0.5V / 10h	1V / 10h
Programming	16 bit, 0 to 35kV	16 bit, 0 to 5A	16 bit, -2kV to +2kV	16 bit, 0 to -15kV	16 bit, min to max Vout
Voltage Monitoring	16 bit, 0 to 35kV ±1% accuracy ±50V offset	16 bit, 0 to 5V ±4% accuracy ±0.1V offset	16 bit, -2kV to +2kV ±1% accuracy ±8V offset	16 bit, 0 to -15kV ±1% accuracy ±15V offset	18 bit, min to max Vout, ±1% accuracy ±15V offset
Current Monitoring	16 bit, 0 to 30μA ±1% accuracy ±0.3μA offset	16 bit, 0 to 5A ± 4% accuracy ±50mA offset	N/A	16 bit 0 to 10μA: ±0.05μA accuracy ±0.05μA offset 16 bit 10μA to 400μA: ±3% accuracy ±5μA offset	18 bit, min to max lout ±3% accuracy ±1µA offset
Response (see note 1)	<1.0 s	<0.1 s	<0.25 s	<0.25 s	<0.1 s, <4 sec to reach <2V away from steady state for 20kV to 18kV and 18kv to 20kV change
Additional info				see note 2	see notes 3 and 4

Note	1:

This is the time taken for the output signal of a module to settle (to 0.2% of the step size, or 1 V (20 mA for the filament), whichever is greater) in response to a ±2% or less (of full scale) step in its output, as measured from when the output first starts to change.

Note 2:

Hard trip at $400\mu A$ in < 0.25s programmable trip delay (for when current at I limit) 0 to 255s, 8 bit res., (5s min, 20s default)

Note 3:

The above specifications do not apply in the range -500V to +500V.

Wobble range: 2V to 2.5kV p-p, sinusoidal. If wobbling occurs near zero, the wobble waveform will be clipped so as to prevent crossing zero.

Wobble Period: 1s to 4s

LENS MODULES

Available as Stand	ard Lens 1 0	utput	Lens 2 O	utput
Part number	Voltage	Current	Voltage	Current
LGM30P/25PN	0V to +30kV	30uA	-25kV to +25kV	30uA
LGM30P/30P	0V to +30kV	30uA	0V to +30kV	30uA
LGM30P/25N	0V to +30kV	30uA	0V to -25kV	30uA
Available on Requ	est Lens 1 O	utput	Lens 2 O	utput
LGM20PN/30PN	-20kV to 20kV	30uA	-30kV to +30kV	30uA
LGM30N/25PN	0V to -30kV	30uA	-25kV to +25kV	30uA
LGM20N/10N	0V to -20kV	50uA	0 to -10kV	50uA

Please consult with factory for availability and custom configuration requests.




PAGE 3 OF 3

Main Chassis

DIMENSIONS: in.[mm]


TOP VIEW




Lens Chassis

DIMENSIONS: in.[mm]


TOP VIEW



FRONT VIEW




FRONT VIEW



REAR VIEW



REAR VIEW



HOW TO ORDER

Description	Part number
FIB - Main Chassis	FIB35
LGM - Lens Chassis	See part number in the Lens Modules Table
FIB to Lens Modules Interconnection kit	FIBK826
FIB HV Output cable	2.8 meters: HVC30/4ISO/1209 5 meters: HVC30/4ISO/1297
Lens HV Output cable	5 meters: HVC30/1S/1253
FIB communication kit	FIBK100
Optical to RS-232 converter	21777









The EBM20N5/24 powers E-Beam Columns in Thermionic Scanning Electron Microscopes providing acceleration, bias and filament sources in a single compact package. Spellman's proprietary HV packaging and encapsulation technology gives dramatic improvements in size, cost and performance compared to other SEM power supply offerings. The EBM20N5/24 provides a highly regulated, low noise, ultra stable accelerator supply programmable from 0 to -20kV at 250uA. The EBM20N5/24 has floating bias and filament supplies referenced to the accelerator. Programming signals utilize differential analog inputs to minimize external noise and offset voltages effects. A ground referenced accelerator current monitor is provided. The EBM20N5/24 is arc and short circuit immune, along with over voltage and over current protection.

TYPICAL APPLICATIONS

Scanning Electron Microscope

SPECIFICATIONS

Input Voltage:

+24Vdc, ±5%, 1.5A maximum

High Voltage Outputs:

ACCELERATOR:

Voltage:

0V to -20kV full load with respect to ground

Current

250µA maximum (including feedback current), continuous from -500V to -20kV

Current Trip Level:

275mA, ±10%. Trips off all outputs, reset by cycling input power

Accuracy (voltage program):

±1% from -500V to -20kV

Load Regulation:

<±100ppm, 20µA to 250µA load change

Line Regulation:

<±100ppm for 10% line change

Ripple:

<20ppm p-p at -20kV, 250µA, maximum bias and filament output

Temperature Coefficient:

<100ppm/°C

Stability:

30ppm/3 minutes at 100µA load current after 1 hour warm up

Triode Supply for Electron Beam Columns

- High Precision, Low Noise, Ultra Stable
- Over Current/Voltage Protection
- Arc and Short Circuit Protection
- OEM Customization Available
- UL Certified, CE Marked and RoHS Compliant

Rise Time (switch ON):

<3 seconds (0% to 90%) with no overshoot

Fall Time (switch OFF):

<100 seconds (to <50 volts)

BIAS

(Referenced to Accelerator)

Voltage:

0 to ± 1.5 kV (max allowable output limited to 2kV)

Current:

150µA maximum

Accuracy (voltage program):

±3% of full scale

Line Regulation:

<±0.1% for 10% line change

Ripple:

<0.1% p-p

Temperature Coefficient:

<1000ppm/°C

Stability:

1%/10 minutes

Rise Time (switch ON):

<3 seconds (0% to 90%) with no overshoot

Fall Time (switch OFF):

<100 seconds (to <50 volts)

FILAMENT:

(center voltage WRT accelerator output)

Power:

0 to 12W

Load Resistance:

1.33Ω ±5%

Accuracy:

±3% of FS

Load Regulation:

<1% for 10% change in load resistance

Line Regulation:

<1% for 10% line voltage change

Ripple:

<0.1% p-p max

Temperature Coefficient:

<300ppm/°C

Stability:

100ppm/10 minutes



INTERFACE:

Input:

Analog control for accelerator, filament and bias

High Voltage Output:

Custom 3 pin receptacle and cable assembly

Temperature:

Operating: 5°C to +40°C Storage: -20°C to +50°C

Humidity:

20% to 85% RH, non-condensing

Dimensions:

10.63 H x 2.36 W x 7.87 D (270mm x 60mm x 200mm) excluding any mounting brackets

Weight:

<10 lbs. (4.5kg)

Regulatory Approvals:

UL recognized component (RC). File number E354595. Compliant to IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. UKCA marked to BS EN 61010-1. RoHS compliant.

As the unit is designed for incorporation within the users system it is not tested against any specific EMC standards. The user will need to take sensible EMC precautions when designing the unit in and verify the overall system EMC performance against any relevant standards.

POWER INPUT CONNECTOR JHA2 3 PIN JST MODEL B 3PS-VH

PIN	SIGNAL	PARAMETER
1	+24V High Voltage Power Input	+24Vdc Input
2	0V Input	+24Vdc Common
3	FG	Chassis Ground


CONTROL AND MONITORING CONNECTOR JHA3 10 PIN JST MODEL S10B-EH


F	PIN	SIGNAL	PARAMETER
	1	FIL PROG (+)	Filament Program (+) Input
Г	2	GND	Ground
	3	BIAS (+)	Bias (+) Input
Г	4	GND	Ground
Γ	5	ACC PROG (+)	Acc Voltage Program (+) Input
	6	GND	Ground
Г	7	EMS	Emission Current Monitor Output
Г	8	GND	Ground
Г	9	ACC MON	ACC Voltage Monitor Output
Г	10	GND	Ground

How to Order:					
Standard: PART NO.:EBM20N5/24					
HV Cable: PART NO.:HVC30/3IS/LL1650 (1.65m Cable)					

+1-631-630-3000

HV CABLE ASSEMBLY DETAILS







PAGE 3 OF 3

DIMENSIONS: in.[mm]

SIDE VIEW













The EBM30N/TEG is an integral solution that provides the high voltage required by Thermionic Emission Scanning Electron Microscope (SEM). Spellman's proprietary packaging and encapsulation technology gives dramatic improvements in size, cost and performance compared to other SEM power supply offerings.

This unit provides a highly regulated, low noise, ultrastable Accelerator supply programmable from 0 to -30kV at 170uA, together with Floating Filament and Bias supplies referenced to the Accelerator to control the beam. The unit also includes high voltage outputs to drive the Detector, comprising PMT, Scintillator and Collector grounded outputs.

Programming signals utilize differential analog inputs to minimize external noise and offset voltages effects. A ground referenced emission current monitor and a filament failure signal are provided.

SPECIFICATIONS

Input Voltage:

+24Vdc, ±5% @ 2.5A max.

High Voltage Outputs:

CA11 Mini 75 receptacle from Claymount. Spellman HV offers mating cable assemblies at different lengths (see HOW TO ORDER table below).

- Triode Supply for Thermionic Emission SEM
- High Precision, Low Noise, Ultra Stable
- Over Current/Voltage Protection
- Arc and Short Circuit Protection
- OEM Customization Available
- UL, CE and RoHS Compliant

Scintillator Output:

Custom 'Poke home' receptacle manufactured by Spellman. For mating cables, see HOW TO ORDER information below.

PMT and Collector Outputs:

Industry standard BNC.HT receptacle: Radiall R316 553

Operating: 0°C to +45°C Storage: -20°C to +75°C

Humidity:

0 to 85% RH, non-condensing

Dimensions:

4.13" H x 9.85" W x 7.48" D (105mm x 250mm x 190mm) excluding the top mounting bracket

Weight:

16.5 lbs. (7.5kg)

Regulatory Approvals:

UL recognized component (RC). File number E354595. Compliant to IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. UKCA marked to BS EN 61010-1. RoHS compliant.

(As the unit is designed for incorporation within the users system it is not tested against any specific EMC standards. The user will need to take appropriate EMC precautions when designing the unit in and verify the overall system EMC performance against any relevant standards.)

OUTPUTS SPECIFICATIONS

Output	Accelerator (Internal Supply)	Bias Cancellation (Internal Supply)	Filament	PMT	Scintillator	Collector
Output Voltage	0 to -30kV, referenced to ground	0 to +3.5kV referenced to Accelerator*	-1.936 to +1.936V referenced to Accelerator	0 to -1300V referenced to ground	+8kV to +11kV referenced to ground	30V to 500V referenced to ground
Output current - max	170μΑ	150μΑ	3.87A	1mA (current trip level: 1.2mA)	250μΑ	5mA
Accuracy	±2% or ±20V (whichever is greater)	±10% or ±180V (whichever is greater)	0.1V	±2% or ±1V (whichever is greater)	±2%	±5%
Load Regulation	<100ppm for 0 to 170µA	N/A	<2% for 10% change in load resistance	<100ppm for 0 to 1mA	<500ppm for 0 to 250µA	<5% for 0 to 5 mA
Line Regulation for a ±5% line change	<100ppm	<0.1%	<1%	<100ppm	<500ppm	<5%
Ripple p-p at max output	<20ppm	<5ppm	<0.1%	<200mV	<0.1%	<0.2%
Temperature Coefficient	<100 ppm/°C	<1000 ppm/°C	<300 ppm/°C	<1000 ppm/°C	<100 ppm/°C	<1000 ppm/°C
Stability (1hr warm up)	8ppm/3min	1%/10min	100ppm/10min	200ppm/1h	500ppm/8h	<1500ppm/1h
Rise time (switch on)	1 to 3s (0 to 90%)	<1s (0 to 90%)	250ms (0 to 90%)	<1s (0 to 90%)	<1s (0 to 90%)	<1s (0 to 90%)
Fall time (switch off)	<100s (to < 50V)	<100s (to < 50V)	<0.5s (100% to 10%)	<10s (to < 50V)	<10s (to < 100V)	<10s (to < 50V)

*The positive Bias Cancellation voltage reduces the negative Bias output, allowing the Emission current to flow (see User Guide for more information).



PL1 INPUT POWER CONNECTOR JST MODEL B 5PS-VH

1	PIN	SIGNAL	I/O	SIGNAL PARAMETE	RS REMARKS
ı	1	+24V	Ι	DC24V Input	Pins connected internally
Ì	2	+24V	- 1	DC24V Input	Filis confidenced internally
Ì	3	0V	1	DC24V Common	Ding gappaged internally
Ì	4	0V	I	DC24V Common	Pins connected internally
Ì	5	FG	-	Case ground	Internally connected to 0V

PL2 DIGITAL I/O CONNECTOR **JST MODEL S10B-EH**

PIN	SIGNAL	I/O	SIGNAL PARAMETERS
1	Remote on/off	I	Outputs 1,2 and 3 (Acc., Bias, Fil.) remote on/off. High = off
2	Remote 4 on/off		P.M.T remote on/off. High = off
3	Remote 5 on/off	-	Scintillator remote on/off. High = off
4	Remote 6 on/off		Collector remote on/off. High = off
5	Remote signal gnd	ı	0V connection for remote controls
6	Filament open cct	0	High = failed
7	Filament OC return	0	OV
8	N/C	-	N/C
9	N/C	-	N/C
10	N/C	-	N/C

PL3 ANALOG I/O CONNECTOR JST MODEL S15B-EH

PIN	SIGNAL	I/O	SIGNAL PARAMETERS
1	Fil Prog (+)		0 to 4V differential input =
2	Fil Prog (-)	I	0 to 4V Filament output
3	Bias Cancel Prog (+)	I	0 to 3.5V differential input =
4	Bias Cancel Prog (-)		0 to 3.5kV Bias Cancellation output
5	Acc Prog (+)	I	0 to 6V differential input =
6	Acc Prog (-)	I	0 to -30kV Accelerator output
7	EMS Monitor	0	Emission Current Monitor Output. 0 to 10V = 0 to 200µA
8	EMS Mon 0V	0	Limited to 12V max. ±3% or 0.1V, whichever is greater
9	PMT Prog (+)		0 to 6.5V differential input =
10	PMT Prog (-)		0 to 1300V P.M.T output
11	Scintillator Prog (+)		0 to 5.5V differential input = 0kV to 11kV Scintillator output
12	Scintillator Prog (-)		0kV to 11kV Scintillator output
13	Collector Prog		0 to 5V differential input = 0 to 500V Collector output
14	Collector Prog 0V	Ī	0 to 500V Collector output
15	N/C	-	N/C

HOW TO ORDER


Description	Part Number
EBM-TEG	EBM30N/TEG
Low voltage mating connectors accessory Kit	13802-27
HV Out Cable - 2 meters	HVC30/3SO/1317
HV Out Cable - 3 meters	HVC30/3SO/1314
HV Out Cable - 5 meters	HVC30/3SO/1315
Scintillator Cable - 1 meter	HVC11/1SO/1320
Scintillator Cable - 2 meters	HVC11/1SO/1316

DIMENSIONS: in.[mm]

FRONT VIEW



TOP VIEW



SIDE VIEW



Note: An accessory kit which contains the mating housings and crimps for the low voltage connectors is available to order free of charge. See HOW TO ORDER table.











The EBM-TEGR is an integral solution that provides the high voltage required by Thermionic Emission Scanning Electron Microscope (SEM) in a 19" rack mountable chassis.

Spellman's proprietary packaging and encapsulation technology gives dramatic improvements in size, cost and performance compared to other SEM power supply offerings.

This unit provides a highly regulated, low noise, ultra stable Accelerator supply programmable up to -30kV at 400uA. This, together with Floating Filament and Grid supplies referenced to the Accelerator control the beam. The unit also includes high voltage outputs to drive the Detector, comprising PMT, Scintillator and Collector grounded outputs.

Customer control of this integrated EBM-TEGR power supply system is accomplished via RS-232 or the optional RS-485 interface. Five interlocks are provided. The unit is CE and UKCA marked.

SPECIFICATIONS

Input Voltage:

100 to 264 Vac @2A max. 47 to 63Hz

Temperature:

Operating: 10°C to +45°C Storage: -10°C to +70°C

Humidity:

0 to 90% RH, non-condensing

- Triode Supply for Thermionic Emission SEM
- High Precision, Low Noise, Ultra Stable
- Over Current/Voltage, Arc and Short Circuit Protection
- RS-232 or RS-485 Digital Interface
- Free GUI for Testing and Development Work
- OEM Customization Available
- CE, UKCA and RoHS Compliant

Interlocks:

Five interlocks are provided on a 9 pin D connector (see pinout details).

The EHT, Collector, Scintillator and PMT interlocks disable the corresponding outputs when open (the other outputs can be powered up).

The Vacuum interlock disables the gun supplies (EHT and heater) when open.

Front Panel Indicators:

POWER ON: Green LED

INTERLOCKS: Yellow LED indicates that all the interlocks

are closed and the unit is able to generate

high voltage.

HV ON: Yellow LED indicates that the high voltage EHT

(Accelerator) Output is energized.

RS-232/RS-485: Yellow LED indicates when communications

are taking place on the RS-232/RS-485 bus. Red LED indicates that an Error condition

has occurred.

Input Power Connector:

FAULT:

I.E.C. 320 Receptacle with integral fuse

High Voltage Output Connectors:

Grid and Filament: Claymount CA1 type 03 (see drawing)

A mating cable assembly is available (see drawing and How To Order table)

Collector and PMT: BNC HT-MHV Receptacle Radiall R316553000

Scintillator: SHV Receptacle Radiall R317580000

OUTPUTS SPECIFICATIONS

Output	Accelerator (EHT)	Filament	Grid	PMT	Scintillator	Collector
Output Voltage	-100V to -30kV, referenced to ground	5V max, 15W max center tapped to the Accelerator	-35V to -1650V referenced to Accelerator	0V to -1300V referenced to ground	+50V to +11kV referenced to ground	-400V to +400V referenced to ground
Output current - max	400μΑ	5A	400µA	1mA (current trip level: 1.2mA)	200μΑ	4μΑ
Accuracy	±2% or ±30V (whichever is greater)	±5% or ±100mA (whichever is greater)	N/A	±2% or ±1V (whichever is greater)	<1% or ±10V (whichever is greater)	±2% or ±2V (whichever is greater)
Load Regulation	<10ppm for 30µA to 400µA	<5mA for a 0.4Ω to 1Ω change at 3A	N/A	<±100ppm for 0 to 1mA	<100ppm for 10µA to 200µA	<5% for 0 to 5 mA
Line Regulation at full load ±10% line change	<10ppm	<5mA	N/A	<100ppm	<100ppm	<10mV
Ripple p-p at max output	<100mV	1mA at 50Hz 30mV at 100kHz at 3A,1Ω	N/A	<200mV	<100mV	<25mV
Temperature Coefficient	<50 ppm/°C	<300 ppm/°C	N/A	<100 ppm/°C	<250 ppm/°C	<50 ppm/°C
Stability (1hr warm up)	<10 ppm/15min <25 ppm/1h	<2mA/1h	<0.4µA/15min	200 ppm/1h	<1%/1h	<50mV/15min

Protection:

All outputs are protected from arcs in the load and continuous short circuit to ground and between each other.

- If the Beam Energy has more than 4 arcs in a 10 minutes period, unit will disable all outputs and sets all programs to zero.
- In case of an over temperature condition for greater than 100° C for ten seconds all outputs will be disabled.
- Over voltage, over current and internal communication issues are also monitored and trigger fault conditions.
- The unit reports fault or trip conditions through status flags. After a Trip occurs, the unit can be reset through software (digital interface) or power cycle.

Dimensions:

See drawing

Weight:

39.7 lbs. (18kg)

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. UK Conformity Assessed. RoHS Compliant.

INTERLOCKS CONNECTOR 9 PIN D SUB-FEMALE

PIN	SIGNAL	I/O	SIGNAL PARAMETERS
1	OV	-	Ground
2	24V	0	24V Output from unit (connected to pin 6 internally)
3	Collector		Input for collector interlock
4	Scintillator		Input for Scintillator interlock
5	Vacuum	ı	Input for vacuum interlock (connected to pin 8 internally)
6	24V	0	24V output from unit (connected to pin 2 internally)
7	EHT	ı	Input for EHT interlock
8	Vacuum	I	Input for vacuum interlock (connected to pin 5 internally)
9	PMT	1	Input for PMT interlock

DIGITAL COMMUNICATIONS CONNECTOR 9 PIN D SUB-MALE

PIN	RS-232	RS-485	DESCRIPTION
1	-	-	N/C
2	RS-232 RxD	-	RS-232 data receive
3	RS-232 TxD	Z	RS-232 data transmit or RS-485 inverting
4	-	-	N/C
5	GND	GND	Ground
6	-	-	N/C
7	-	Y	RS-485 non-inverting
8	-	-	N/C
9	-	-	N/C


HOW TO ORDER


Description	Part Number
EBM-TEGR	EBM30N12/TEGR
EBM-TEGR with RS-485 option	EBM30N12/TEGR/DCC4
HV Output cable - 4 meters	HVC75/3SO/1282

+1-631-630-3000


e-mail: sales@spellmanhv.com


DIMENSIONS: in.[mm] SIDE VIEW





FRONT VIEW

















Spellman's EBM-FEG Series is an integrated, multiple output high voltage power supply specifically designed to drive Scanning Electron Microscope (SEM) Columns. Spellman's extensive applications knowledge has enabled us to develop a range of technology platforms that can be customized to meet the demanding requirements of SEM.

The main Acceleration Voltage is a high stability 30kV supply, with integrated floating Filament, Extractor and Suppressor outputs required to drive Field Emission, Cold Cathode and Schottky Electron Sources in a compact solution with extenders to mount in a 19" rack. All outputs are offered with ultra-low output ripple, minimal microdischarge, excellent regulation, stability, temperature coefficient and accuracy specifications for unprecedented image quality and resolution. Isolation and control of the respective floating sources is provided via Spellman's proprietary high voltage isolation techniques.

Customer control of this integrated EBM-FEG power supply system is accomplished via a fiber optic RS-232 interface. All high voltage safety interlocks are of a failsafe hardware based design. The unit is UL and CE marked and is designed to be compliant with SEMI standards.

TYPICAL APPLICATIONS

Scanning Electron Microscopes (SEM) Electron Beam Controller

SPECIFICATIONS

Input Voltage:

+24Vdc, ±5% @ 4 amps max. Inrush is <6 amps for 1 second.

Environmental:

Operating Temperature:

+10°C to +45°C ambient for normal operation. The unit will operate from 0°C but will require an extended warm up period.

Storage Temperature:

-20°C to +60°C

Humidity:

0 to 80% RH, non-condensing

2000 meters ASL at full power. For altitudes above 2000 meters the maximum ambient operating temperature is linearly derated by 1.1°C per 300 meter interval.

Mechanical:

The unit is provided with a pair of removable mounting flanges; these allow the unit to mount in a 19" rack system. The unit can be operated in any orientation.

- Integrated Tetrode Supply for Field Emission SEM
- Very Low Ripple and Ultra Stable Outputs
- Robust Arc and Short Circuit Protection
- Designed to Minimize Micro-discharge Events
- Optically Isolated Digital Interface
- Free GUI for Testing and Development Work
- UL Recognized, CE Marked & Designed to Meet SEMI S2

Vacuum Interlock:

The vacuum interlock is an optical interlock which is made when light is present on the fiber. When no light is present the interlock is broken and the unit disables all of the outputs.

Front Panel Indicators:

Power On:

An illuminated green LED indicates that +24V power is present and it will be illuminated over the range 22.8 to 25.2 volts and will flash with a 1 second period when out of range.

Vacuum Interlock:

An illuminated yellow LED indicates that the vacuum interlock is closed. The vacuum interlock LED must be illuminated for the unit to be able to generate high voltage.

Test GUI:

A product GUI can be provided free of charge for customer testing and development work.

Protection:

All outputs are protected from arcs in the load and continuous short circuit to ground and between each other.

All low voltage inputs are protected against over voltages of ±30 volts. The power input is protected against over voltage and reversed connection.

If the Beam Energy has more than 'A' arcs in a nominal 'B' time (sec) period the unit will disable all outputs and sets all programs to zero. If there are less than 'A' arcs the unit will continue to operate. The default values are A = 8 and B = 10. Both 'A' and 'B' are settable via optical bus commands and GUI.

In case of an over temperature condition for greater than ten seconds all outputs will be disabled.

The unit reports fault or trip conditions through status flags.

After a Trip occurs (arc, over current, over voltage, temperature etc.), the unit can be reset through software (optical bus command) or power cycle.

Weight:

44 lbs. (20kg)

Regulatory Approvals:

UL recognized component (RC). File number E354595. Compliant to IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1. CE marked to EN 61010-1. UKCA marked to BS EN 61010-1. RoHS compliant.

As the unit is designed for incorporation within the user's system it is not tested against any specific EMC standards. The user will need to take appropriate EMC precautions when designing the unit in and verify the overall system EMC performance against any relevant standards.



OUTPUTS SPECIFICATIONS

UTPUTS SPECIFICATIONS					
OUTPUT	Beam Energy	Filament	Suppressor	Extractor	
Output Voltage	-20V to -30kV referenced to ground. Amplitude does not exceed 35kV and is <60 V when output disabled. Conditioning voltage -32.5kV at zero load current.	nominal 1.8V max 3V referenced to Beam Energy	-100V to -1kV referenced to Beam Energy	100V to 10kV referenced to Beam Energy	
Output current - max	200μΑ	3A	100μΑ	700μΑ	
Current Trip	250µA ±10% for 1s Output disabled and program set to zero	>3.15A for 10s. All outputs disabled and programs set to zero	>100mA ±10% for 5s. All outputs disabled and programs set to zero	Programmable 0 to 735µA. All outputs disabled and programs set to zero	
Accuracy	<1% or ±10V (whichever is greater)	±5mA (between 2A to 3A)	<2% or ±6V (whichever is greater)	<1% or ±20V (whichever is greater)	
Linearity	<± 25V	±10mA (between 0.5A to 3A)	±5V	±20V	
Load Regulation	<±100mV for 30μA to 200μA	<5mA for 0.4Ω to 1Ω change at 3A	<120mV for 10μA to 100μA	<100mV at 40μA 0.1Hz to 20MHz, <1V at 10 - 700μA	
Line Regulation for a ± 5% line change	<10ppm	<1mA	<5ppm	<5ppm	
Ripple p-p at max. output	<50mVp-p 0.1Hz to 20MHz	<1mAp-p 20Hz to 10kHz <30mVp-p at approx 100kHz	<20mVp-p at 0.1Hz to 20MHz	<100mV p-p at 0.1Hz to 20MHz	
Temperature Coefficient	<5 ppm/°C from 20°C to 30°C, <10 ppm/°C otherwise	<50 ppm/°C	<50 ppm/°C	<25 ppm/°C	
Stability (1h warm up)	200mV/15min	<0.5mA/60min	<0.3V/15min	<0.3V/15min	
Ramp Rate Programable Range	50 to 5000 V/s	1 to 3000 mA/s	10 to 1000 V/s	10 to 1000 V/s	
Voltage Monitor Resolution	0.5V	2.5mV	0.25V	2.5V	
Voltage Monitor Accuracy	±2% or ±10V	±5% or ±25mV	±2% or ±250mV	±1% or ±20V	
Current Monitor Resolution	100nA	1mA	0.25μΑ	0.25μΑ	
Current Monitor Accuracy	±2% or ±1µA	±10mA	±10%	±2% or ±2µA	
Additional info	Programmable Wobble feature. Sinusoidal, amplitude up to 5% Beam Energy voltage, 0.5Hz to 1.6Hz	Open Circuit detection: Vout > 5.2 ± 0.1V All outputs disabled and programs set to zero. Filament supply optimized for a nominal load resistance of 0.6Ω			

PAGE 3 OF 3

INPUT POWER CONNECTOR UNIVERSAL MATE-N-LOK 1-350942-0

PIN	SIGNAL	PARAMETER
1	+24Vdc	+24Vdc @ 4A
2	Power Ground	Power Ground

VACUUM INTERLOCK CONNECTOR

The vacuum interlock connector is a dual channel Avago HFBR- 2524z/1524z connector.

OPTICAL COMMUNICATIONS CONNECTOR

The fiber optics communications connector is a dual channel Avago HFBR- 2524z/1524z connector. A suitable Serial to optical communication kit including fiber optic cables, optic to RS-232 converter, RS-232 extension lead and RS-232 to USB cable is available. Optical to RS-232 converter can be ordered separately. See HOW TO ORDER table.

HIGH VOLTAGE OUTPUT CONNECTOR

The unit uses a custom high voltage 4 pole receptacle. A mating cable assembly in different lengths is available. See HOW TO ORDER table.

HOW TO ORDER


Description	Part Number
EBM-FEG	EBM30N6/FEG
Optical to RS-232 Communication Kit	EBMKFEG
Optical to RS-232 Converter (included in the above kit)	21777
HV Output Cable - 1.5 meters	HVC30/4ISO/1201
HV Output Cable - 2.8 meters	HVC30/4ISO/1197

DIMENSIONS: in.[mm]


REAR VIEW



TOP VIEW



FRONT VIEW









Spellman's EBM60-FEG Series is an integrated, multiple high voltage power supply specifically designed to drive Field Emission Scanning Electron Microscope (SEM) columns. Spellman's extensive applications knowledge has enabled us to develop a range of technology platforms that can be customized to meet the demanding requirements of SEM.

The main Acceleration Voltage is a high stability 60kV supply, with integrated floating Filament, Extractor and Suppressor outputs required to drive Field Emission, Cold Cathode and Schottky Electron Sources. All outputs are offered with ultra-low output ripple, minimal micro-discharge, excellent regulation, stability, temperature coefficient and accuracy specifications for unprecedented image quality and resolution. Isolation and control of the respective floating sources is provided via Spellman's proprietary high voltage isolation techniques.

Customer control of this integrated EBM60-FEG power supply system is accomplished via an RS-232 interface. The unit is CE and UKCA marked.

TYPICAL APPLICATIONS

Scanning Electron Microscopes (SEM) Electron Beam Controller

SPECIFICATIONS

Input Voltage:

100 to 240 Vac ±10% @1A max. 50 to 60 Hz ±5%

Environmental:

Operating Temperature:

+10°C to +45°C ambient for normal operation. The unit will operate from 0°C but will require an extended warm up period.

Storage Temperature:

-25°C to +60°C

Humidity:

0 to 85% RH, non-condensing

Mechanical:

The unit can be operated in any orientation.



- Very Low Ripple and Ultra Stable Outputs
- Robust Arc and Short Circuit Protection
- Designed to Minimize Micro-discharge Events
- RS-232 Digital Interface
- Free GUI for Testing and Development Work
- CE, UKCA and RoHS Marked

Front Panel Indicators:

- -Power On
- -Interlocks enabled (both interlocks are closed)
- -HV On (any of the HV outputs are enabled)
- -Warning (any of the internal warning levels exceeded)
- -Operating (unit running correctly)
- -Trip
- -Fault
- -Serial Bus (communication taking place)

Status Outputs:

The unit has three digital outputs to indicate status conditions through TTL signals (high when the corresponding LED is illuminated)

- 1- HV on
- 2- Fault
- 3- Unit Operating

Test GUI:

A product GUI can be provided free of charge for customer testing and development work.

Interlocks:

Two separate interlocks are provided:

Gun interlock: 24V output provided for an external

volt free interlock

HV cable interlock: interlock plate mounted over the

HV connector

If any interlock is not present: all high voltage supplies including filament are shut down, however communication over the serial interfaces remains operational.

Protection:

-All outputs are protected from arcs in the load (repetition rate up to 0.1 Hz) and continuous short circuit.

- -The unit monitors the temperature of the main power semiconductors and shutdown the relevant outputs if a temperature become excessive.
- -All low voltage inputs are protected against over voltages of ± 30 Volts.
- -The power input is protected against over voltage and reversed connection.

Weight:

86 lbs. (39kg)

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. UK Conformity Assessed. RoHS Compliant.



245

OUTPUTS SPECIFICATIONS

OUTPUT	Accelerator	Filament	Suppressor	Extractor
Output Voltage	-200V to -60kV referenced to ground	nominal 1V max 1.5V referenced to Accelerator	-10V to -1kV referenced to Beam Energy	200V to 5kV referenced to Beam Energy
Output current - max	300μΑ	3A	100μΑ	500μA
Current Trip	350μA ±10% Output disabled and program set to zero	>3.15A for 10s. All outputs disabled and programs set to zero	>120mA ±10% All outputs disabled and programs set to zero	600μA ±10% All outputs disabled and programs set to zero
Accuracy	±5V	±5mA (between 2A to 3A)	±14V	±2%
Linearity	< ± 5V between 500V and 60kV	±10mA	±14V	±2V
Load Regulation	<±10ppm for 30μA to 400μA	<5mA for 10% in load resistance	<± 100ppm for 10μA to 90μA	<± 100ppm for 10μA to 500μA
Line Regulation for a ± 10% line change	<±10ppm	<1mA	<±10ppm	<±10ppm
Ripple p-p at max. output	<120mVp-p at 1Hz to 1MHz	<40mAp-p 20Hz to 10kHz across 0.5Ω @ 2.5A	<10mVp-p at 1Hz to 1MHz	<50mV p-p at 1Hz to 1MHz
Temperature Coefficient	<20 ppm/°C at 60kV after 1h warm up	<20 ppm/°C	<50 ppm/°C	<25 ppm/°C
Stability (1h warm up)	<15ppm or 40mV (whichever is greater) /10min	<30ppm/10min and 5mA/3 months @ 2.5A	<100ppm/10min	<20ppm/10min
Voltage Monitor Resolution	1.14V	62.5µV	19mV	97mV
Voltage Monitor Accuracy	±1% or ±50V	±5% or ±25mV	±0.5% or ±0.5V	±0.5% or ±3V
Current Monitor Resolution	5.7nA	62.5µA	2.3nA	11nA
Current Monitor Accuracy	±1μA	±1% or ±5mA	±2µA	±0.5% or ±2µA
Additional info	Programmable Wobble feature. Sinusoidal, 0V to 500V p-p, 0.2Hz to 2Hz	Open Circuit detection: Vout > 3.1 ± 0.1V All outputs disabled and programs set to zero. Optimized for a nominal load resistance of 0.5Ω		

PAGE 3 OF 3

GUN INTERLOCK CONNECTOR 3 PIN MATE-N-LOK (TE CONN. P/N: 1-350943-0)

PIN	SIGNAL	VO	PARAMETER
1	Interlock -	1	24V Return
2	N/C	-	
3	Interlock +	0	24V Drive

STATUS OUTPUT CONNECTOR 9 PIN FEMALE D

PIN	SIGNAL	I/O	PARAMETER
1	HV ON	0	High voltage status, logic high* when any of the HV outputs is enabled
2	HV ON GND	-	High voltage status return
3	Fault	0	Fault status, logic high* when any internal fault is detected
4	Fault GND	-	Fault status return
5	UO	0	Unit Operating status, logic high* when the unit is running correctly
6	UO GND	-	Unit Operating status return
7	N/C	-	No connection
8	N/C	-	No connection
9	N/C	-	No connection

^{*}TTL Signal: High > 2.7V, Low < 0.8V

RS-232 COMMUNICATION CONNECTOR 9 PIN MALE D


PIN	SIGNAL	I/O	PARAMETER
1	N/C	-	No connection
2	RS232 RXD		RS-232 receive data
3	RS232 TXD	0	RS-232 transmit data
4	N/C	-	No connection
5	GND	-	Ground
6	N/C	-	No connection
7	N/C	-	No connection
8	N/C	-	No connection
9	N/C	-	No connection

INPUT POWER CONNECTOR

I.E.C. 320 Receptacle with integral fuse

HIGH VOLTAGE OUTPUT CONNECTOR

The unit uses a Claymount CA4 75kV 4 pin receptacle. Mating cable assemblies in different lengths are available. See HOW TO ORDER table.





+1-631-630-3000

DIMENSIONS: in.[mm]

SIDE VIEW 4.37 [111.0] 1.28 [32.5] 5.91 [150] 1.97 [50]

TOP VIEW 14.85 [377] - 1.00 [25.5] 15.76 [400] 19.70 [500] 16.03 [407] - 0.41 [10.5]

REAR VIEW



HOW TO ORDER

Description	Part Number
EBM60-FEG	EBM60N18/FEG
HV Output Cable - 3 meters	HVC75/4SO/1365
HV Output Cable - 4 meters	HVC75/4SO/1366



FAX: +1-631-435-1620



- Electron Beam High Voltage Power Supply
- 100kV Output Capability
- Low/High 10μA/100μA Output Current Selection
- Less than 75mV of Ripple
- Excellent Regulation and Stability Performance
- Oil Free/Solid Encapsulated Design

The Bertan VS100 high voltage power supply was specifically designed for precision electron beam applications like semiconductor nano-lithography, micro-optics and development mask work. Its ultra low ripple and excellent stability specifications make it ideal for use in these demanding applications. A switch selectable low and high output current range is featured.

The solid encapsulated high voltage section eliminates any user maintenance issues, while isolating the components from environmental variables. The unit is fully overload, arc and short circuit protected. Remote control programming and monitoring capability is provided. A second high voltage monitor, separate from the control electronics is provided. This allows accurate passive measurement of the high voltage output.

TYPICAL APPLICATIONS

Micro-Optics Semiconductor lithography Development mask work

SPECIFICATIONS

Input Voltage:

220Vac, ±10%, single phase 50/60 Hertz

Output Voltage:

0 to 100kV, negative polarity. Externally switch selectable to 105kV, ±500 volts

Output Current:

0-10µA, low range 0-100µA, high range Switch selectable

Line Regulation:

±0.001% of rated voltage over specified input voltage range

Load Regulation:

≤20V for a current change of 25µA to 60µA and 60µA to 25µA

Ripple:

≤75mV peak to peak

Partial High Voltage Discharge:

less than 200mV

Stability:

0.001% per 8 hours after a 6 hour warm up, for a temperature of 20°C ±0.2°C

Temperature Coefficient:

50ppm per degree C over a 10°C to 40°C range

Environmental:

Operating Temperature: 0 to 40 degrees C Storage Temperature: -40 to 85 degrees C Humidity: 10 to 90% RH, non condensing

Cooling:

Forced Air-control chassis; Convection Cooled- high voltage chassis

Front Panel:

Power ON/OFF switch HV ON/OFF switch HV ON/OFF indicator Analog output voltage meter

Dimensions:

Control Chassis: 5.25" H X 19" W X 15.3" D (13.3cm X 48.3cm X 38.4cm) HV Chassis: 10.25"H X 19"W X 27"D (26.7cm X 48.3cm X 55.9 cm)

Weight:

Control Chassis: 20 pounds (9kg) HV Chassis: 116 pounds (50kg)

Interface Connector:

19 pin Burndy GOB1619SNE (mating connector provided)

AC Input Connector:

3 pin IEC320 input socket

Output HV Connector:

Claymount 2050-073

Output HV Cable:

Corporate Headquarters

Hauppauge, New York USA

Detachable at rear panel, cable not provided.




REMOTE INTERFACE CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
Α	-5V Reference	-5.0 volts @ 10mA output
В	Voltage Programming	0 to -5v = 0 to 100% rated output, $Zin = 100K\Omega$
С	Spare	N/C
D	Spare	N/C
Е	Monitor Common	Ground
F	HV Status	TTL High = HV OFF, TTL Low = HV ON
G	+5V	5 volts @ 250mA output
Н	Interlock	Ground or TTL low to enable interlock
J	Program Common	Ground
K	Spare	N/C
L	Spare	N/C
М	Spare	N/C
Ν	Spare	N/C
Р	Voltage Monitor	0 to -5V = 0 to 100% rated output, Zout = $10K\Omega$
R	Current Monitor	0 to -5V = 0 to 100% rated output, Zout = $10K\Omega$
S	Spare	N/C
Т	Spare	N/C
U	Spare	N/C
V	Spare	N/C

DIMENSIONS: in.[mm]


HV CHASSIS


FRONT VIEW



CONTROL CHASSIS

FRONT VIEW







BACK VIEW



TOP VIEW



BACK VIEW





Corporate Headquarters







Spellman's shipborne and land-based power feed equipment (PFE) is used to power submarine fiberoptic cable repeaters for telecommunications shore stations and during cable laying and repair operations. We are the leading supplier of Power Feed Equipment to the Submarine Telecom Industry.

Spellman's Portable PFE (PFE-P) provides the consistent, reliable and safe high voltage power in a compact footprint. The PFE-P incorporates the same advanced digital management system as Spellman's Shipborne PFE (PFE-SB); including voltage and current control, push-button polarity setting, continuous monitoring and alarm reporting from the Main Control Unit (MCU).

The system can be configured with the optional System Management Terminal (SMT) to provide programmable electroding functions, data and event logging and fully adjustable ramp rates, trips and alarms.

The system is powered from a 230Vac single phase mains supply.

SPECIFICATIONS

Input Voltage:

230Vac ±10% 50/60Hz (Single Phase)

Input Current:

50A ac maximum at minimum line voltage

Output Voltage:

0 to 6kV, linearly controllable via the MCU

Output Current:

1A maximum at any output voltage up to 6kV

Reversible by selecting positive or negative mode on the MCU when the HV is disabled.

Voltage and Current Ramp Rates:

See MCU and SMT description.

Voltage Ripple:

<0.1% pk-pk of max output +1Vrms

Typically <0.25% over any 24 hour period with a temperature range of 0°C to 30°C.

- 6kV 1A Portable Power Feed Equipment
- Can be Used as an Emergency or Auxiliary PFE
- Up and Down Ramp Rates for Voltage and Current
- Push-button Electronic Polarity Setting
- Alarm and Trip Functions
- SMT Option Offers Touch Screen Control, Programmable Electroding Function and Data/Event Logging

Voltage Regulation:

Load: 0.05% of full voltage +500mV for full load change Line: +/-0.05% of full voltage +500mV over specified range

Current Regulation:

Load: 0.05% of full current for any voltage change Line: +/-0.05% of full current over specified input range

Temperature Coefficient:

< 100 ppm/°C

Operating Temperature:

0 to +30°C

Humidity:

0% to 90%, non-condensing

Cooling:

Local cooling and/or ventilation needs to be adequate to balance the system heat dissipation of 1.2kW at 6kV, 1A output.

The MCU is equipped with an Emergency Stop Button. Terminals in the rear of the cabinet allow connection of external emergency stop devices.

Clamp/Safety Chassis:

Protects the connected line and PFE-P. A HV dump circuit will quickly and safely discharge the system in the event of emergency shutdown. Front panel mounted lamps indicate if the PFE-P output is safe or energized.

HV Output:

The unit is supplied with 10 meters of RG213/URM67 cable terminated with a 15kV Lemo plug. See HV Output cable detail dwg.

Control:

Manual controls for output voltage and current are provided on the MCU front panel. The PFE-P is capable of operating in either Constant Current or Constant Voltage mode as required by the operator.

Protection:

Over-voltage and Over-current protection levels are settable on the MCU. In the event of a cooling fan failure, the internal temperature limit ensures a safe system shutdown.

Regulatory Approvals:

RoHS compliant. Designed to meet IEC/UL 61010-1 safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1.

0.000

0.000

0.000



Main Control Unit (MCU):

The system can be controlled manually using the MCU front panel controls.



- 4.2" LCD display
- Full output control and monitoring including polarity reversal
- 4mm socket monitor points for voltage and current
- · Front panel controls for voltage and current
- Ramp rates available:
 Default: 60kV/min 6A/min
 Slow: 500V/min 0.2A/min
- Over volts/current trips
- HV ON and Alarm outputs provided for customer installation of warning lights and alarms

Interlock System:

Full protection for user and connected equipment. All PFE-P access panels and patch panel connections are interlocked. External connection terminals are provided to allow connection to CTCs, associated equipment or external E-Stop devices.

OPTIONS

Cable Termination Cubicle (CTC12/377)

Facility to safely accommodate half joints and bare cables for installation and repairs. The CTC provides a safe, interlocked enclosure for connection of the PFE HV to the cable conductors. 2 clamps and strain relief allow the fiber core to be separated and safely routed out of the box to external optical equipment.




System Management Terminal (SMT):

The optional SMT is an advanced touchscreen control and monitoring system which can be installed on top of the PFE or remotely up to 80m from the PFE.

- Full output control and monitoring
- Fully adjustable ramp rates in current or voltage control: 10V-10kV/min and 10mA-10A/min
- User settable over/under voltage and current trips and alarms
- Output voltage and current logging
- Event logging
- Programmable electroding (tone generator 10-40Hz provided)


Typical System Management Screens:






DIMENSIONS: in.[mm]

FRONT VIEW



HV Output Cable

The unit is supplied with 10 meters of RG213/URM67 cable. Assembly terminated with a 15kV Lemo plug.



PAGE 1 OF 2



- Full Array of Dry Contact Closures Available for Remote Station Alarm Monitoring
- Fully-Programmable Electronic Test Load Capable of Dissipating 5kW
- Electroding Functions Provided
- Single Cabinet. Rear Door Provided for Safety Interlocking

Spellman High Voltage Electronics, the leading independent supplier of Power Feed Equipment to the Telecom industry, has developed a new generation of Low Voltage Power Feed Equipment, (PFE-LV). This proposed new PFE-LV is targeted at the emerging requirements for shorter submarine cable installations, while addressing underlying markets issues such as lower cost, smaller foot print, and easier operation.

KEY FEATURES

Redundancy is provided for the converters (1+1)

Simplified sliding drawers for PFE open, grounding, test modes

Redundancy is provided for the LCU. In case of failure of LCU, the PFE will continue to operate normally

LCU contains pull-out 17" LCD screen, keyboard, trackball and CPU

Simplified keylock scheme ensures safety of operating personnel

Highly visible Vacuum Fluorescent Display (VFD) on each Converter displays voltage, current and modes of operation

Unique protective "trap door" barrier allows a converter or test load to be replaced safely while the PFE is still powering the cable

SPECIFICATIONS

Output Voltage:

6kV maximum rated continuous operation, 5kV nominal

Output Current:

1.2A maximum rated continuous operation, 1.0A nominal

+1-631-630-3000

Output Power:

5kW for 1+1 redundancy

Input Voltage:

-40.5 VDC to -60 VDC

Programming:

Full-featured programming, monitoring, alarms, diagnostics, and ramping functions provided via LCU module.

Full local and remote monitoring via Ethernet connection.

Current Ripple:

10mA peak to peak of maximum output

Voltage Ripple:

0.2% peak to peak of maximum output

Current Stability:

0.1% (constant load) after a 4 hour warm up

Operating Temperature:

5 to 40°C operating

Storage Temperature:

-40 to +85°C storage

Humidity:

5% to 85%, non-condensing

Cooling:

Forced Air

Dimensions:

86.68"H x 23.64"W x 23.64"D (2200mm x 600mm x 600mm)

Weight:

Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com


FAX: +1-631-435-1620

900 pounds (335.9kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. X2744 is GR-63-CORE, GR-189-CORE, ETSI ETS 300 019, ETS 300 118, ETS 300 127, ETSI EN 300 132-2, ETSI EN 300 386, EN 60950. UL/CUL recognized file E148969 (A5) (X2743, X2744, X2745).







Corporate Headquarters

Hauppauge, New York USA



86.68 [2200]

PAGE 1 OF 2



- 6, 9, 12, 15kV Versions Available, each @ 1.5A
- Full Array of Dry Contact Closures for Remote Station Alarm Monitoring
- Fully-Programmable Electronic Test Load Bay Capable of Dissipating 22.5kW
- Electroding Functions Provided
- 3-Bay Design. Rear Doors Provided for Safety Interlocking
- Built-in Data Logger Functions Capture Data Every 10ms

Spellman High Voltage Electronics, the leading independent supplier of Power Feed Equipment to the Telecom industry, has developed a new generation of High Voltage Power Feed Equipment, (PFE-HV). This PFE-HV is targeted at the emerging requirements for longer submarine cable installations, while addressing underlying issues such as lower cost, smaller foot print, and easier operation.

KEY FEATURES

Redundancy is provided for the converters (n+1)

Simplified sliding drawers for PFE open, grounding, test modes

Redundancy is provided for the LCU. In case of failure of LCU, the PFE will continue to operate normally

LCU contains pull-out 17" LCD screen, keyboard, mouse pad and CPU

Simplified keylock scheme ensures safety of operating personnel

Highly visible Vacuum Fluorescent Display (VFD) on the output module (OMU) and each converter displays voltage, current and modes of operation

Unique protective "trap door" barrier allows a converter to be replaced safely while the PFE is still powering the cable

SPECIFICATIONS

Output Voltage:

18kV maximum rated continuous operation, up to 15kV nominal

Output Current:

1.8A maximum rated continuous operation, 1.5A nominal

Output Power:

Up to 22.5kW for n+1 redundancy

Input Voltage:

-40.5Vdc to -60Vdc

Programming:

Full-featured programming, monitoring, alarms, diagnostics, and ramping functions provided via LCU module.

Monitoring:

Full local and remote monitoring via Ethernet connection.

Current Ripple:

10mA peak to peak of maximum output

Voltage Ripple:

0.2% peak to peak of maximum output

Current Stability:

0.1% (constant load) after a 4 hour warm up

Operating Temperature:

5 to 40°C operating

Storage Temperature:

-40 to +85°C storage

Humidity:

5% to 85%, non-condensing

Cooling:

Forced Air

Dimensions: (per bay)

86.68"H x 23.64"W x 23.64"D (2200mm x 600mm)

Weight: (per bay)


900 pounds (335.9kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. GR-63-CORE, GR-189-CORE, ETSI ETS 300 019, ETS 300 118, ETS 300 127, ETSI EN 300 132-2, ETSI EN 300 386, EN 60950. Safety IEC 60950-1 E148969- (A5) (X4146, X4147, X4148, X4149, X4750)

255





(€

Corporate Headquarters

Hauppauge, New York USA

e-mail: sales@spellmanhv.com

FAX: +1-631-435-1620

+1-631-630-3000







- 6kV to 20kV Versions Available
- Continuously Variable Electronic Test Load Capable of Dissipating 30kW
- Up and Down Ramp Rates for Voltage and Current
- Programmable Electroding Functions Provided
- Electronic Polarity Reversal
- Data and Event Logging Functions
- Alarm and Trip Functions

Spellman High Voltage is the leading independent supplier of Power Feed Equipment to the Telecom industry and most frequently utilized power supplies for shipborne uses. Our Power Feed Equipment (PFE-SB) has been optimized for shipborne use to provide continuous power to a line whilst being laid and is known for its reliability and quality. It is used with repeatered fiber optic cable systems for telecommunications and has been installed on numerous cable laying ships around the world.

It provides all of the features to allow safe, reliable operation with configuration functions to suit all cable installation requirements. The PFE system is designed to provide a well-regulated, low ripple, high voltage supply at varying current requirements.

An advanced digital management system provides output configuration, control, polarity setting, continuous monitoring and alarm reporting from the Main Control Unit (MCU), or the System Management Terminal (SMT).

The Electronic Test Load is an active solid-state design allowing the load to be dynamically varied using a manual front panel control.

The system is powered directly from 3-phase supply without the need for autotransformers.

SPECIFICATIONS

PFE-SB-Input/Output

Model	Output Voltage	Output Current	Input Voltage	Input Current (per phase max)
PFESB6PN12	6kV	2A max		25A
PFESB10PN24	10kV	2.4A max	400Vac 3 phase ±10%	40A
PFESB15PN36	15kV	2.4A max	50/60Hz	60A
PFESB20PN40	20kV	2A max		75A

+1-631-630-3000

Input Wiring:

3Φ + Neutral (Star). For a 3Φ supply without a neutral (delta), a single phase 230Vac 10A supply will be required to power the control modules.

Voltage Ripple:

< 0.3%

Stability:

Typically <0.25% over any 24 hour period with a temperature range of 0°C to 30°C.

Voltage Regulation:

Load: 0.05% of full voltage for full load change Line: +/-0.05% of full voltage +500mV over specified range

Current Regulation:

Load: 0.05% of full current for any voltage change Line: +/-0.05% of full current over specified input range

Temperature Coefficient:

< 100 ppm/°C

Operating Temperature:

0 to +30°C

Storage Temperature:

-10 to +70°C

Humidity:

0% to 90%, non-condensing

FAX: +1-631-435-1620

e-mail: sales@spellmanhv.com

Forced Air. 210 liters/sec (445 cfm) per cabinet, 1500 liters/sec (3180 cfm) for the test load

Regulatory Approvals:

Designed to meet IEC/UL 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use; CAN/CSA-C22.2 No.61010-1.



PAGE 2 OF 4

KEY FEATURES

Clamp/Safety Chassis:

Protects the repeaters/cable and PFE. A HV relay and dump circuit will quickly and safely discharge the system in case of emergency shutdown. A front panel mounted lamp indicates if the PFE output is energized.

Output Control:

Using either the Main Control Unit (MCU) or SMT; the system output can be operated in constant current or constant voltage control and as a feed for a single end, double end or branched line.


0.000

0.000

0.000

System Management Terminal (SMT):


The SMT is an advanced touchscreen control and monitoring system which can be installed within the PFE cabinets or remotely up to 80m from the PFE.





- User settable over/under voltage and current trips and alarms
- · Output voltage and current logging
- Event logging
- Programmable electroding (tone generator 10-40Hz provided)

Typical System Management Screens:



+1-631-630-3000

Main Control Unit (MCU):

The system can be controlled manually using the MCU front panel controls.



- 4.2" LCD display
- Full output control and monitoring including polarity reversal
- Test points for voltage and current
- Front panel controls for voltage and current
- Ramp rates available:
 Default: 60kV/min 6A/min
 Slow: 500V/min 0.2A/min
- Over volts/current trips
- HV and Alarm outputs

Patch Panel:

User configurable interconnects from Converter(s) to Electronic Load or Cable Termination Cubicles (CTC's).

Electronic Load:

Fully isolated and actively adjustable resistance by the user.

Max power: 30kW
Max voltage: ± 15kV @ 2A
Max current: 2.4A @ ±12.5kV

Interlock System:

Full protection for user and connected equipment. All PFE access panels and patch panel connections are interlocked. External connection terminals are provided to allow connection to CTCs, associated equipment or external E-Stop circuits.

Optional Hood (17668-4)

A flange at the rear provides attachment of exhaust ducting, allowing most of the heat dissipated from the system to be transferred outside the immediate environment of the PFE.

Optional Cable Termination Cubicle (CTC12/377)

Facility to safely accommodate half joints and bare cables for installation and repairs. The CTC provides a safe, interlocked enclosure for connection of the PFE HV to the cable conductors.


2 clamps and strain relief allow the fiber core to be separated and safely routed out of the box to external optical equipment.

W 27.26" [692mm] D 10.44" [265mm] H 8.27" [210mm]





PFESB6PN12




PFESB6PN12 Weight

 Cabinet 1
 441lbs.[200kg]

 SMT
 33lbs. [15kg]

 Electronic Load
 364lbs. [165kg]

PFESB10PN24



PFESB10PN24 Weight

 Cabinet 1
 529lbs. [240kg]


 SMT
 33lbs. [15kg]

 Electronic Load
 364lbs. [165kg]






PFESB15PN36



PFESB15PN36 Weight

Cabinet 1 507lbs. [230kg]
Cabinet 2 309lbs. [140kg]
Electronic Load 364lbs. [165kg]

PFESB20PN40



PFESB20PN40 Weight

Cabinet 1 507lbs. [230kg]
Cabinet 2 419lbs. [190kg]
Electronic Load 364lbs. [165kg]

PAGE 1 OF 2



Spellman's new DGM935 high voltage power supply for Image Intensifier applications continues to set the standards for high voltage power conversion technology. The DGM series can be adapted to suit specific requirements with a wide selection of multiple output voltages and power capabilities in a compact package, making it perfect for the OEM user.

Monitoring of all output voltages is possible via local test points. The unit can operate in four modes selectable via three inputs. The output voltages are independently adjustable in each mode by the pre-set potentiometer located on the front of the unit.

TYPICAL APPLICATIONS

Radiology

Cardiology

Neuroradiology

Night Surveillance

Non Destructive X-Ray Inspection

Image Intensifiers

SPECIFICATIONS

Input Voltage:

+24Vdc ±1%

Input Current:

500mA maximum

Output Voltages:

Anode:

Output Voltage: 30kV Output Current: 30µA

Electrode 1:

Output Voltage: 50V to 300V Output Current: 0 to 1µA

Electrode 2:

Output Voltage: 300V to 2kV Output Current: 0 to 1µA

Electrode 3:

Output Voltage: 2kV to 18kV Output Current: 0 to 18µA

- Multiple Outputs
- Simple Interface Via Three Control Inputs
- Pre set Adjustment of Output Voltages in Four Mode Operation

Ripple:

< 0.3%

Temperature Coefficient:

<200ppmK⁻¹

Stability:

<0.3% over 8 hrs

Temperature:

Operating: +5°C to +55°C

Input:

8 pin header

Dimensions:

6.30"H x 5.51"W x 1.93"D (160mm x 140mm x 49mm)

Weight:

2.86 lb. (1.5kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. Compliant to IEC 60601-1. UL/CUL recognized, File E242588. RoHS Compliant.

INPUT/OUTPUT CONNECTORS

Test Point Terminals:

Wire type suitable for clip on probe.

Output Terminals (0V, OVP and GND):

6.3mm Fast-on connector and M4 x 12mm stud

Output Connector Anode:

M14 X 1 thread, 53mm deep x 8.5mm internal diameter.

Output Connector (electrodes 1 & 2):

5/16 x 32 UNF thread, 26.5mm deep x 5mm internal diameter.

Inputs PC and G:

6.3mm Fast-on connector

Note: 0V, OVP and GND are all connected together internally.


All outputs are protected against high voltage breakdown in the user's equipment and short-circuit protected.

PAGE 2 OF 2


DIMENSIONS: in.[mm]

(A) Configuration 5.51 [140.0] 5.98 [152.0] 6.30 [160.0]

FRONT VIEW



SIDE VIEW




INPUT 8 PIN HEADER

PIN	SIGNAL	SIGNAL PARAMETERS
1	24V	Power Input
2	OV	Power Ground
3	OV	Power Ground
4	24V	Linked internally to pin1
5	M2	Mode select input 2
6	M1	Mode select input 1
7	N/C	N/C
8	M3	Mode select input 3


ALTERNATE CONFIGURATIONS AVAILABLE

(Specify at time of order)

(B) Configuration



(C) Configuration











0.15 [4.0]

PAGE 1 OF 2





Spellman's new DGM945 high voltage power supply for Image Intensifier applications continues to set the standards for high voltage power conversion technology.

The DGM945 also has inputs to allow measurement of the photocathode current and getter current. The photocathode measurement has two ranges: sensitive range: 0 to 50nA and a standard range: 0 to 15µA. The sensitive input is used to provide a monitor output with a sensitivity of 0.1V/nA. The getter input allows measurement of the getter current, indicating if the Image Intensifier tube is still holding a good vacuum and is without gases causing ions.

Monitoring of all output voltages is possible via local test points or over the serial interface. The unit can also store up to eight modes of operation. The output voltages are independently adjustable in each mode either by the rotary encoders built into the unit or via the serial interface.

The DGM series can be adapted to suit specific requirements with a wide selection of multiple output voltages and power capabilities in a compact package, making it perfect for the OEM user.

TYPICAL APPLICATIONS

Radiology
Cardiology
Neuroradiology
Night Surveillance
Non Destructive X-Ray Inspection
Image Intensifiers

- Multiple Outputs
- Three Control Inputs
- Three Optical Encoders
- RS-232 Serial Port for Control and Monitoring
- OEM Customization Available

SPECIFICATIONS

Input Voltage:

+24Vdc ±10%

Input Current:

500mA maximum

Programmable Output Voltages:

Anode:

Output Voltage: 30kV

Output Current: 5µA continuous (50µA peak)

Electrode 1:

Output Voltage: 10V to 350V Output Current: 0 to 10µA

Electrode 2:

Output Voltage: 200V to 2kV Output Current: 0 to 10µA

Electrode 3:

Output Voltage: 2kV to 20kV Output Current: 0 to 20µA

Electrode 4:

Output Voltage: 2.7kV Output Current: 0 to 10µA

Ripple:

< 0.3%

Temperature Coefficient:

<200ppmK⁻¹

Stability:

<0.3% over 8 hrs

Temperature:

Operating: +5°C to +55°C

Input Connector:

15 pin male sub D

Dimensions:

5.47"H x 5.67"W x 1.97"D (139mm x 144mm x 50mm)

Weight:

2.86 lb. (1.3kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. Compliant to IEC 60601-1. UL/CUL recognized, File E242588. RoHS Compliant.



PAGE 2 OF 2

INPUT 15 PIN MALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	VO	Signal Ground
2	RxD	RS-232 receive data input
3	TxD	RS-232 transmit data output
4	OV	Signal Ground
5	OV	Signal Ground
6	UC2	Mode select input 2
7	0V	Signal Ground
8	0VP	Power return
9	DTR	RS-232 Data terminal ready output
10	CTS	RS-232 Clear to send input
11	N/C	N/C
12	Ipc	Ipc = 10nA / volt
13	UC3	Mode select input 3
14	UC1	Mode select input 1
15	24V	Power input

INPUT/OUTPUT CONNECTORS

Test Point Terminals:

Copper pad plus 1.1 mm \emptyset pth.

Output Terminals (0V, OVP and GND):

6.3mm Fast-on connector and M4 x 12mm stud

Output Connector Anode:

LGH1

Output Connector (other electrodes):

LGH1/2

Inputs PC and G:


6.3mm Fast-on connector

Note: 0V, OVP and GND are all connected together internally.

All outputs are protected against high voltage breakdown in the user's equipment and short-circuit protected.

DIMENSIONS: in.[mm]


TOP VIEW



FRONT VIEW



SIDE VIEW











Ideal for Electrospinning

- 0-30kV Local or Remote Programming
- 0-300µA Local or Remote Programming
- Polarity Reversible Upon Command in <1 Sec at No Load
- Low Stored Energy, Current Limited Output
- Full Feature Front Panel, Ideal for Laboratory Useage

Spellman's CZE1000R is a full feature rack mountable high voltage power supply ideal for laboratory usage. It's designed to meet the needs of applications requiring a hot switched reversible output voltage. The output polarity can be guickly and safely reversed via a front panel switch.

Both the output voltage and current are fully adjustable from 0 to 30kV and 0 to 300uA via front panel ten turn locking counting dials. Remote control operation is done by 0 to +10Vdc programming signals; either user generated or using the provided +10 Vdc reference and external potentiometers.

Front panel voltage and current meters provide local monitoring. Voltage and current test points are provided such that 0 to 10Vdc corresponds to 0 to 100% rated output.

A two position, normally closed, external interlock is provided for protection of external high voltage accessible areas. If the interlock is opened the high voltage will shut off and fall to zero in less than one second and not be able to be re-energized until the interlock is closed.

Excellent load and line regulation specifications along with outstanding stability and low ripple of the CZE1000R assure a stable high voltage output for consistent process results.

TYPICAL APPLICATIONS

Electrospinning Mass Spectrometry Capillary Electrophoresis Electrostatic Research

OPTIONS

220 220Vac Input Voltage RPO Rear Panel HV Output

SPECIFICATIONS

Input Voltage:

115Vac, ±10%, 50/60Hz

Input Current:

Less than 1 amp

Efficiency:

75% typical

Output Voltage:

0 to 30kV

Polarity:

Auto reversible via front panel switch

Output Current:

0 to 300µA

Power:

9 watts, maximum

Line Regulation:

0.01% for a 10% input voltage change

Load Regulation:

0.01% for a full load change

Ripple:

0.1% Vp-p

Stability:

0.02% per 8 hours (after 1/2 hr warmup)

NL Time Constant:

100ms

Stored Energy:

0.2 Joules at 30kV

Temperature Coefficient:

100ppm/°C

Operating Temperature:

0°C to 40°C

Storage Temperature:

-40°C to 85°C

Humidity:

10% to 85% RH, non condensing

Cooling:

Convection cooled

Dimensions:

5.25"H x 19"W x 17"D (13.3cm x 48.3cm x 43.2cm).

Weight:

22lbs. (10kg)

Interface Connector:

14 pin terminal block

AC Input Connector:

IEC320 connector with 6' (1.83m) cord

HV Output Connector:

Detachable 36" (0.91m) cable provided

Regulatory Approvals:

Designed to meet EEC EMC Directive. Designed to meet EEC Low Voltage Directive.



e-mail: sales@spellmanhv.com

265

PAGE 2 OF 2

DIMENSIONS: in.[mm]

CZE1000R TERMINAL BLOCK 14 PIN

PIN	SIGNAL	PARAMETERS
1	+10Vdc Reference Output	+10Vdc, 4mA maximum
2	Internal Voltage Control	Front Panel Program Voltage (programming potentiometer)
3	Voltage Program Input	0 to 10Vdc = 0 to 100% rated output, Zin =10M Ω
4	Internal Current Control	Front Panel Current Control (programming potentiometer)
5	Current Program Input	0 to 10Vdc = 0 to 100% rated output, Zin =10M Ω
6	Signal Common	Ground
7	Voltage Test Point	0 to 10Vdc = 0 to 100% rated output, Zout =10k Ω , 1%
8	Current Test Point	0 to 10Vdc = 0 to 100% Rated Output, Zout =10kΩ, 1%
9	External Interlock Out	32Vdc @ 2 amps, max, (connect to pin 10 through safety switch)
10	External Interlock In	Return for interlock (connect to pin 9 through safety switch)
11	+10Vdc Reference Output	+10Vdc, 4mA maximum
12	Enable	Open or ground = HV OFF, >3.4Vdc (up to 15Vdc) = HV ON
13	Spare	No Connection
14	Spare	No Connection


Note:

The unit is shipped with the following pins jumpered for front panel operation: 2-3, 4-5, 9-10, 11-12 It is strongly recommended to remove the 9-10 jumper and use a high voltage safety interlock switch.


High Voltage Cable:

A mating high voltage connecter is provide with the unit. Have a spare on hand or replace broken/lost mating high voltage cables by ordering Spellman part number 105719-034

FRONT VIEW



TOP VIEW



BACK VIEW









Spellman's CZE2000 modular high voltage power supply is ideal for OEM usage. It is specifically designed to meet the needs of applications requiring a hot switched reversible output voltage. The output polarity of the unit can be quickly and safely reversed via the Polarity Control Signal provided on the interface connecter.

Both the output voltage and current are fully adjustable via ground referenced remote programming signals such that 0 to 10Vdc corresponds to 0 to 100% rated output voltage and current.

Remote motioning functionality is provided by voltage and current test points such that 0 to 10Vdc corresponds to 0 to 100% rated voltage and current. Additionally remote polarity and mode indicators provide a comprehensive overview of power supply operation.

Excellent load and line regulation specifications along with outstanding stability and low ripple assure a stable high voltage output for consistent process results.

TYPICAL APPLICATIONS

Electrospinning Mass Spectrometry Capillary Electrophoresis Electrostatic Research

SPECIFICATIONS

Input Voltage:

24Vdc, ±10%

Input Current:

Less than 1 amp

Efficiency:

75% typical

Output Voltage:

See selection table

Output Current:

See selection table

Polarity:

Auto reversible via command

Power:

10 watts, maximum

Ideal for Electrospinning

- 0-30kV Remotely Programmable
- 0-300µA Remotely Programmable
- Polarity Reversible Upon Command in <1 Sec at No Load
- Low Stored Energy, Current Limited Output
- Cost Effective Modular Design

Line Regulation:

0.01% for a 10% input voltage change

Load Regulation:

0.01% for a full load change

Ripple:

0.1% Vp-p

Stability:

0.02% per 8 hours (after 1/2 hr warmup)

NL Time Constant:

100ms

Stored Energy:

0.2 Joules at 30kV

Temperature Coefficient:

100ppm/°C

Operating Temperature:

0°C to 40°C

Storage Temperature:

-40°C to 85°C

Humidity:

10% to 85% RH, non condensing

Cooling:

Convection cooled

Dimensions:

3.5"H x 5"W x 10"D (8.9cm x 12.7cm x 25.4cm).

Weight:

6.2lbs. (2.8kg)

Interface Connector:

25 pin male D connector

HV Output Connector:

Detachable 36" (0.91m) cable provided

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E148969. RoHS Compliant.



PAGE 2 OF 2

CZE2000 SELECTION TABLE


	MAXIMUM RATING		MODEL NUMBER
ı	kV	mA	
Γ	5	2.0	CZE5PN2000
Г	10	1.0	CZE10PN2000
	15	0.67	CZE15PN2000
I	20	0.50	CZE20PN2000
ſ	30	0.30	CZE2000


CZE2000 25 PIN MALE D CONNECTOR

PIN	SIGNAL	PARAMETERS
1	+24Vdc Return	Power Return
2	+24Vdc Return	Power Return
3	+24Vdc Return	Power Return
4	HV Enable/Inhibit	Open or <1Vdc = HV OFF, >3.4Vdc (up to 15Vdc) = HV ON
5	Voltage Test Point	0 to 10Vdc = 0 to 100% rated output, Zout =10k Ω , 1%
6	Current Test Point	0 to 10Vdc = 0 to 100% rated output, Zout =10k Ω , 1%
7	Chassis Ground	Ground
8	Remote Voltage Control	0 to 10Vdc = 0 to 100% Rated Output, Zin = $10M\Omega$
9	Remote Current Control	0 to 10Vdc = 0 to 100% Rated Output, Zin = $10M\Omega$
10	+10Vdc Reference Output	+10Vdc, 4mA maximum
11	Signal Return	Signal Return
12	Polarity Control	Open or >3.4Vdc (up to 15Vdc) = Positive Polarity. Grounded or <1Vdc = Negative Polarity
13	Positive Polarity Indicator	+24Vdc sourced through a 100Ω series limiting resistor. +24Vdc = active signal
14 +24Vdc Input Power Input		Power Input
15 +24Vdc Input Power Input		Power Input
16	Chassis Ground	Ground
17	Negative Polarity Indicator	+24Vdc sourced through a 100Ω series limiting resistor. +24Vdc = active signal
through 2.7kΩ resistor with a 4		Open collector pulled up internally to +15Vdc through $2.7k\Omega$ resistor with a 470Ω limiting resistor in series. Transistor OFF = signal active
19	V Mode Indicator	Open collector pulled up internally to +15Vdc through $2.7k\Omega$ resistor with a 470 Ω limiting resistor in series. Transistor OFF = signal active
20	Return Current Test Point	0 to 10Vdc = 0 to 100% rated output current, as measured returned from load. Zout = $10k\Omega$, 1%
21	Load Return	High Voltage Return Point. Required for GFI circuit functionality
22	Ground Fault Indicator	Open collector pulled up internally to +15Vdc through $4.7k\Omega$ resistor with a 470Ω limiting resistor in series. Transistor OFF = signal active
23	Spare	No Connection
24	Spare	No Connection
25	Spare	No Connection

DIMENSIONS: in.[mm]

FRONT VIEW





BOTTOM VIEW $1.42 \pm .02 [36.1]$ $2.50 \pm .03$ [63.5] $6.00 \pm .010$ [152.4] .940 ± .02 [23.9] $3.00 \pm .010 [76.2]$ INTERNAL THREADS 8-32 X .28 DEEP TYP. 4 PL. $.24 \pm .03 [6.09]$



PAGE 1 OF 3



Spellman's CCM1KW capacitor charging module is designed to provide up to 1000 Joules per second at an output voltage up to 4000 Volts. The power factor corrected AC input, small package size and both a comprehensive and minimal analog interface simplifies integrating the CCM1KW into your OEM system design. Available in either positive or negative polarity, the CCM1KW is fully arc, open and short circuit protected. Units can be operated in parallel for applications requiring higher power (see manual for details).

TYPICAL APPLICATIONS

UV light sources for curing and sterilization Industrial and medical laser applications

SPECIFICATIONS

Input Voltage:

90-264 Vac, 50/60 Hertz, power factor corrected input ≥0.98

Input Current:

14 Amps worst case, 1000 Joules per second 7 Amps worst case, 500 Joules per second

Efficiency:

>85%

Output Power:

1000 Joules per second, 500 Joules per second

Output Voltage:

0-1kV, 0-2kV and 0-4kV version available

Output Polarity:

Positive or negative, specify at time of order

Stored Energy:

Less than 0.2 Joules

Pulse to Pulse Repeatability:

±0.2% up to 1kHz

Compact & Lightweight Package

- Universal/Power Factor Corrected Input
- Low Cost Modular OEM Platform
- Advanced Resonant Soft Switching Inverter Topology
- RoHS Compliant
- UL/CUL Recognized

Temperature Coefficient:

≤100ppm per degree C

Fault Diagnostic System:

Over Temperature and Over Voltage Over Voltage Fault is latched requiring AC power recycle to clear.

Over Temperature Fault is latched but can be cleared via inhibit/fault reset line.

Environmental:

Temperature Range:

Operating: 0°C to 40°C Storage: -40°C to 85°C

Humidity:

10% to 90% RH, non-condensing

Cooling:

Forced air

Input Line Connector:

2 position Phoenix MSTB connector, straight and right angle mating connector provided

HV Output Connector:

Standard: Kings/Winchester Electronics SHV 1707-1 Optional: Amphenol MHV UG-931/U

Interface-A Connector:

15 pin D, female

Interface-B Connector:

4 pin male Molex 705530038

Ground Stud:

10-32, nut supplied

Dimensions:

3" H X 6" W X 9" D (76.2mm x 152.4mm x 228.6mm)

Mounting:

M4 screw. Max. depth is 0.188" (4.78mm)

Weight:

6.9lb. (3.13kgs)

Regulatory Approvals:

Compliant to 60601-1-1. Compliant to 60601-1-2. UL/CUL recognized file E242584. RoHS compliant.



PAGE 2 OF 3

AC INPUT-2 POSITION TERMINAL BLOCK

PIN	SIGNAL	SIGNAL PARAMETERS
1	AC Input High/Phase 1	Line Hot/Phase 1
2	AC Input Low/Phase 2	Line Neutral/Phase 2

ANALOG INTERFACE A— 15 PIN FEMALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	Inhibit/Fault Reset	Ground = HV Enable, Open/+15Vdc = HV Inhibit
2	N/C	N/C
3	OverTemp Fault	No OT Fault = +15Vdc @ 3mA, OT Fault = Ground
4	Signal Ground	Signal Ground (optional)*
5	Voltage Program	0 to 10Vdc = 0 to 100% rated output voltage
6	Overvoltage Status	No OVP = +15Vdc @ 3mA, OVP Fault = Ground
7	Peak Hold Monitor	Peak output voltage displayed, 0 to 10Vdc = 0 to 100% rated output voltage with a 5 second time constant
8	Voltage Monitor	0 to 10Vdc = 0 to 100% rated output voltage, ±1%
9	+15Vdc	+15Vdc @ 150mA, maximum**
10	N/C	N/C
11	+15Vdc	+15Vdc @ 150mA, maximum (optional)**
12	Signal Ground	Signal Ground (optional)*
13	End of Charge	Charging = +15Vdc @ 1.5mA, End of Charge = Ground
14	Signal Ground	Signal Ground
15	Signal Ground	Signal Ground

Note: Output status signals are NMOS transistor controlled, 100mA maximum sink current. Actual signals are 5kΩpull ups to the internal +15Vdc logic source.

INTERFACE B-4 PIN MALE D HEADER

	PIN	SIGNAL	SIGNAL PARAMETERS
I	1	Inhibit/Fault Reset	Ground = HV Enable, Open/+15Vdc = HV Inhibit
Ī	2	Signal Ground	Signal Ground
ſ	3	Voltage Program	0 to 10Vdc = 0 to 100% rated output voltage
	4	+15Vdc	+15Vdc @ 150mA, maximum (optional)*


CCM1KW SELECTION TABLE

kV	JOULES/SECOND	MODEL
1	500	CCM1*500
2	500	CCM2*500
4	500	CCM4*500
1	1000	CCM1*1000
2	1000	CCM2*1000
4	1000	CCM4*1000

^{*}Specify P for positive or N for negative

500 J/s units have a single internal fan, 1000 J/s units have both an internal and external fan.

TYPICAL GRAPH FOR CCM1P1000



By utilizing a unique inverter topology, a reduction in peak power is achieved for the same average output power




Straight and right angle AC input mating connectors are provided

OPTION ORDERING INFORMATION

OPTION	OPTION CODE
MHV UG-931/U HV Connector	MVH
Legacy Interface Signals	L

OPTION ORDERING EXAMPLE



^{*}Optional interface signals can be provided to be compatable with other pre-existing legacy interfaces. On standard units these signals are N/C.

^{**+15}Vdc ±10% is provided on the standard unit. Optional +12Vdc ±5%/100mA, maximum can be provided.

PAGE 3 OF 3


500 Joules per second

(unit with internal fan) DIMENSIONS: in.[mm]


REAR VIEW



FRONT VIEW



BOTTOM VIEW



1000 Joules per second

(unit with internal and external fan) DIMENSIONS: in.[mm]


REAR VIEW



FRONT VIEW



BOTTOM VIEW







271





- Compact & Lightweight Package
- Power Factor Corrected Input
- Low Cost Modular OEM Platform
- Rugged IGBT Inverter Design
- Auxiliary +24Vdc @ 2.2 Amp Output Provided

Spellman's CCM capacitor charging module is designed to provide 3100 joules per second at an output voltage up to 4000 Volts. With a power density of 6.6 watts per cubic inch, the CCM packs more than 30% more power into the same volume when compared to other commercially available units. The power factor corrected AC input, small package size and comprehensive analog interface simplifies integrating the CCM into your OEM system design. Available in either positive or negative polarity, the CCM is fully arc, open and short circuit protected.

TYPICAL APPLICATIONS

UV light sources for curing and sterilization Industrial and medical laser applications ICP-MS applications

SPECIFICATIONS

Input Voltage:

Power factor corrected input ≥0.98 180-264Vac @ 20.3A, 47-63Hz, fused via externally accessible fuses

Efficiency:

>85%

Output Power:

3100 Joules per second, average

Output Voltage:

4000 Volts, maximum

Output Polarity:

Positive

Pulse to Pulse Repeatability:

±0.6% up to 120Hz

Temperature Coefficient:

≤100ppm per degree C

Fault Diagnostic System:

Over Temperature, Over Voltage and Open Load sensing

Environmental:

Temperature Range:
Operating: 0°C to 40°C
Storage: -40°C to 85°C
Humidity:
10% to 90% RH, non-condensing

Cooling:

Forced air

Ground Stud:

M6 X10mm, M6 nut supplied

Input Line Connector:

2 position Phoenix HDFK4 connector

HV Output Connector:

Kings KV-79-15, Bulkhead mounted

+24Vdc Output Connector:

AMP #1-350942-0

Dimensions:

5.81" H X 5.8" W X 14" D (148mm x 147mm x 356mm)

Weight:

14.5lb. (6.6kgs)

Regulatory Approvals:

Compliant to the EEC EMC directive. Compliant to EEC low voltage directive.



PAGE 2 OF 2

AUXILIARY +24VDC CONNECTOR J2 2 POSITION AMP CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	+24Vdc	+24Vdc @ 2.2 amps
2	Ground	Ground

CCM ANALOG INTERFACE-J1 15 PIN FEMALE D CONNECTOR

PIN	SIGNAL	SIGNAL PARAMETERS
1	Inhibit	Ground = HV ON, High = HV OFF
2	Temperature Fault	Fault = OV; no fault = +15Vdc through 6.8kΩ
3	General Fault	Fault = OV; no fault = +15Vdc through 6.8kΩ
4	HV ON Indicator	Ground = HV ON, +15Vdc = HV OFF +15Vdc through 6.8kΩ
5	Voltage Program	0 to 10Vdc = 0 to 100% Rated Output
6	Open Circuit Detector	Fault = OV; no fault = +15Vdc through 6.8kΩ
7	Peak Voltage Monitor	0 to 10Vdc = 0 to 100% Rated Output held for 10 seconds at peak level
8	Voltage Monitor	0 to 10Vdc = 0 to 100% Rated Output, Instantaneous output
9	+15Vdc Output	+15Vdc @ 150ma output, maximum
10	N/C	N/C
11	+15Vdc Output	+15Vdc @ 150ma output, maximum
12	+15Vdc Output	+15Vdc @ 150ma output, maximum
13	End of charge Indicator	Ground = End of Charge, High Impedance = Charging
14	Ground	Ground
15	Ground	Ground


How to Order:	
Standard:	PART NO.: CCM4P3100

DIMENSIONS: in.[mm]

FRONT VIEW



TOP VIEW



BACK VIEW



((

Corporate Headquarters

Hauppauge, New York USA









Spellman's new EVA Series is specifically designed for demanding electron beam coating applications. A full featured front panel provides local control, while an extensive analog interface allows remote capability. The included Ethernet and RS-232 digital interfaces simplify integrating the EVA into your system design.

The EVA's robust IGBT inverter design is inherently fault tolerant. The proprietary low capacitance, low stored energy high voltage output section is ideal for dynamic load and fault conditions encountered in coating applications. Fast arc recovery times (<2ms) minimize process interruptions. Many operational parameters can be configured by the user to suit their particular requirements via the provided graphical user interface (GUI).

An optional filament gun supply is available. The EVA can support one, two or three filament gun supply channels providing unprecedented flexibility and cost effectiveness.



HARDWARE BASED OPTIONS

3PH	180-264Vac Three Phase Input
1PH	180-264Vac Single Phase Input
	(01.141.0, 01.141.5.51.1)

(3kW & 6kW only)

400VAC 360-528Vac, Three Phase Input

(6kW & 12kW only)

LL(X) High Voltage Cable Length

HV2 Two High Voltage Output Connectors HV3 Three High Voltage Output Connectors FIL1 Filament Gun Supply—One Channel Filament Gun Supply—Two Channels FIL2 FIL3 Filament Gun Supply—Three Channels

HPF 50 Amp Filament Supply

SOFTWARE CONFIGURABLE FEATURES

Adjustable Overload Trip

Arc Trip Count Arc Quench Time Arc Reramp Time Arc Window Time



- Specially Designed for E Beam Coating Applications 3kW. 6kW and 12kW Power Levels
- Remote Analog and Ethernet/RS-232 Interface
- Arc and Short Circuit Protected, Fast Arc Recovery
- User Configurable Dynamic Arc Intervention
- Optional Filament Gun Supply (up to 3 channels)
- OEM Customization Available

3/6/12KW HV SPECIFICATIONS

Input Voltage: (must be specified at time of order)

180-264Vac, 50/60Hz, three phase, Option 3PH:

90% efficiency, 0.85 power factor

180-264Vac 50/60Hz, single phase, 90% Option 1PH:

efficiency, 0.65 power factor (3kW & 6kW only)

Option 400VAC: 360-528Vac 50/60Hz, three phase, 90% efficiency, 0.85 power factor (6kW & 12kW only)

Input Current:

Option 3PH: 180-264Vac, 50/60Hz, three phase

> 3kW—13 amps, maximum 6kW-25 amps, maximum 12kW-50 amps, maximum

180-264Vac, 50/60Hz, single phase Option 1PH:

> 3kW-29 amps, maximum 6kW-57 amps, maximum

Option 400VAC: 360-528Vac, 50/60 Hz, three phase,

6kW—13 amps, maximum 12kW-25 amps, maximum

Output Voltage:

5kV @ 600mA, negative polarity. 3kW maximum. 10kV @ 600mA, negative polarity. 6kW maximum. 10kV @ 1200mA, negative polarity. 12kW maximum.

Local Output Controls:

Voltage is continuously adjustable over entire range via a 10 turn potentiometer.

Voltage Regulation:

Load: 0.05% of full voltage +500mV for full load change. 0.05% of full voltage +500mV over specified input range. Line:

Ripple:

<3% Vrms

Stability:

0.02%hr. after 1 hour warm-up.

Temperature Coefficient:

100ppm/°C.

Environmental:

Temperature Range: Operating: 0°C to 40°C Storage: -40°C to 85°C

Humidity:

10% to 90% RH, non-condensing.

Coolina:

Forced air; inlet through side panels, outlet at rear panel

Metering:

Front panel digital voltage and current meters, 3.5 digit, accurate to within 1%.





3/6/12KW HV SPECIFICATIONS

System Status Display:

"Dead Front" type indicators provide status of up to 12 system parameters including voltage regulation, fault conditions and

Input Power Connector:

A 6 foot (1.8 meter) long captive line cord will be provided.

Analog Interface Connector:

50 pin female D connector

High Voltage Output Cable:

10 ft (3.05m) shielded high voltage cable, removable at rear panel.

Dimensions:

3kW/6kW Units:

5.25"(3U)H x 19" W x 21" D (133mm x 482mm x 533mm) 12kW Units:

10.5"(6U)H x 19" W x 21" D (266mm x 482mm x 533mm)

Weight:

3kW/6kW Units: 46 pounds (20.87kg) 12kW Units: 90 pounds (40.82kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. UL/CUL recognized file E227588. RoHS compliant.

Digital Interface

The EVA features a standard RS-232 and Ethernet digital interface, simplifying power supply communication requirements saving the user time and money, while enhancing functionality and overall capability. Spellman provides a GUI allowing customization of operational features while also providing basic power supply functionality and control via a sample simulated front panel.

Arc Intervention

Spellman's EVA power supplies sense arc events via a fast acting current sense transformer. The arc intervention circuitry prevents power supply damage from continuous, long term arcing. Customers can change arc intervention parameters (Arc Count, Arc Quench, Reramp Time, and Window Time) within preset limits via the provided GUI. Customized units can be configured for unique arc prone environments, contact Spellman for details.

Additional High Voltage Output Connectors

Spellman's EVA is designed to provide 1, 2 or 3 parallel configured high voltage output connectors. The standard unit provides one high voltage output connector. If you intend to use the EVA in a multi channel application but want to utilize your own filament power supply, this factory installed option provides the additional high voltage connections required. Hardware Option HV2 provides two high voltage output connectors, while Hardware Option HV3 provides three high voltage output connectors.

Optional Beam Controller (Filament Power Supply) and Gun Output Box



Multiple beam control units can be provided, allowing 1, 2 or 3 separate electron guns to be independently operated.

Each beam control unit consists of a beam controller and a gun output box. The beam controller is a 1U rack-mounted chassis containing the filament power, control and emission regulation circuitry. The gun output box contains the high frequency filament transformer which is referenced to the high voltage output potential. This box should be mounted close to the electron gun to minimize the length of the high current filament connections. The box also contains electron gun emission current monitoring circuitry and provides a feedback signal used to regulate the electron gun emission current.

Each beam control channel, if operated alone, can utilize 0 to 100% of the rated emission current capacity. When two or three beam control channels are used at the same time, the total system emission current capacity remains the same. Individual channel programming must be done such that the total current does not exceed the system's total emission current available.

BEAM CONTROLLER SPECIFICATIONS

Input Voltage:

180-264 Vac, 50/60Hz, single phase, 7.5 amps maximum

Output Voltage/Current:

0-12Vrms at ≈ 30kHz, 0-35 amps. An optional 50 amp filament (HPF) is available.

Meterina:

Corporate Headquarters

Front panel digital filament current and emission current meters, 3.5 digit, accurate to within 1%.

System Status Display:

"Dead Front" type indicators provide status of up to 12 system operations including voltage regulation, fault conditions and circuit control.

Input Power Connector:

A 6 foot (1.8 m) long IEC320 Cord Set will be provided.



PAGE 3 OF 7

BEAM CONTROLLER SPECIFICATIONS

Analog Interface Connector:

Male 25 pin D connector

Filament Output Connections: (gun drive cable)

The secondary leads of the filament power transformer exiting the gun output box are 36" (91.44cm) long. The cover of this box is interlocked for safety purposes.

Environmental:

Temperature Range: Operating: 0°C to 40°C

Storage: -40°C to 85°C

Humidity:

10% to 90% RH, non-condensing.

Cooling:

Forced air; inlet through side panels, outlet at rear panel.

Dimensions:

Beam Controller:

1.75"H (1U) x 15" W x 19"D (44.5 x 381 X 482.6mm)

Gun Output Box:

4.06"H x 6.13"W x 11"D (103.2 x 155.7 x 279.4mm)

Weight:

Beam Controller:

18 pounds (8.1kg)

Gun Output Box:

6 pounds (2.7kg)

Emission current is programmed locally (front panel adjustment) or remotely (0-10Vdc = 0-100% of rated current) via each beam controller. Filament Limit Set Point, Filament PreHeat Set Point, and Automatic. Filament PreHeat functionality are provided.

EVA MODEL CONFIGURATION

Ordering:


EVA5N3/1PH 3 kilowatt unit, single phase EVA10N6/3PH 6 kilowatt unit, three phase EVA10N12/400VAC 12 kilowatt unit, 360-528Vac

Note: Input voltage must be specified at time of order. EVA model number must contain input voltage option code to be valid.

Sample Options:

ÉVA10N6/1PH/HV2 Single Phase Input & 2 HV Connectors EVA10N12/400VAC/FIL3 360-528Vac Input & 3 Gun Supplies

TYPICAL EVA OPERATING SETUP



The signal cable connecting the high voltage power supply to the beam controller is 39.4" (1m) long. A captive but field replacable 10 foot (3.05m) long high voltage cable is provided to connect each beam control output box to the high voltage power supply.



PAGE 4 OF 7

HV POWER SUPPLY INTERFACE— 50 PIN FEMALE D CONNECTOR

DIN	SIGNAL	PARAMETERS
1	Power Supply Common	Power Supply Ground
2	Reset/HV Inhibit	Normally open, Low = Reset/Inhibit
3	External Interlock	+24Vdc @ open, <25mA @ closed
4	External Interlock Return	Return for External Interlock
5	mA Test Point	$0-10$ Vdc = $0-100$ % rated output, Zout= 1K Ω , 1%
6	kV Test Point	0-10Vdc = 0-100% rated output, Zout= 1K Ω , 1%
7	+10Vdc Reference Output	+10Vdc @ 1mA
8	mA Program Input	0-10Vdc = $0-100$ % rated output, Zin>10MΩ
9	Local mA Program Output	0-10Vdc = 0-100% rated output, front panel pot
10	kV Program Input	0-10Vdc = $0-100$ % rated output, Zin>10MΩ
11	Local kV Program Output	0-10Vdc = 0-100% rated output, front panel pot
12	Remote Power On Output	+24Vdc @ open, <25mA @ closed
13	Remote Power On Return	Return for Remote Power On
14	Remote HV Off	+24Vdc @ open, <25mA @ closed, connect to
15	Remote HV Off/On Common	pin15 for front panel operation HV On/Off Common
16	Remote HV On	+24Vdc @ open, <25mA @ closed, momentarily
10	Hemote HV OH	connect to pin 15 enable high voltage
17	HV Off Indicator	+24Vdc @ 25mA = HV Off
18	HV On Indicator	+24Vdc @ 25mA = HV On
19	Power Supply Common	Supply Ground
20	+24Vdc Output	+24Vdc @ 100mA, maximum
21	Voltage Mode Status	Open Collector, Low = Active
22	Current Mode Status	Open Collector, Low = Active
23	Spare	open deliceter, few = /telive
24	Interlock Closed Status	Open Collector, Low = Active
25	Spare	open deliceter, few = /telive
26	Spare	
27	Spare	
28	Remote Overvoltage Adjust	0-10Vdc = 0-100% rated output
29	Spare	o tordo o tooto taloa oalpal
30	Over Voltage Fault	Open Collector, Low = Active
31	Over Current Fault	Open Collector, Low = Active
32	System Fault	Open Collector, Low = Active
33	RGLT Error Fault	Open Collector, Low = Active
34	Arc	Open Collector, Low = Active
35	Over Temp Fault	Open Collector, Low = Active
36	AC Fault	Open Collector, Low = Active
37	Spare	open deliceter, few = /telive
38	Spare	
39	Spare	
40	Spare	
41	Spare	
42	Spare	
43	Spare	
44	+5Vdc Output	+5Vdc @ 100mA, maximum
45	+15Vdc Output	+15Vdc @ 100mA, maximum
46	-15Vdc Output	-15Vdc @ 10mA, maximum
47	RS232 Tx	, -
48	RS232 Rx	
49	RS232 GND	
50	Power Supply Common	Power Supply Ground
- "		

BEAM CONTROLLER INTERFACE— 25 PIN FEMALE D CONNECTOR


PIN	SIGNAL	SIGNAL PARAMETERS
1	Power Supply Common	Signal Ground
2	Spare	
3	External Interlock	+15Vdc at Open, <15mA @ Closed
4	External Interlock Return	Return for Interlock
5	Filament Current Test Point	0 to 10Vdc = 0 to 100% rated output
6	Beam Current Test Point	0 to 10Vdc = 0 to 100% rated output
7	+10Vdc Reference	+10Vdc, 1mA Max
8	Filament Limit Program Input	0 to 10Vdc = 0 to 100% rated output
9	Local Filament Limit Program	Front panel potentiometer wiper
10	Beam Current Program Input	0 to 10Vdc = 0 to 100% rated output
11	Local Beam Current Program	Front panel potentiometer wiper
12	Filament Preheat Program In	0 to 10Vdc = 0 to 100% rated output
13	Local Fil. Preheat Program	Internal potentiometer
14	Beam Off	+15Vdc at Open, <25mA @ Closed
15	Beam On/Off Common	Connect together for FP operation
16	Beam On	Momentarily connect to pin 15 = Beam On
17	Remote Beam Off Indicator	0=Beam On, +15V, 10mA Max=Beam Off
18	Remote Beam On Indicator	0=Beam Off, +15V, 10mA Max=Beam On
19	Spare	
20	Spare	
21	Spare	
22	Remote PS Fault	0 = Fault, +15Vdc @ 0.1mA = No Fault
23	Spare	
24	Power Supply Common	Signal Ground
25	Shield Return	Chassis Ground





3U 6kW Power Supply

FRONT VIEW





BACK VIEW




PAGE 6 OF 7

DIMENSIONS: in.[mm]


6U 12kW Power Supply

FRONT VIEW





BACK VIEW





279



Beam Controller

FRONT VIEW






BACK VIEW




DIMENSIONS: in.[mm]

Gun Output Box

FRONT VIEW



TOP VIEW



BACK VIEW













The MSC2.5PN7.5 is a bipolar reversible power supply specifically designed for electrostatic chuck clamping applications. Two 0 to 2500 volt @ 7.5 watt reversible outputs that are of opposite polarity are provided on the two high voltage output connectors. Front panel controls via programming buttons and an OLED display allow local operation and control of the unit. The RS-232/RS-485/Ethernet digital interface allows for simple OEM integration into complex system designs.

SPECIFICATIONS

Input:

+24Vdc $\pm5\%$ @ <2 amps. Switch controlled on front panel and fuse protected.

High Voltage Output 1 and Output 2

Voltage:

0 to ±2500 volts. Output 1 and 2 amplitudes are independently programmable

Current:

0 to 3mA

Current Limit:

Output current limits can be independently set in the range of 0.1mA to 3.0mA in 0.1mA steps.

Power:

7.5 watts, maximum

Polarity:

Bipolar, High Voltage Output 1 polarity always opposite of High Voltage Output 2

Voltage Control:

Resolution = 1V

Accuracy = $\pm 1\%$ of programmed value

Regulation:

Line: <0.1% for 10% input voltage change under

any load conditions Load: <1.3% for zero to full load

Stability

<0.1%/hour, <0.2%/8 hours at constant operating conditions after 1 hour warm up

Temperature Coefficient:

<50ppm per degree C

Ripple:

<0.1% p-p at full load, maximum output

Rise and Fall Times:

Rise time (0V to ± 2500 V) and fall time (± 2500 V to 0V) are separately programmable in the range of 300ms to 9.9s (to within 1% of final voltage value)

- Specifically Designed for E-Chuck Applications
- Two Reversible Outputs of Opposite Polarity
- Rated 2.5kV 3mA. Amplitudes are Set Independently
- Automatic User Configurable De-chucking Function
- 300mS Slew Time Driving 20nF of Load Capacitance
- Front Panel Control via Buttons and LCD Display
- RS-232, RS-485 and Ethernet Interface
- Free GUI for Testing and Development Work

Voltage Monitor:

Resolution = 1V

Accuracy = $\pm 1\%$ of actual output (± 8 volt offset)

Current Monitor:

Resolution = $1.25 \mu A$

Accuracy = ±2% of actual output ±100µA offset

Typical Load Capacitance:

<20nF (for other load capacitance, contact Spellman)

Protection:

Arc and short circuit protected. Equipped with input and output current limits. Output current limit settable from 0.1mA to 3mA. Not designed to withstand continuous arcing.

Auto-Toggle/De-Chucking Function:

This unit has both a manual and a customer configurable automatic toggle function (degauss/de-chuck).

Communication:

The unit can be operated locally from the front panel. It can also be controlled through the RS-232/RS-485 serial interface, or Ethernet. The serial interface can be configured via the front panel to either RS-232 or RS-485. The unit is shipped from the factory set to RS-232. 9600 baud, no parity, no handshake or flow control. Note: When Ethernet is connected to the LAN port, Serial comms is disabled

Front Panel Indicators:

The unit has a 20 character by 2 line back lit OLED display and a high voltage status LED. Configuration and setting of various parameters can be accomplished via push button switches. The OLED will power down after five minutes and is reactivated by pressing any button. The red LED indicator illuminates when high voltage is being produced. When the unit is shutdown due to a fault the LED will flash at a 1 Hertz rate until the fault is cleared.

Front Panel Controls:

The unit has front panel buttons for local control.

Local

Front panel control and monitoring via the OLED display

Toggle

Manual change of output polarity

Output On/Off

Soft turns the high voltage output on and off

Mode

Changes the mode of operation and navigation menu

Rotary Control/Enter

For navigating and entering value changes



Environmental:

Temperature Range:
Operating: 0°C to 45°C
Storage: -35°C to 85°C
Humidity:

0 to 85% RH, non-condensing

Cooling:

Convection cooled

Input Power Connector:

2 pin Molex VersaBlade connector. A mating input cable is available (see How To Order table)

Serial Communications Connector:

9 pin female D connector

High Voltage Output Connectors:

Radiall BNC-HT/MHV connector. Mating HV output cables are available (see How To Order table)

Installation Brackets:

A kit including 2 brackets and installation screws (M4x10) allows the unit to be mounted on a half width rack (see How To Order table)

Dimensions:

12.45"L x 8.03"W x 3.46"D (316mm x 204mm x 88mm)

Weight:

3.09lbs. (1.4kg)

Regulatory Approvals:

Compliant to EEC Low Voltage Directive. UK Conformity Assessed. RoHS Compliant.

INPUT POWER — MOLEX VERSABLADE 2 PIN CONNECTOR

PIN	SIGNAL	PARAMETER
1	+24Vdc	+24Vdc @ 2A
2	+24Vdc Return (Gnd.)	Power Ground

SERIAL COMMUNICATIONS— 9 PIN FEMALE D CONNECTOR

PIN	SIGNAL	I/O	SIGNAL PARAMETERS
1	NC	-	Connection
2	Z/TXD	I/O	TXD RS-232/RS-485 Inverting
3	Y/RXD	I/O	RXD RS-232/RS-485 Non Inverting
4	NC	-	No Connection
5	GND	-	Ground
6	NC	-	No Connection
7	NC	-	No Connection
8	NC	-	No Connection
9	NC	-	No Connection

HOW TO ORDER

Description	Part Number
MSC Power Supply	MSC2.5PN7.5
Power input cable, 3m	HVC05/2NSO/1229
HV Output cable, 3m	HVC5/1ISO/1228
Set of brackets for rack mount	MSCK100


DIMENSIONS: in.[mm]

REAR VIEW



M5 GROUND STUD

TOP VIEW



FRONT VIEW





Spellman's ESC Series of electrostatic chuck power supplies provide clean and accurate voltages required for electrostatic chuck wafer processing applications. These custom designed, well regulated supplies precisely secure the wafer during lengthy process cycles. Versions are available with a ground referenced reversible output in addition to units featuring a true floating bipolar output with associated floating center tap point. Comprehensive fault diagnostic circuitry monitors power supply functionality and communicates status data to the user interface. Spellman's ESC Series power supplies are housed in compact, lightweight packages designed for OEM installations requiring minimal system footprint space.

TYPICAL SPECIFICATIONS

ESC5PN25

Output Configuration:

Single ground referenced HV output, positive or negative polarity

Input:

+24Vdc, ±5% @ 2 amps, maximum

Output:

+2kV to -5kV. 2mA @ +2kV, 5mA @ -5kV

Short Circuit Current Limit:

5.5mA, maximum

Output Isolation:

None, ground referenced output

Slew Rate:

80ms, typical

Maximum Cycle Frequency:

10 times per second

Overshoot:

<10% of set point value

Ripple:

10Vrms

Line Regulation:

±0.7% over specified range

Load Regulation:

±0.7% over specified range

Output Voltage Accuracy:

<2% of set point value between 50-5000Vdc

• Ground Referenced, Reversible Output

- Floating, Reversible Bipolar Output
- +24Vdc DC Input
- Comprehensive Fault Diagnostics
- High Voltage Safety Interlock
- OEM Customization Available

Program/Monitor Accuracy:

1% of full scale, ±50mV

Dimensions:

9°W x 1.5°H x 6.1°L (228.6mm x 30.5mm x 155mm)

Weight:

4.5lbs. (2kg)

ESC01.5PN7.5

Output Configuration:

Floating, reversible polarity bipolar output with floating center tap

Input:

+24Vdc, ±10% @ 2 amps, maximum

Output:

Bipolar, 0 to ±750Vdc (0 to 1500Vdc total) @ 5mA

Short Circuit Current Limit:

5.5mA, maximum

Output Isolation:

Center tap is isolated for ±2kV from ground

Slew Rate:

40ms, typical

Maximum Cycle Frequency:

10 times per second

Ripple:

2.5Vrms

Line Regulation:

±0.7% over specified range

Load Regulation:

±0.7% over specified range

Output Voltage Accuracy:

<1% of set point between 50-1500Vdc

Program/Monitor Accuracy:

0.5% of full scale, ±50mV

Dimensions:

3.4 W x 3 H x 10.5 L (86.5mm x 76.5mm x 266.7mm)

Weight:

5lbs. (2.3kg)







Spellman's Injector Control Assembly (ICA) multi-output high voltage power supplies are used to supply the appropriate electrode voltages to a triode electron gun in order to inject electrons into a Linear Accelerator (LINAC). The resulting high-energy electron pulses are used to create high-energy X-Rays for applications such as cargo screening and cancer therapy.

This multi-output, rack mount power supply provides the Cathode, Heater and Grid voltages required by the e-gun. The Cathode current can be pulsed up to 500Hz. The Heater and Grid supplies float at the Cathode voltage potential, typically up to -15kV. Injector current is regulated by programming the Grid Pulse Voltage. Remote control and monitoring is via standard Ethernet protocols. LED indicators on the front panel provide basic output and fault status, including Cathode Current and Arc faults.

The ICA series can be customized for specific system requirements.

TYPICAL APPLICATIONS

Cargo screening, cancer therapy

SPECIFICATIONS

Input Voltage:

100-240Vac, 50-60Hz

Cathode:

Output Voltage:

0 to -15kV

Pulsed Cathode Current:

200mA to 1500mA

Mean Cathode Current:

5.5mA (max)

Current Pulse Width:

Up to 6µs (90% to 90%)

Current Pulse Frequency:

Up to 500Hz

Current Risetime:

200ns (typical)

Heater:

Output Voltage:

0 to -6.5Vdc (wrt Cathode)

Current:

ЗА

Resistance:

0.7ohm

• Multi-Output E-Gun Supply

- Fast Rise Time Pulsed Cathode Current
- Remote Programming via Ethernet
- Customizable for OEM Applications

Grid (fixed):

Voltage:

-60 to -135Vdc (wrt Cathode)

Current:

250mA

Pulse Voltage:

0 to 340Vdc (wrt Cathode)

Injector current is regulated by programming the Grid Pulse Voltage

Connections:

Front Panel:

Ethernet (RJ45 jack)

Interlock (24V nominal, 9 pin D-sub male pin plug)
Pulse Input (BNC)

Rear Panel:

AC Power In (IEC320 C14 male pin receptacle) HV Out (3 pin terminal block)

Interlock:

24V must be present to enable output high voltage cathode. It is intended to connect to the system to disable the ICA in case any system interlocks have not been satisfied.

Operating Temperature:

10°C to +40°C

Storage Temperature:

-40°C to +70°C

Humidity:

30% to 60% relative humidity, non-condensing

Weight:

15lbs. (6.8kg)

Regulatory Approvals:

The ICA is designed to meet 60601-1, and is RoHS compliant.


FRONT PANEL LED INDICATORS


INDICATOR	COLOR	CONDITION Illuminated When
Trigger Present	Green	Input trigger is present
AC Power	Green	AC supply voltage is present
Interlock In	Green	Interlock in signal is present
Arc Fault	Red	Arc fault signal is active
Cathode Current Fault	Red	Cathode current fault signal is active
Cathode Voltage ON	Amber	Cathode high voltage is present






FRONT VIEW





BACK VIEW









The XRV Controller (XRVC) provides intuitive, touch screen driven programming and control of any of Spellman's popular XRV Series of X-Ray generators. This sophisticated and robust controller was designed using an embedded computing system running a custom Graphical User Interface (GUI). The GUI, embedded computer and ancillary hardware are housed in a rugged rack mount or bench top chassis. Capability of the XRVC include: creation of custom X-Ray tube seasoning profiles, one shot or continuous user fabricated operational profiles, automatic X-Ray tube configuration and much more.

SPECIFICATIONS

Input Voltage:

180-264Vac, 50/60Hertz

Dimensions:

Rack mount:

5.25"H x 19"W x 13"D (133.35mm x 482.6mm x 330.2mm)

Bench top:

5.21"H x 17"W x 13"D (132.35mm x 431.8mm x 330.2mm)

Weight:

12 lbs (5.44kg)

Input Power Connector:

14 pin circular connector type 97-3102A-22-19P

Environmental:

Temperature Range:

Operating: 0°C to +50°C

Storage: -20°C to +80°C

Humidity:

0% to 95% RH

Cooling:

Convection cooled

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant

ADVANCED CONTROLLER FUNCTIONALITY

Seasoning

- Ability to create, save and load customized seasoning profiles (Default profiles are included)
- Real time seasoning progress, elapsed time and remaining time clocks
- Automatic notice when seasoning is required

- Intel Atom N270 CPU @ 1.6GHz
- 1GB Ram
- 7" Touch Screen LCD @ 800 x 600
- Intel 945 Express Graphics
- 10/100/1000Mbit Ethernet
- RS-232 Serial Ports
- 160GB Internal Hard Drive

Communications

- Ability to communicate with the XRV over RS-232 serial port
- Ability to communicate with the XRV over a direct crossover Ethernet connection or Ethernet switch

One Shot Profiles

- Ability to create, save and load customized one shot profiles
- Verification of profiles within the operating capabilities of the connected XRV unit

X-Ray Tube Selection


- Specific X-Ray tubes automatically configures the system with the recommended manufactureres operational profiles
- Supported tubes for automatic configuration can be uploaded into the XRVC

Easy to Use

- Intuitive, touch-centric, menu driven system allows operator use with little to no learning curve.
- Communication settings are retained by the XRVC, requiring only a single configuration session.
- Comprehensive status/control screen provides information on all critical operational parameters and system status indicators.

SOFTWARE FEATURES

- Designed for compact, touch centric environment
- Integrated on screen keyboard provides rich input capabilities for operation without an external keyboard
- Adaptive software detects XRV controller and configures accordingly
- Dynamic feedback allows control of unit with real time viewing of the output







Spellman's optional XRV I/O box is the ideal accessory for integrating Spellman's XRV X-Ray generators to a system environment. The XRV can now easily be packaged with industry standard metal ceramic X-Ray tubes, coolers and chillers while meeting all necessary safety and interlock requirements. The XRV I/O box is capable of accommodating a number of control interface options and can be installed in rack or wall configurations to best suit the integrators system placement requirements.

TYPICAL APPLICATIONS

Power distribution for system components

SPECIFICATIONS

Input Voltage:

180-264Vac, 50/60Hz

Operating Temperature:

0°C to +50°C

Storage Temperature:

-20°C to +80°C

Humidity:

0% to 95% relative humidity, non-condensing

Cooling:

Convection

Dimensions:

19.0"W X 5.21"H X 18.00"D (482.6mm X 132.33mm X 330.2mm)

Weight:


30lbs (11.19kg)

Regulatory Approvals:

Compliant to EEC EMC Directive. Compliant to EEC Low Voltage Directive. RoHS Compliant

- Mains to Cooler/Chiller, XRV Generator and XRV Touch Screen Controller
- Integrates all Necessary Safety Mechanisms to X-Ray System Environment to Meet International Standards
- X-Ray On, Pre-Warn and Safety Circuit Lamps
- Monitors Tube Cooling and Door Interlocks
- Rack and Wall Mount Versions Available
- Fail Safe Interlock Option Available

TYPICAL SYSTEM SET UP



See detailed schematic page 3



XRV I/O BOX SELECTION TABLE

MODEL NUMBER	DESCRIPTION
XRV-9-1	Rack mount without XRV controller
XRV-9-2	Rack mount with XRV controller
XRV-9-3	Wall mount without XRV controller
XRV-9-4	Wall mount with XRV controller
XRV-9-5	Rack mount without XRV controller with optional safety relay for interlocks
XRV-9-6	Rack mount with XRV controller with optional safety relay for interlocks

TB1, TB2, TB3-MAIN AC INPUT POWER-

PIN	SIGNAL	PARAMETERS
TB1-1	Line 1	180 - 264Vac
TB2-1	Line 2	Neutral or 180 - 264Vac (3 phase source)
TB3-1	GND	Ground

TB4- COOLER / CHILLER-MAINS AC OUTPUT

PIN	SIGNAL	PARAMETERS
1	Line 1	180 - 264Vac
2	Line 2	180 - 264Vac or Neutral
3	GND	Ground

TB5-COOLER / CHILLER INTERLOCKS

PIN	SIGNAL	PARAMETERS
1	Flow INTLK	Dry contacts, ≤24Vdc
2	Common	Dry contacts, ≤24Vdc
3	Temp INTLK	Dry contacts, ≤24Vdc

TB6-LOW VOLTAGE / DOOR INTERLOCKS

PIN	SIGNAL	PARAMETERS
1	Door INTLK	Dry contacts, ≤24Vdc
2	Door INTLK	Dry contacts, ≤24Vdc

TB7-XRV I/O MAINS TO CDRH* SAFETY INTERLOCK

PIN	SIGNAL	PARAMETERS
1	Power INTLK Line 1 OUT	180 - 264Vac
2	Line 1 IN	180 - 264Vac
3	Power INTLK Line 2 OUT	Neutral or 180 - 264Vac (3 phase source)
4	Line 2 IN	Neutral or 180 - 264Vac (3 phase source)
5	GND	Ground

*CDRH (Center for Devices and Radiological Health) Safety Interlock Switch meets FDA 21 CFR 1020.40 requirements.

This switch has both low voltage interlock and power interlocks for the XRV mains.

TB8-XRV AUX AC OUTPUT-TO XRV JB1

PIN	SIGNAL	PARAMETERS
Α	Line 1	180 - 264Vac
В	Line 2	Neutral or 180 - 264Vac (3 phase source)
С	GND	Ground


TB9-XRV I/O TO XRV CONTROLLER INTERFACE

PIN	SIGNAL	PARAMETERS
1	Line 1	180 - 264Vac
2	Line 2	Neutral or 180 - 264Vac
3	GND	Ground
4	INTLK 1	Dry contacts, ≤24Vdc
5	INTLK 2	Dry contacts, ≤24Vd
6	INTLK Common	Common for INTLK 1, 2
7	X-Ray ON Light	Dry contacts, ≤24Vdc
8	Pre-Warn Light	Dry contacts, ≤24Vdc
9	Light Common	Light common
10	Key Switch 2	Dry contacts, ≤24Vdc
11	Key Switch 3	Dry contacts, ≤24Vdc
12	Key Switch Common	Key common


TB11-X-RAY ON / PRE-WARN LIGHTS


PIN	SIGNAL	PARAMETERS
1	X-Ray ON Light	180 - 264Vac, 5 amp
2	X-Ray ON Light	180 - 264Vac, 5 amp
3	Pre-Warn Light	180 - 264Vac, 5 amp
4	Pre-Warn Light	180 - 264Vac, 5 amp

PAGE 3 OF 4










SIDE VIEW



BACK VIEW





+1-631-630-3000



Corporate Headquarters



Resistive Voltage Dividers

...for the measurement of high voltages using a standard digital voltmeter*

Spellman's HVD Series of high voltage dividers provide laboratory or production facilities with a convenient method of measuring up to 100kVdc, 200kVdc or 400kVdc with accuracy better than 0.5%. These dividers are designed for use with high impedance digital voltmeters. All HVD dividers are housed in a polycarbonate cylinder containing a matched set of precision metal film resistors which have a temperature coefficient of less than 25ppm. A ladder-type construction technique is used in conjunction with polished high voltage bushings specifically designed to minimize corona. BNC connectors are used to provide the low voltage proportional output signal.

The HVD Series of high voltage dividers have no inferred bandwidth measurement capability what so ever. They are intended for DC steady state measurement only.

Custom Encapsulated OEM High Voltage Dividers

Spellman designs and manufactures a wide array of custom encapsulated high voltage dividers for OEM applications like ion beam implantation for semiconductor manufacturing. Unique HV divider sizes, shapes, mounting arrangements and terminations can be provided addressing specific custom requirements. Contact Spellman to discuss your needs with our knowledgeable sales staff.

Calibration

Spellman provides an NIST traceable calibration certificate with each HVD. A yearly recalibration cycle is recommended. Contact Spellman for calibration services.



	HVD100	HVD200	HVD400
Input Voltage	0-100kVdc	0-200kVdc	0-400kVdc
Input Impedance	1000Mohms	2000Mohms	4000Mohms
Output Impedance	1M; 100kohms	20kohms	40kohms
Output Taps	100V, 10V	2V	4V
Accuracy	0.5%: (0.1% opt) ¹	0.5%: (0.25% opt) ²	0.5%
Stability	0.01%/8hrs	0.025%/8hrs	0.025%/8hrs
Temp. Coefficient	25ppm/°C	25ppm/°C	25ppm/°C
Height	17.5" (44.5cm)	33.5" (84.5cm)	61" (154.94cm)
Max. Diameter	10" (25.4cm)	12" (30.5cm)	20" (50.8cm)
Weight	6.75 lbs (3.1kg)	12 lbs (5.5kg)	24.45 lbs (11.8kg)
Output Connector	BNC type	BNC type	BNC type

⁽¹⁾ For accuracy of 0.1% specify HVD100-1(2) For accuracy of 0.25% specify HVD200-1

WARNING

DANGEROUS LIFE THREATENING VOLTAGES MAY BE PRESENT ON THIS EQUIPMENT. OBSERVE EXTREME CAUTION WHEN OPERATING OR WORKING NEAR HIGH VOLTAGE DEVICES. NEVER TOUCH ANY HIGH VOLTAGE ASSEMBLY THAT IS SUSPECTED TO BE ENERGIZED OR CHARGED. DO NOT HANDLE OR COME WITHIN THE PROXIMITY OF HIGH VOLTAGE CONNECTIONS UNTIL ALL EQUIPMENT IS TURNED OFF AND THE SETUPS CAPACITANCE IS DISCHARGED. FAILURE TO FOLLOW SAFETY PROCEDURES MAY BE FATAL.



inaccurate measurements.

^{*}for use with digital voltmeter 10Gohms or higher.

Note: Due to the high input impedance requirement connecting the HVD to an oscilloscope input (1Mohms input impedance) will cause erroneous,

Spellman USA and Corporate HQ

475 Wireless Bivd.
Hauppauge, NY 11788
United States
tel: +1 631-630-3000
fax: +1 631-435-1620
email: sales@spellmanhv.com

Spellman Valhalla NY USA

One Commerce Park Valhalla, NY 10595 United States tel: +1 914-686-3600 fax: +1 914-686-5424

Spellman UK

Broomers Hill Park #14, Broomers Hill Pulborough, West Sussex, United Kingdom RH20 2RY tel: +44 (0) 1798 877000 fax: +44 (0) 1798 872479

Spellman Japan

Kano Bldg. 5F, 1-26-7 Nishigotanda, Shinagawa-ku, Tokyo 141-0031 Japan tel: +81 (0) 3-5436-9810 fax: +81 (0) 3-5436-9811

Spellman China

Spellman High Voltage Electronics (SIP) Co Ltd. No. 86 Jinjiang Road, Suzhou Industrial Park 215217 China tel: +86-512-67630010 fax: +86-512-67630030

Spellman High Voltage Korea Co.,Ltd.

#B-720, BRC Smart Valley, Song Do Mirae-ro 30, Yeonsu-Gu, Incheon, Korea 406-081 tel: +82 32-719-2300 fax: +82 32-720-4300

Spellman de Mexico - Plant 2

Avenida Pedregal # 2 Esquina Avenida Chapultepec Parque Industrial FINSA Oriente Matamoros, Tamps., Mexico 87340 tel. +52 868 150-1200

Spellman de Mexico - Plant 3

Avenida Chapultepec # 101 Esquina Avenida Horizonte Parque Industrial FINSA Oriente Matamoros, Tamps., Mexico 87340 tel. +52 868 150-1200

Spellman High Voltage GmbH

Josef-Baumann-Straße 23 44805 Bochum Germany tel: +49 (0) 234 87906-0

